

User Manual

Rotem
Trio
Poultry



Rotem Trio

Poultry Controller

P/N: 116924



Trio Poultry Controller

User Manual

Rev R2.1, 06/2025

Product Software: Version 8.5.29-2.0

This manual for use and maintenance is an integral part of the apparatus together with the attached technical documentation.

This document is destined for the user of the apparatus: it may not be reproduced in whole or in part, committed to computer memory as a file or delivered to third parties without the prior authorization of the assembler of the system.

Munters reserves the right to effect modifications to the apparatus in accordance with technical and legal developments.

Table of Contents

<i>Chapter</i>		<i>page</i>
1	INTRODUCTION	9
1.1	Disclaimer.....	9
1.2	Introduction	9
1.3	Notes	9
2	THE TRIO TOUCH SCREEN.....	10
2.1	Icons	10
2.2	Dashboard.....	11
2.3	Power Outage.....	13
2.3.1	Trio Dashboard	13
2.3.2	TrioAir	13
3	BASIC SETUP.....	14
3.1	Defining the General Settings	14
3.1.1	Defining the Preferences	14
3.1.2	Defining the Time/Date.....	15
3.1.3	Defining the Sleep Mode	15
3.1.4	Defining the House Setting.....	16
3.2	Flock Settings	17
3.2.1	Manual Set Up	17
3.2.1.1	Flock Settings Main Screen.....	17
3.2.1.2	Settings	18
3.2.1.3	House Modes	19
3.2.2	New Flock Wizard	19
3.3	Adjusting the Bird Count	22
4	TEMPERATURE SETTINGS	24
4.1	What is the Temperature Curve	24
4.2	Configuring the Temperature Curve.....	25
4.2.1	Defining the Temperature Curve Parameters.....	25
4.2.2	Defining Temperature Curve Settings	26
4.3	Emergency Temperature Control.....	27
4.4	Temperature Humidity Index.....	27
5	INTRODUCTION TO VENTILATION.....	29
5.1	Defining the Minimum and Maximum Ventilation	29
5.2	Defining the Fans/Ventilation Scheme.....	30

5.2.1	Basic Ventilation	30
5.2.2	Extra Ventilation	31
5.2.3	Tunnel Ventilation	32
5.2.4	Manual Fan Operation.....	32
6	MINIMUM AND MAXIMUM VENTILATION	34
6.1	Building Structure Summary	34
6.2	Defining Basic Ventilation.....	35
6.2.1	Defining Dynamic Ventilation	36
6.2.2	Ventilation by Weight.....	38
6.2.2.1	How Does Ventilation by Weight Work	38
6.2.2.2	Defining the Ventilation By Weight Parameters.....	38
6.2.3	Adding a Curve.....	39
7	LEVELS OF VENTILATION	40
7.1	Configuring the Basic Ventilation Settings	40
7.2	Basic Ventilation.....	41
7.2.1	Defining Basic Ventilation	41
7.2.2	Fan Options	43
7.2.2.1	Minimum Ventilation Cycle.....	44
7.2.2.2	Analog Fans	46
7.2.2.3	Fans (Efficiency Fan)	47
7.2.2.4	Fan Rotation.....	49
7.2.3	Inlet and Curtain Ventilation	51
7.2.3.1	Level Control	52
7.2.3.2	Static Pressure Control	53
7.2.3.2.1	Static Pressure in Minimum Ventilation or Extra Ventilation	53
7.2.3.2.2	Static Pressure Main Screen.....	54
7.2.3.2.3	Static Pressure Settings Screen.....	55
7.2.3.2.4	High Static Pressure Alarm State.....	55
7.2.3.3	Manual Inlet/Tunnel Door Operation	55
7.3	Extra Ventilation.....	55
7.3.1	Introduction to Extra Ventilation.....	56
7.3.2	Defining Extra Ventilation	56
7.4	Tunnel Ventilation.....	58
7.4.1	Defining the Tunnel Ventilation Parameters.....	58
7.4.2	Defining the Tunnel Ventilation Settings.....	61
7.4.3	Tunnel Doors.....	62
7.4.3.1	Tunnel Ventilation	62
7.4.3.2	Basic Ventilation.....	62
7.4.4	Defining the Wind Chill Factor.....	63
7.4.5	Tunnel Ventilation Static Pressure	65
7.5	Testing the Ventilation System	66

7.6	Calibrating the Inlet/Tunnel Door.....	68
7.7	Stir Fan.....	70
7.7.1	How do Stir Fans and Exhaust Fans Work Together?.....	70
7.7.2	Defining the Stir Fan Functionality.....	72
8	COOLING.....	75
8.1	Cooling Pads.....	75
8.1.1	Cooling Principles.....	75
8.1.2	Selecting the Cooling Mode.....	76
8.1.2.1	Continuous Cooling.....	78
8.1.2.2	Cycle Cooling.....	79
8.1.2.3	Ramping Cooling.....	80
8.2	Foggers.....	81
9	HEATING FUNCTIONS.....	84
9.1	Heating Functions.....	84
9.2	Toggle Switch Options.....	85
9.2.1	Automatic Operation.....	85
9.2.2	Manual Operation.....	85
9.3	Second Stage Heating.....	85
9.3.1	What is Second Stage Heating.....	85
9.3.2	How do Heaters and High Heaters Work Together?.....	85
9.4	Central Heaters.....	87
9.5	Zone Heaters.....	89
9.6	Heating Options.....	91
9.6.1	Analogue Heaters.....	91
9.6.2	Heat Cycles.....	91
10	BROOD AREA.....	93
11	FEED AND SILO MANAGEMENT.....	96
11.1	Feeding Summary.....	96
11.2	Setting up Feeding.....	96
11.2.1	Automatic Feed Control.....	96
11.2.2	Manual Feed Control.....	99
11.3	Configuring the Silo.....	99
12	WATER CONTROL.....	101
12.1	Introduction to Water on Demand.....	101
12.1.1	How is Water Pressure Measured.....	101
12.1.2	Water Program Control.....	101
12.1.3	Water Pressure Units.....	101
12.2	Setup.....	101
12.2.1	WOD Relay Control.....	102
12.2.1.1	WOD - Time Control.....	102

12.2.1.2	WOD - Light Control.....	103
12.2.2	WOD Pro 0 - 10 Volt Control.....	104
12.2.2.1	WOD Pro - Time Control.....	105
12.2.2.2	WOD Pro - Light Control.....	106
12.2.2.3	WOD Pro Pressure Alarms	107
12.2.3	Manual Control Over Lighting and WOD.....	108
12.3	Flushing the Drinking Lines	108
13	LIGHTING PROGRAM.....	110
13.1	Relay Control	110
13.2	0 - 10 Volt Control.....	113
13.3	Service Lights.....	115
13.4	Light Intensity Alarm	117
14	EXPECTED BIRD WEIGHT.....	118
14.1	Reference Bird Curve	118
14.1.1	Curve Enabled	118
14.1.2	Curve Disabled	120
14.2	Male/Female Weighing	121
14.2.1	Gender Separated Weighing	121
14.2.2	Non-Separated Weighing	122
15	AIR QUALITY	124
15.1	Defining the Air Quality Parameters.....	124
15.2	Defining the Air Quality Settings	125
16	TIMERS	127
17	ALARMS.....	130
17.1	Defining the Alarm Parameters.....	130
17.1.1	Alarm Definitions.....	130
17.1.2	Alarm Test	131
17.1.2.1	Manual Test	131
17.1.2.2	Scheduled Tests	131
17.2	Viewing the Alarms.....	132
17.3	Defining the Auxiliary Alarms.....	132
17.4	Sending a General Alarm.....	134
17.5	Water Alarm	135
18	HISTORY.....	137
18.1	Climate and Air Quality.....	137
18.2	Alarms and Events	138
18.3	Water and Feed History	139
18.4	Devices History	140
18.5	Bird Weight History.....	141

19	RESETTING, SAVING AND LOADING SETTINGS, UPDATING SOFTWARE	142
19.1	Resetting the Settings.....	142
19.2	Resetting the Trio CPU and Sensor Connections	143
19.3	Saving or Loading the Settings	144
19.4	Viewing the Log.....	144
19.5	Updating the Software.....	145
20	WARRANTY	146

1 Introduction

1.1 Disclaimer

Munters reserves the right to make alterations to specifications, quantities, dimensions etc. for production or other reasons, subsequent to publication. The information contained herein has been prepared by qualified experts within Munters. While we believe the information is accurate and complete, we make no warranty or representation for any particular purposes. The information is offered in good faith and with the understanding that any use of the units or accessories in breach of the directions and warnings in this document is at the sole discretion and risk of the user.

1.2 Introduction

Congratulations on your excellent choice of purchasing a Trio Poultry Controller!

In order to realize the full benefit from this product it is important that it is installed, commissioned and operated correctly. Before installation or using the controller, this manual should be studied carefully. It is also recommended that it is kept safely for future reference. The manual is intended as a reference for installation, commissioning and day-to-day operation of the Munters Controllers.

1.3 Notes

Date of release: Jan 2020

Munters cannot guarantee to inform users about the changes or to distribute new manuals to them.






All rights reserved. No part of this manual may be reproduced in any manner whatsoever without the expressed written permission of Munters. The contents of this manual are subject to change without notice.

2 the Trio Touch Screen

- Icons
- Dashboard
- Power Loss


2.1 Icons

	
	Go back to the previous screen
	View the Main menus
	Choose language
	Trio connected to internet via Wi-Fi. Click to view network settings.
	Trio connected to internet via LAN. Click to view network settings.
	View alarms
	Go back to the main screen
	Extra menus
	Edit parameters
	Function settings


	Function test
	Replace the dashboard battery with a standard 3V battery.
	Click this icon to delete data stored on that page.
Phone App	
	Click the circle containing the user name to edit personal preferences such as the language, units, name, and more.
	When a Trio controls two or more rooms or there are two or more houses on a farm, Send to All enables editing certain select functions in more than one room or house. Edit the setting, click Send to All, and select the required Trios. The select rooms' or houses' settings are updated. Note: Send to All does not appear on every screen.


2.2 Dashboard



The Dashboard gives an overview of all Trio functions.



Trio Rotem displays the house mode, when defined in any mode besides Growing Mode (refer to Manual Set Up, page 17).



- Click on the  in each section to go to the relevant control page.
- Click on Ventilation, Temperature, or Devices squares to view the hot screen for those functions.




2.3 Power Outage

- Trio Dashboard
- TrioAir


2.3.1 TRIO DASHBOARD

In the event of a power outage, the following warning appears:



Power Loss

Immediate Attention Required



- The power supply has been lost and the device is currently running on backup battery power
- If you have enabled the Alarm system for your account, an alert has been sent to all relevant contacts
- The controller will automatically shut down shortly

00:00:21

- Controller functions will cease
- The alarm will be delivered by all approved methods.
- Once power is re-applied, the controller resumes normal operations.

CAUTION This warning only appears in units equipped with a backup battery. Refer to the Installation Manual for more details.

2.3.2 TRIOAIR

In situations where no other internet services are available, farms subscribed to the TrioAir Premium package can receive an alarm via TrioAir. To enable this service, the Trio must be equipped with a cellular modem and an integrated Munters SIM card. Refer to the [TrioAir Zendesk](#) for more details.

3 Basic Setup

The following section describes the initial steps to be performed after completing the physical installation.


- Defining the General Settings
- Flock Settings
- Adjusting the Bird Count

3.1 Defining the General Settings

- Defining the Preferences
- Defining the Time/Date
- Defining the Sleep Mode
- Defining the House Setting

3.1.1 DEFINING THE PREFERENCES


1. Go to System > General Settings > User .



2. Define the units: There are two options:


- Define all units as metric or imperial.
- Define each unit. Click Edit > Customize and define:
 - Temperature (Celsius or Fahrenheit)
 - Pressure (Pascal/Inches of Water)
 - Weight (Kilogram/Pounds)
 - Air Flow: Cubic Meter/Hour or Cubic Feet/Minute

3. Enable/disable Pin Code Access: Pin Code Access is a security measure. Anyone wanting to edit the settings must have this code.



3.1.2 DEFINING THE TIME/DATE

1. Go to System > General Settings > Time & Date



2. Click **Edit** and define:

- Time
 - Automatic Date & Time Adjustment: Enable this option to update date and time automatically.
 - Date and Time Set: Manually enter the date and time.
- Time Zone: Select the zone from the drop-down list.


CAUTION Set the time zone even if you enable automatic date and time adjustment.

3.1.3 DEFINING THE SLEEP MODE

To extend the life time of the controller display screen's LEDs, the screen dims after a given amount of time has passed since a user touches the screen.

1. Go to System > General Settings > Time & Date






2. Click Edit and define:

- Turn Display Off After: 15, 30, 45 minutes (15 minute default).
- Display Sleep Mode Default: Choose 24 hours or define the time frame.

3.1.4 DEFINING THE HOUSE SETTING

Go to System > House Settings. The screen enables the user to set the house dimensions. Set them according to the actual house size. These dimensions are used for calculating the wind chill factor.



- Define:
 - House number. Each controller on a network must have a unique number.
 - Define height, width, and length of house (controller calculates total area).
 - To set the dimensions in metric or non-metric units, go to Defining the Preferences, page 14 and edit the units.

3.2 Flock Settings

Flock Settings are data points used to define each flock. Define these settings at the beginning of a growth cycle. Flock settings include:


- Growth day (used in various system algorithms)
- Flock number enables tracking each flock's production
- Manual Set Up
- New Flock Wizard

3.2.1 MANUAL SET UP

- Flock Settings Main Screen
- Settings
- House Modes

3.2.1.1 Flock Settings Main Screen

1. Go to Flock > Flock Settings.




2. Define:

- Growth day:: This parameter defines the birds' age. Growth day automatically goes up by one (1) at midnight. When editing the growth day, you can increase the number; you cannot decrease the number. Trio increases the growth day at midnight. Range: 0 - 999
- Initial Number of Birds: Set the number of birds that are in the beginning of a flock (150,000 maximum).



NOTE In case birds die, you can edit the number of birds. Go to Adjusting the Bird Count, page 22.

NOTE If you wish to display the number of female and male birds separately, go to Control Strategy > Flock and enable Separate Male/Female. Refer to Gender Separated Weighing, page 121. Trio Controller supports up to 150,000 birds in each gender.



- Flock No.: Give a unique number for each flock.
- House Mode: Room mode enables or disables general functionality. When defined as Growing, all functions can be enabled. Growth day is managed as above. If you switch the room to a different mode, growth day stops advancing and only certain, specific functions are enabled. If you select a house mode other than Growing, the mode is displayed on the Dashboard.
 - The House Modes are detailed in House Modes, page 19.
 - For information on Brooding mode, refer to Brood Area, page 93.

3.2.1.2 Settings



2. Click the required tab and define:
- Set the target temperature above which ventilation output increases. Range: -40 to +192° F; Default: +75.2° F
 - Minimum/Maximum Ventilation: Set the minimum and maximum ventilation for air exchange, according to the birds' age. If these values are the same, ventilation is constant.

- Heating: This parameter enables heating and defining a heating temperature in each special room mode.
 - Enable the heater.
 - Define the temperature at which the heater turns on.

NOTE A heater relay must be defined and mapped for this parameter to appear.

- Turn On Lights: This parameter turns on lights when the mode is activated.
 - Enable the lights.
 - Lights Output: Define the light intensity.

NOTE A light relay must be defined and mapped for this parameter to appear.

- Enable Temperature Alarms: Set the temperature below/above which Trio activates an alarm. Range:
 - Enable the alarm.
 - Low alarm: -40 to +103° F; Default: 32°
 - High alarm +0.9 to 193.9° F; Default: 104°

3.2.1.3 House Modes

“Flock Settings” Settings page defines basic parameters for houses when these room are NOT in Growth mode. All four modes have the same parameters.

- Empty: Empty house mode is used when the whole house is empty (meaning, between flocks).
 - Provide ventilation according to the output set by the heat and ventilation.
 - Growth day stays at zero.
 - Stop water alarm - even when the alarm function is enabled.
- Pre-Heat: Pre heat the facility before moving the birds in to the pre-heat temperature set-point. This mode is used 24 – 72 hours before starting a new flock. If you wish to use this mode, the Wizard option appears. Refer to the next section.
- Cleaning: Between batches the facility is cleaned by soaking.
 - Provide ventilation according to the output set by the heat and ventilation.
 - Stop growth day progress.
- Catching: Catching Mode is used when birds are being removed from the chicken house. In this mode:
 - Provide ventilation according to the level
 - Heat output should be OFF.
 - Growth day stays at zero.
 - Turn on light if enabled. The user defines the lighting intensity.


3.2.2 NEW FLOCK WIZARD

Trio provides a simple to use wizard to set up the Growing or Pre-Heat modes. Using the wizard enables defining negative growth days. When starting a new flock Trio:


- Erases historical data
- Sets the growth day to zero

- Increases the number by one
- Records a “New Batch” event

1. Click




2. Define the flock number and click Next.




3. Select Growing or Pre-Heat. You must select an option to continue.

- Growing Mode



- Define the Growth Day (zero or higher), Initial Number of Birds, and Initial Bird Weigh.

- Pre-Heat Mode:



- Define:
 - Growth Day (-7 or higher; default is -2)
 - Initial Number of Animals
 - Next Growing Stage
 - Initial Bird Weight

3.3 Adjusting the Bird Count

Edit the number of birds when removing or adding them to/from to the flock.

1. Go to Flock > Bird Management. This screen displays the bird mortality data.

Day	Daily			Total		
	Dead	Culled	Moved	Total Mortality	Mortality %	Bird Count
3 19/07/2023	17	4	10	21	0.4 %	4,969
0 16/07/2023	0	0	0	0	0 %	5,000

- Dead: Number of birds found dead.
- Culled: Number of injured or sick birds removed.
- Moved: Number of birds moved daily. This refers to birds that were moved for reasons other than death. This number is not factored into the mortality percentage rate.
- Total Mortality: Cumulative mortality.
- Mortality %: Total mortality divided by the initial number of birds.
- Bird Count: Current bird count. Trio calculates this number based on the above factors.

NOTE If you wish to display the number of female and male birds separately, go to Control Strategy > Flock and enable Separate Male/Female. Refer to Gender Separated Weighing, page 121.


Day	Female Today			Female Total			M: Dead
	Dead	Culled	Moved	Total Mortality	Mortality %	Bird Count	
1 10/05/2023	9	4	0	13	0.1 %	9,987	6

2. To adjust the number of birds:

- Click **Add Mortality** and edit the number of birds that died or were culled.


- Click **Moved Birds** to enter the number of live birds removed from the house. This number is used when calculating the total number of birds, but not the mortality.

Click the graph symbol to view the data in a chart form.



The Dashboard summarizes this screen's data showing:

- the current total number of birds.
- the FCR (feed conversion ratio (the amount of feed delivered converted to meat. The lower the number, the better)).
- the mortality rate.



4 Temperature Settings

- What is the Temperature Curve
- Configuring the Temperature Curve
- Emergency Temperature Control
- Temperature Humidity Index

4.1 What is the Temperature Curve

As animals grow, the required air temperature changes. Trio enables setting up a temperature chart in which you set the target temperatures for (up to) 10 days in the growth cycle. Target temperature is the ideal temperature for birds on that growth day. After defining the target temperatures and growth days, Trio creates a curve in which the target temperature automatically, gradually adjusts itself. As the growth days increase, the target temperature gradually decreases to the next setting.

For example, if on day 1 the target temperature is 95° F and on day 5 the target temperature is 86° F, Trio adjusts the target temperature on days 2 to 4 so that it approaches the day 5 setting.




Figure 1: Temperature Curve Example

In addition the Temperature Curve has secondary functions:


- Defines when heating begins in cases where the actual temperature drops below the target temperature (**Heat**).
- Defines when heating turns off.
- Defines when an alarm is sent when temperatures are too low (**Low Alarm**)
- Defines when an alarm is sent when temperatures are too high (**High Alarm**)

4.2 Configuring the Temperature Curve

- Defining the Temperature Curve
- Defining Temperature Curve Settings

4.2.1 DEFINING THE TEMPERATURE CURVE PARAMETERS

1. Go to Climate > Temperature Curve.



Day	Target	Heat	Cool	Tunnel	Low T° Alarm	High T° Alarm	Current Target
0	80.1 °F	78 °F	90 °F	90 °F	70 °F	90 °F	80.3 °F
5	82 °F	78 °F	82 °F	82 °F	70 °F	90 °F	
10	82.5 °F	79 °F	82.5 °F	82.5 °F	69 °F	91 °F	

2. Configure up to 10 points in the curve.

3. Define:


- Day: Define the growth day at which each temperature spec applies. Each day must have a unique number. Range: 0 – 999.
- Target: Target temperature is the required temperature for the bird house. All ventilation calculations are based on this specification. Range -40° to +90° C/-40° to +194° F.
- Heat: This parameter is the set point at which the heaters are activated.
- Cool: This parameter is the set point at which cooling devices are activated. When the target temperature changes, this number changes accordingly.

NOTE Heat and Cool appear if a heater and cooler are defined in Devices and Sensors.

- Tunnel: This parameter is the set point at which tunnel ventilation begins. When the target temperature changes, this number changes accordingly. Range: Target temperature to +90° C/194° F.

NOTE Tunnel appears if Tunnel Ventilation is enabled in Ventilation Settings (page 58).

- Low/High Temperature Alarm: These parameters are temperatures at which Trio sends an alarm.



4. Click  to view the curve history.

4.2.2 DEFINING TEMPERATURE CURVE SETTINGS

The screenshot shows the 'Temperature Curve → Settings' screen for 'House 1'. At the top, there are navigation icons (back, menu, home) and a status bar showing 'DAY 0' and 'TIME 12:08'. The main settings area includes:

- Target Offset:** A control with minus and plus buttons and a text input field set to '0.0 °F'.
- Temperature Sensor Alarm:**
 - Sensor Low T° Below Alarm (diff):** A text input field set to '0.0 °F'.
 - Sensor High T° Above Alarm (diff):** A text input field set to '0.0 °F'.
- High Temperature Alarm:**
 - Enable Compensation:** A toggle switch that is currently turned on.
 - Outside Temperature Compensation:** A text input field set to '18.0 °F'.
 - Absolute High Temperature:** A text input field set to '95.0 °F'.

On the right side, there is a numeric keypad labeled 'Range' with buttons for digits 1-9, a decimal point, and an 'Enter' button.

1. Click



2. Define:

- Target Offset: Adjusts all temperature curves by this amount. You can use this to temporarily adjust all temperatures up or down for special circumstances. The offset applies to all table parameters.
- Sensor Low T° Below Alarm: Set value below which the “Low temperature sensor” alarm is activated. This is a differential. Range 0.0° - 17.9°
- Sensor High T° Above Alarm Diff: Set value above which the “High temperature sensor” alarm is activated. This is a differential. Range 0.0° - 17.9°
- High Temperature Alarm. Enable if required.
 - Outside Temperature Compensation: High temperature set point = measured outside temperature + “outside temperature compensation”. Range [0.0° - 17.9°]
 - Absolute High Temperature: Set the critical temperature (maximum allowable).

4.3 Emergency Temperature Control

In the event that Trio fails to receive a signal from the temperature sensor for an extended period of time, an alarm is triggered. Between the time that Trio stops receiving a signal and when an alarm is triggered, ventilation remains at the current level. When an alarm is triggered:

- If there is an outside temperature sensor:
 - ventilation is adjusted.
 - Ventilation levels will not fall lower than the Minimum Ventilation
- If there is no outside temperature sensor
 - maintain the last known positive output (before the failure)
 - turn off negative output
 - Cooling and air quality treatment cease

4.4 Temperature Humidity Index


As an option, Rotem Trio can operate the ventilation according to a temperature-humidity index (THI), a formula that combines the temperature and humidity levels. This formula measures heat stress and is an industry standard that can be used to provide ventilation efficiently. Based on this formula, Trio recalculates the target and heat temperatures defined in the Temperature Curve screen. Ventilation is then based on the calculated values. Please note:

- The calculated target temperature can be higher or lower than the standard target temperature.
- When this option is used:
 - the Humidity Treatment continues to function.
 - the temperature curve offset is disabled.
- THI does not affect the Tunnel Temperature.
- THI does not affect CO₂ or Ammonia treatments.
- THI temperatures only operate when the controller provides minimum ventilation (meaning, not in Tunnel Mode).


To set the THI:

- ➡ Install a humidity sensor.

1. Go to System > Control Strategy > Climate .



2. Enable the THI function.
3. Go Climate > Temperature Curve > Settings.



4. Define:

- Humidity Rest Point: Define the level of humidity at which THI has no effect. Range: 55-75%.
- Target offset per 10% RH: Define the change to the target temperature for each 10% difference from the Humidity Rest Point. Range: 0 - 5° C
- Maximum offset below target: Sets the maximum change below the target temperature. Range: 0 - 5° C. Default 3° C
- Maximum offset above target: Sets the maximum change above the target temperature. Range: 0 - 5° C. Default 1° C

5 Introduction to Ventilation

Defining Munters' Trio ventilation consists of three elements:

- [Defining the Minimum and Maximum Ventilation](#): Defining the minimum and maximum ventilation defines how much air is required for any given growth day. Based on these requirements, Trio determines which fans run.
- [Defining the Fans/Ventilation Scheme](#): Defining the fans/ventilation determines how much air the fans provide and which fans provide the air.
- In addition, Trio controls the inlets and tunnel doors. There are two ways to control the inlets and tunnel doors:
 - Static pressure: Based on the difference in the interior and exterior air pressures, Trio continually calculates the inlets'/doors' opening positions. When inlets/doors change to another level, they do so before the fans increase/decrease to that level. Note that Trio uses the positions assigned to the inlets/tunnel doors levels as the minimum position.
 - Position control: The user can define the opening positions of the inlets, outlets, and tunnel doors by level. Note that when inlets/doors change to another level, they do so before the fans increase/decrease to that level.
- Inlet control is fully explained in Inlet and Curtain Ventilation, page 51.

5.1 Defining the Minimum and Maximum Ventilation

In setting up the Climate > Min/Max Ventilation screen, the user defines the lower and upper ventilation limits during the growth cycle: the minimum and maximum amount of air exchange allowed for each growth day.

- When minimum ventilation is operating, the ventilation works to ensure that there is sufficient clean air while keeping the air temperature close to the target temperature.
- The maximum limit ensures that the birds/animals do not receive too much air during any particular growth stage.
- If the temperature is above the target temperature by a sufficient amount, the ventilation level increases. If the increase in ventilation does not reduce the temperature, ventilation increases until it reaches the maximum amount defined for that growth day.
- If the temperature decreases to a user-defined point, heaters can turn on. At this temperature, ventilation will be at the minimum level.

Options:

- Day curve only.
- Dynamic Ventilation: This option enables increasing or decreasing the minimum/maximum ventilation based on the outside temperature.

- Dynamic minimum: The controller adjusts the minimum between the cold and warm set points according to a user-defined differential from the target temperature.
- Dynamic maximum: The controller adjusts the maximum between the maximum cold and max warm set points according to a user-defined differential from the target temperature.

For more information, refer to Defining Dynamic Ventilation, page 36.

- Ventilation by Weight: The user defines the amount of air to be supplied to the birds, based on their cumulative weight. For more information, refer to Ventilation by Weight, page 38.
- Curve: Trio calculates a curve between growth days; the increase between days is steady. If a curve is not enabled, ventilation increases at the next defined growth day. For more information, refer to Adding a Curve, page 39.

5.2 Defining the Fans/Ventilation Scheme

Trio enables defining the volume of air supplied using three different methods:

- Basic (required)
- Extra (option)
- Tunnel (option)

5.2.1 BASIC VENTILATION


Basic Ventilation provides extremely precise levels of ventilation. There are up to 10 levels of ventilation (the user can define less than 10 if desired). Each level represents a 10% increase in ventilation, with Trio precisely adjusting the fan speeds and combinations to ensure that exactly the right amount of air is being provided. At each level, the user defines what combination of fans provide the required level of ventilation. Before going to the next level, fans will provide the maximum amount of air possible at that level.

Depending on the type of fans installed, Basic Ventilation supports on-off fans, variable fans, and efficiency fans. In addition, fans can run in a cycle (option).

If the Basic Ventilation runs at 100% (the highest amount of air defined) and the temperature continues to rise, Trio switches to Extra or Tunnel Ventilation (if enabled).

In the illustration below, Basic Ventilation is running at 30% (the defined minimum). Maximum ventilation is set to 95%. In addition, the ventilation is running at the minimum and the temperature is low, heating is running at 10%.

- Refer to Defining Basic Ventilation, page 35 for more details.




5.2.2 EXTRA VENTILATION

If enabled, Extra Ventilation acts as a transitional phase. Extra Ventilation operates in situations where:

- Basic Ventilation does not provide enough air to lower the temperature to the Target Temperature
- The temperature is still below the Tunnel Set Point.
- Trio only enters Extra Ventilation if the temperature is 0.5° above the Target Temperature (this is the minimum; you can set the differential to be higher).
- You can set a differential for each level to ensure that ventilation increases only when required.
- Extra Ventilation supports up to 10 levels. As in Basic Ventilation, you define the fans to be used in each level. However, there is no curve between levels.

In the example below, Extra Ventilation is running at Level 15. The minimum for this growth day is Level 3 (30%) and the maximum is Level T1 (first tunnel level).




- Refer to Extra Ventilation, page 55 for more details.

5.2.3 TUNNEL VENTILATION

If enabled, once the temperature reaches the Tunnel Set Point, Trio turns on the tunnel fans and opens the tunnel doors. As in Basic Ventilation, you define the fans to be used in each level. However, there is no curve between levels.

- Even if Extra Ventilation is enabled, Trio will go straight to tunnel mode if the temperature is above the Tunnel Set Point (skipping over Extra Ventilation).
- You can set a differential for each level to ensure that ventilation increases only when required.

In this example, tunnel fans are at level T6.



- Refer to Tunnel Ventilation, page 58 for more details.
- Refer to Defining the Wind Chill Factor, page 63 for details on factoring in the wind chill factor in tunnel mode.

5.2.4 MANUAL FAN OPERATION

Relay-controlled fans can run in manual operation. Manual operation means that the relay toggle switch is set to ON or OFF. The controller software does not change or affect the fan output.

- When a fan is set to ON, the following features are affected:
 - That particular fan runs at 100% capacity. Any other fan in that level runs according to the programming.
 - Fans running in cycle mode: Fans do not close during the Off time.
 - Vents in static pressure mode do not close during cycle Off time.
 - Fan rotation is disabled for all fans.
 - Only fans defined as ON operate.
 - Any fan defined as being in Rotation is disabled.
- When set to OFF, the following features are affected:
 - Insufficient air supply:

- If ventilation is operating in minimum ventilation mode
- One or more fans in the ventilation combination is set to OFF
- Trio generates an “Insufficient Air Supply” Alarm. The alarm remains active until it is reset, even if the fan relay is turned on.
- If all fans are OFF, no “Low Static Pressure Alarm” is generated.
- Vents in static pressure mode or position mode close if there is no fan operating.
- Level transition operates normally. If all fans are set to Off, the temperature determines when the controller transitions to the next level
- Fan rotation is irrelevant for any fan defined as OFF.

6 Minimum and Maximum Ventilation


The following sections detail how to configure the minimum and maximum ventilation levels by growth day. As the temperature rises above the target temperature, Trio gradually increases ventilation level using a combination of increased fan speeds, cycle times, opening the inlets and more.

- Building Structure Summary
- Defining Basic Ventilation

6.1 Building Structure Summary


In a typical setup, flocks are housed in a building in which all rooms are connected to one central ventilation system. Each room has an inlet which controls the amount of air entering. Centralized fans push air in via the inlet.

Outside air is pushed into the attic; the controller maintains the required pressure in the air duct. By adjusting the air inlet, each room independently controls the amount of air entering. As temperature rises, the inlets' opening increases.



6.2 Defining Basic Ventilation

1. Go to System > Control Strategy > Ventilation .



2. Verify that Dynamic Minimum/Maximum and Min Ventilation are disabled.

3. Go to Climate > Min/Max Ventilation.




Day	Minimum	Maximum
1	5 %	55 %
10	15 %	100 %

4. Click .

5. Define:

- Day: Set the growth day for the required min/max set points. Each day must have a unique number. Add up to ten lines.
- Min/Max Level: Define the minimum and maximum ventilation levels. Trio will automatically adjust the ventilation as the temperature changes.

Extra/Tunnel Minimum Ventilation: As option when additional minimum ventilation is required in hot climates, Extra and Tunnel Ventilation can provide minimum ventilation.

6. In System > Control Strategy > Ventilation , enable Extra Ventilation and/or Tunnel (refer to Defining Extra Ventilation, page 56).

7. Go to Climate > Min. Max. Ventilation.

8. Place the cursor in Min Level or Max Level. The Basic/Extra/Tunnel icons appear.

	Day	Minimum	Maximum
	1	5 %	55 %
-	10	15 %	100 %

Basic Extra Tunnel

Range 5 - 100

9. Click the required ventilation icon.
10. Define the ventilation as required.
 - Options:
 - Defining Dynamic Ventilation
 - Ventilation by Weight
 - Adding a Curve

6.2.1 DEFINING DYNAMIC VENTILATION

Dynamic Ventilation means that at extreme temperatures (which the user defines), ventilation can be increased or decreased.

- Dynamic Minimum: The user defines the cold and warm temperatures at which the minimum ventilation takes places. In addition, the user defines the ventilation percentages. To ensure air quality, install air quality sensors (CO₂, Ammonia, Humidity). These sensors will increase ventilation when necessary.
- Dynamic Maximum: The user defines the cold and warm temperatures at which the maximum ventilation takes places. outside temp. In addition, the user defines the ventilation percentages (for cold temperatures) and the ventilation level (for warm temperatures).

1. Go to System > Control Strategy > Ventilation .


Control Strategy → Ventilation

Minimum / Maximum Ventilation

- Curve Status
- Min Ventilation by Weight
- Dynamic Minimum Ventilation
- Dynamic Maximum Ventilation

2. Under Minimum / Maximum Ventilation, enable
 - Dynamic Minimum Ventilation or
 - Dynamic Maximum Ventilation or
 - Both. In this example both are enabled.

3. Go to Climate > Min/Max Ventilation > Settings.



4. Define:

- Dynamic Minimum Cold/Warm Outside Temperature: Define the cold and warm outside temperature points.
- Dynamic Maximum Cold/Warm Temperature: Define the cold and warm outside temperature points .

5. Go to Climate > Min/Max Ventilation.



6. Define:

- Cold Minimum.: When the outside temperature reaches the **Dynamic Minimum Cold Outside Temperature**, Minimum Ventilation runs at this percentage.
- Warm Minimum : When the outside temperature reaches the **Dynamic Minimum Warm Outside Temperature**, Minimum Ventilation runs at this percentage.
- Cold Maximum: When the outside temperature reaches the **Dynamic Maximum Cold Outside Temperature**, Maximum Ventilation runs at this percentage .
- Warm Max. Level: When the outside temperature reaches the **Dynamic Maximum Warm Outside Temperature**, Maximum Ventilation runs at this Extra Ventilation level.

CAUTION When employing Dynamic Minimum, it is important to install air quality sensors to ensure that there is sufficient minimum air. If the air quality decreases, these sensors increase the air flow.

6.2.2 VENTILATION BY WEIGHT

- How Does Ventilation by Weight Work
- Defining the Ventilation By Weight Parameters


6.2.2.1 How Does Ventilation by Weight Work

Ventilation by Weight provides air based on the number of birds in the house, their projected weight, and the outside temperature. After calculating how much air is required based on these factors, Trio determines the required ventilation level to supply the air. Anytime one of the factors changes, Trio recalculates the ventilation (to prevent changing the ventilation too frequently any change must be larger than a user-defined amount).

- When using cycle fans, each level has minimum and maximum on times, which determine the minimum and maximum CFM. If the ventilation doesn't provide enough air for the birds (based on their numbers and weight) Trio sends an alarm. You will need to redefine the minimum level.
- When using variable speed fans, the defined percentages determine the minimum and maximum CFM. However, if a variable fan is set to run in a cycle, the cycle time determines the fan operation, not the user-defined fan speed.

6.2.2.2 Defining the Ventilation By Weight Parameters

1. Go to System > Control Strategy > Ventilation .



2. Under Minimum / Maximum Ventilation, enable Min Ventilation By Weight.

3. Go to Climate > Min/Max Ventilation.

Day	Min. Air/Weight	Maximum
1	0.22 M3/h/Kg	55 %
10	0.1 M3/h/Kg	100 %

4. Click .

5. Define:

- Min Air Weight: The amount of air per bird's weight to be supplied.
- Max: The maximum ventilation level by growth day.

NOTE If you enabled Dynamic Ventilation, click Settings and define the parameters. Refer to Defining Dynamic Ventilation, page 36.

6.2.3 ADDING A CURVE

The following section shows how to configure your fans to increase in a curve between the days defined in the Min Max Ventilation Screen.

1. Go to System > Control Strategy > Ventilation .

Control Strategy → Ventilation

Minimum / Maximum Ventilation

- Curve Status
- Min Ventilation by Weight
- Dynamic Minimum Ventilation
- Dynamic Maximum Ventilation

2. Enable Curve Status. Ventilation now increases in a curve.


7 Levels of Ventilation

- Configuring the Basic Ventilation Settings
- Basic Ventilation
- Extra Ventilation
- Tunnel Ventilation
- Testing the Ventilation System
- Calibrating the Inlet/Tunnel Door
- Stir Fan

7.1 Configuring the Basic Ventilation Settings

➡ Map at least one fan and one inlet before beginning.

1. Go to Climate > Ventilation and click



2. Define:

- **Efficiency Maximum:** Refer to Fans (Efficiency Fan)
- **Ventilation Tuning:** This parameter determines how aggressively the Trio responds to differences between the measured temperature and the target temperature.

CAUTION Munters recommends leaving this parameter at Normal.

- **Min Cycle Off Time (sec.):** Refer to Minimum Ventilation Cycle, page 44.
- **Total Cycle Time (sec.):** Total time in ventilation cycle.

7.2 Basic Ventilation

Basic Level Ventilation defines the amount of air to be supplied at each level of minimum ventilation level. As the temperature increases, minimum ventilation increases the amount of air supplied to maintain the temperature as close to the target temperature as possible

- Fans controlled by relays are on/off. When they are on, they run at maximum speed. Variable fans' speed can be controlled, according to needs.
 - As you configure the levels, make sure that ventilation increases as the levels increase. Trio displays each levels' fan output. When using on/off fans (fans controlled by relays) increasing the number of fans increases the ventilation. When using analog fans, the user defines the fans' maximum output; this output must be taken into account along with the number of fans.
-
- Defining Basic Ventilation
 - Fan Options
 - Inlet and Curtain Ventilation

7.2.1 DEFINING BASIC VENTILATION

In this configuration, Trio raises the minimum ventilation from 10% at Level One to 100% at Level 10.

- In Devices and Sensors map relays and analog output ports to fans, inlets, and stir fans as required. Only mapped devices show up in the following screens. Always define at least one inlet.

1. Go to Climate > Ventilation.



Level CFM	Fans			Inlet
	1	2	3	
0 0				1
1 0				
2 0				
3 0				
4 0				

NOTE At this point, fans do not appear.




2. Click .

3. Click a relay-controlled fan that you want to activate. 1) A box appears around the fan. 2) A fan appears in the upper right.



Level CFM	Fans			Inlet
	1	2	3	1
0				
1				
2				
3				
4				

4. Click the fan in the upper right. Both fans turn blue.



Level CFM	Fans			Inlet
	1	2	3	1
0				
1				
2				
3				
4				

5. Define fans and inlets as required.

Level CFM	Fans			Inlet
	1	2	3	1
0 3,000				 10 %
1 3,000				
2 3,000				
3 3,000				
4 6,000				 20 %

In this example Fan 1 operates according to the levels determined by the temperature and day, beginning at Level 0. The fan will supply up to 10% of the possible ventilation. At Level 4, Fan 2 also begins to operate, supplying up to 40% of the possible ventilation.

Each level shows the maximum possible ventilation capacity. In this example, each fan has a capacity of 3000CFM. At Level 1 this means that the maximum is 3000CFM and at Level 4 6000 CFM.


Details about defining the inlet are given in Inlet and Curtain Ventilation, page 51.

7.2.2 FAN OPTIONS


- Minimum Ventilation Cycle: Fans run in an on/off cycle with user-defined times.
- Analog Fans: Fan speed changes as ventilation requirements change.
- [Efficiency fan](#): Fan runs at a maximum speed percentage defined by the user.
- Fan Rotation: Different fans running in Minimum Ventilation Cycle can be designated to run in rotation.

7.2.2.1 Minimum Ventilation Cycle

1. Go to System > Control Strategy > Ventilation .



2. Enable Fan Cycle – Basic.
3. Go to Climate > Ventilation > Settings.



4. Define:
 - Total Cycle Time (sec): Define the minimum ventilation cycle time. Range: 60 – 999 seconds.
 - Min Cycle Off Time (sec.): When using cycle time, Trio automatically adjusts the ON time set in the main screen. This parameter defines the minimum cycle off time. Range: 0 – 600 seconds.
5. Go to Climate > Ventilation. The (Fan) On time appears on the screen.

Level M3/h	On (sec.)	Fans		
		1	2	3
0 0 5,000 →	0			
1 5,000	0			
2 5,000	0			
3 5,000	0			
4 0	0			

6. To run a fan in cycles:

a. Click

b. Click a fan. The symbol appears.

c. Click . The symbol turns blue .

d. Under On (sec), enter the cycle ON time (Go to the Settings to define the Off time).

Level CFM	On (sec.)	Fans			Inlet
		1	2	3	
0 3,000	0				 10 %
1 3,000	0				
2 3,000	0				
3 3,000	0				
4 4,000 4,200 →	100				 20 %

In this example, at Level 4 Fan 1 runs in cycles (100 seconds on) and Fan 2 runs continuously. The maximum ventilation capacity reflects the change caused by running the fan in a cycle.

7.2.2.2 Analog Fans

1. Click an analog output-controlled fan. 1) A box appears around the fan. 2) A fan appears in the upper right.

The screenshot shows a mobile application interface for 'House 1'. At the top, there's a navigation bar with a back arrow, a menu icon, and status information: 'DAY 0', 'TIME 16:36', and 'House 1'. On the right side of the navigation bar are icons for a globe, a settings icon, a notification bell with a red '4', and a home icon. Below the navigation bar is a blue header labeled 'Ventilation' with 'CANCEL' and 'SAVE' buttons. The main content is a table with the following structure:

Level CFM	Fans			Inlet
	1	2	3	1
0				
1				
2				
3				
4				

To the right of the table is a numeric keypad. At the top of the keypad is a 'Range' label with '0 - 100'. The keypad has buttons for digits 1-9, 0, and a decimal point. A green 'Enter' button is at the bottom left of the keypad, and a backspace icon is at the bottom right.

2. Click on the fan and the Analog Cycle icons.
3. Enter the fan's output.

Level CFM	Fans			Inlet
	1	2	3	1
0 1,700 1,980 →	 35 %			 10 %
1 2,019 2,300 →				
2 2,340 2,640 →				
3 2,680 2,960 →				
4 3,000 3,440 →	 25 %	 25 %		 20 %

At Level0, Fan 1 runs at 35% speed. At Level 4 (40% of the total output), the speed drops to 25% but Fan 2 turns on as well.

CAUTION Make sure that the ventilation CFM increases between levels. If the amount of air drops, increase the fans' percentages or increase the number of fans.

7.2.2.3 Fans (Efficiency Fan)

1. Click an analog output-controlled fan. 1) A box appears around the fan. 2) A fan appears in the upper right.


Level CFM	Fans			Inlet
	1	2	3	1
0	 35			 10
1				
2				
3				
4	 25	 25		 20

Range 0 - 100

1	2	3
4	5	6
7	8	9
-	0	.
Enter		

2. Click the fan in the upper right. Both fans turn blue. A percentage appears under the fan.



3. Click . This icon and the fan icon turn green.

Level CFM	Fans			Inlet
	1	2	3	1
0	35			10
1				
2				
3				
4	25	25	0	20

4. In the percentage, enter the fan's minimum speed (in percentage).

5. Go to Settings.

Ventilation → Settings

Efficiency Maximum Speed (Green Fan) 60 %



Basic

Ventilation Tuning Normal (Recommended)

Total Cycle Time (sec.) 300

Min Cycle OFF Time (sec.) 60

6. In Efficiency Maximum Speed, enter the fan's maximum speed (in percentage).

House 1				
Ventilation				
Level CFM	Fans			Inlet
	1	2	3	1
0 1,700 → 1,980	 35 %			 10 %
1 2,019 → 2,300				
2 2,340 → 2,640				
3 2,680 → 2,960				
4 4,900 → 5,420	 25 %	 25 %	 45 %	 20 %


7. In this example Fan 1 and Fan 2 are standard analog fans, and Fan 3 is an efficiency fan whose minimum speed is 45% and maximum speed is 60% of the fan's possible speed. The ventilation capacity reflects the efficiency fan's capacity.

7.2.2.4 Fan Rotation

Using the same fan or a limited number of fans exclusively can lead to mechanical wear and tear, for example to the drive belt. To minimize this damage, Trio enables "rotating" between fans. Fan Rotation is used mainly in the lower ventilation levels. The rotation function switches between cycle fans in the same stage.

To enable fan rotation:


1. Go to System > Control Strategy > Ventilation  .



2. Enable Fan Cycle Basic and Fan Rotation (Fan Rotation does not appear unless Fan Cycle is enabled.)

3. Go to Climate > Ventilation.



4. After enabling fans, click on any fan that you want to rotate.  appears.

5. Click the icon. Repeat for any required fans.

Level CFM	On (sec.)	Fans			Inlet
		1	2	3	1
0 1,000 → 1,630	100				 10%
1 1,700 → 2,330	0				
2 4,200 → 4,330	120				

In the above example, at level 0 Fan 1 rotates with Fan 2. At level 2, Fans 1 and 2 rotate while Fan 3 remains constant.

7.2.3 INLET AND CURTAIN VENTILATION

In Basic Ventilation, Trio enables control over the inlets using one of three methods:

- Level Control
- Static Pressure Control
- Manual Inlet/Tunnel Door Operation

NOTE Outlet control is by level only.

To select the inlet control method:

1. Go to System > Control Strategy > Ventilation

The screenshot shows the 'Control Strategy -> Ventilation' settings page. At the top, there are navigation icons and a notification badge with the number '4'. The main content area is divided into sections: 'Enable Fan Cycle' with radio buttons for 'Basic' (selected), 'Extra', and 'Tunnel'; 'Fan Rotation' with a blue toggle switch turned on; 'Inlets' with 'Inlets Position' set to 'By Level', 'Inlets Auto Calibration' with a grey toggle switch turned off, and 'Power Up Calibration (By Opening)' with a grey toggle switch turned off; and 'Tunnel Doors' at the bottom.


2. Under Inlet Operation Mode, select Level or Pressure.

7.2.3.1 Level Control

1. Go to Climate > Ventilation.



2. Click .



3. Click on a required inlet/outlet and enable it by clicking on the fan symbol that appears.

4. Define the opening level.

5. Repeat for every required fan at each level.

NOTE Munters recommends configuring the inlets for every ventilation level.

NOTE Inlets open before the fans being to operate, preventing excess pressure.

Level M3/h	Inlet		Outlet
	1	2	1
0 0	15 %		
1 0	20 %		
2 0	10 %	10 %	5 %

7.2.3.2 Static Pressure Control

When set to pressure control, the static pressure (the difference between the interior and exterior air pressures) controls the inlets opening and closing (the opening position is determined in the Inlet & Curtain Levels screen). Maintaining the proper pressure enables air to enter the rooms at the right speed and direction and ensures efficient air exchange. Note that the Trio adjusts the inlets' opening only if one or more fan is operating.


Set the required pressure, according to the air flow specification. The greater the difference between the exterior and interior pressures, the greater the air flow.

- Static Pressure in Minimum Ventilation or Extra Ventilation
- Static Pressure Main Screen
- Static Pressure Settings Screen
- High Static Pressure Alarm State

7.2.3.2.1 Static Pressure in Minimum Ventilation or Extra Ventilation

In minimum/extra ventilation the target pressure is adjusted as a function of the outside temperature. Trio calculates the pressure target according to a curve between low and high temperature target pressure set points.


NOTE Static pressure ventilation does not operate in tunnel mode.



The curve is adjusted according to the outside temperature, in order to maintain the pressure. If the outside temperature is warm, large amounts of slow moving air is allowed to enter the house (low static pressure). When the outside air is cold, the Vent Master adjusts the inlets to allow a low volume of fast-moving cold air (high static pressure).

7.2.3.2.2 Static Pressure Main Screen

1. Go to Climate > Static Pressure.




2. Define:

- **Band:** The static pressure level below or above which the controller must close or open the inlets to minimize or maximize the ventilation. Range: 0.00 – 0.080 INWC.
- **Pressure Targets:** Set the required pressure level for the cold and warm outside temperatures. Range: 0.080 – 0.401 INWC.
- **Outside Temperatures:** Set the temperatures at which the inlets open or close. (This parameter requires an outside temperature sensor). Range: -40.0 to +59.0° F.
- **Pressure Alarm:** Set the low and high pressures, at which an alarm is transmitted. Range: 0.000 – 0.161 INWC
- **Emergency Pressure State:** If the air pressure reaches a level such that a high pressure alarm is generated, Trio goes into an Emergency Pressure state:
 - Any vent that is not fully open, opens an additional 10%.
 - Trio remeasures the pressure. If the air pressure is still too high, vents open an additional 10%. This process continues until pressure meets the specification.
 - If the vents are open fully (100% open), other ventilation devices open by 10%.
 - **Note:**
 - Ventilation continues according to the climate conditions.
 - Vents do not close.
 - If the vent cycle time is off, they do not open.
 - Auto calibration is disabled.

- The alarm must be reset, an event generated, and the pressure lowered to cancel the condition.

7.2.3.2.3 Static Pressure Settings Screen



- Define:
 - Wind delay: When pressure rises above or drops below the required level, Trio waits this amount of time before adjusting the inlet openings. Range: 0 – 999 seconds
 - Low Pressure Alarm Minimum Level: Low static pressure alarm is disabled when the minimum ventilation drops below this level. Range 1 – 10.

7.2.3.2.4 High Static Pressure Alarm State

If the static pressure is above the target level, inlets continue to open until they reach the maximum position. In the situation where static pressure is above the target and all inlets are open, Trio enters a High Static Pressure Alarm state. In this situation:

- Trio triggers a High Pressure Compensation event that is recorded.
- Other inlets are opened by 10%. This step is repeated if the pressure does not go down.
- The high static pressure alarms continue until the user resets the alarm, even if the static pressure falls below the alarm set point. The user must reset the alarm; acknowledging the alarm or rebooting the unit does not stop the alarm.

7.2.3.3 Manual Inlet/Tunnel Door Operation

- When an inlet or a tunnel door is running in manual mode, the programming does not determine the inlet's/door's position.
- In situations where Trio is running in Ventilation by Weight (page 38) but cannot supply sufficient air per bird, Trio generates an "Insufficient Air Supply" alarm.

7.3 Extra Ventilation

Enable this option to provide extended layout to set the power/transitional ventilation levels.).


- ➡ Extra Ventilation must be enabled for the functions to appear on the screen.
- ➡ Configuring Extra Ventilation requires mapping at least one fan, one inlet, or one tunnel door
 - Introduction to Extra Ventilation
 - Defining Extra Ventilation


7.3.1 INTRODUCTION TO EXTRA VENTILATION

Extra ventilation is an option used to increase ventilation when:

- Minimum ventilation runs at 100%
- Temperature has not reached tunnel target temperature.
- The room temperature is at least 0.5° C above the target temperature. However you can define a higher differential.


7.3.2 DEFINING EXTRA VENTILATION

1. Go to System > Control Strategy > Ventilation .
2. Under Ventilation, enable Extra Level.



3. Go to Climate > Ventilation and click the Extra Ventilation Tab.

4. Click .



5. On each level, define:
 - Level: Read-only.


- Diff: Define the temperature differential. When the temperature rises above the target temperature by this amount at each level, Extra Ventilation begins. Range: 0.0°C >10.0°C.

NOTE Each differential must be equal to or higher than the previous level's differential.

- Fan Status. Refer to Defining Basic Ventilation, page 41 on how to configure fans.


Extra Ventilation Fan Cycle (Optional):

6. Go to System > Control Strategy > Ventilation .



7. Under Enable Fan Cycle, check Extra.

8. Go to Climate > Ventilation > Extra Ventilation.




9. Define the cycle times. Refer to Minimum Ventilation Cycle, page 44 for details.


7.4 Tunnel Ventilation

When enabled, you can:


- Set tunnel levels in the ventilation program.
- Define tunnel set points in the ventilation program.
- Define Pressure settings for tunnel.
- Define Tunnel temperature set point in the temperature curve (refer to Configuring the Temperature Curve, page 25).
- ➔ One tunnel door must be mapped or tunnel ventilation will not operate.
- ➔ Configuring Tunnel Ventilation requires mapping at least one fan or one tunnel door.
- ➔ Tunnel Ventilation must be enabled for the functions to appear on the screen.
- Defining the Tunnel Ventilation Parameters
- Defining the Tunnel Ventilation Settings
- Tunnel Doors
- Defining the Wind Chill Factor
- Tunnel Ventilation Static Pressure

7.4.1 DEFINING THE TUNNEL VENTILATION PARAMETERS

1. Go to System > Control Strategy > Ventilation .
2. Under Ventilation:
 - a. Enable Tunnel Ventilation.



- b. Select the tunnel operation mode (refer to Inlet and Curtain Ventilation, page 51 for details on this parameter).



3. Go to Climate > Temperature Curve.

Temperature Curve

Day	Target	Heat	Cool	Tunnel	Low T° Alarm	High T° Alarm
0	80.1 °F	78 °F	90 °F	90 °F	70 °F	90 °F
5	82 °F	78 °F	82 °F	82 °F	70 °F	90 °F
10	82.5 °F	79 °F	82.5 °F	82.5 °F	69 °F	91 °F

Current Target: 81.9 °F

4. For each day, define the Tunnel temperature. This parameter defines the temperature at which Tunnel Mode begins to operate.

5. Go to Climate > Ventilation and click the Tunnel Tab.

Ventilation

Basic Tunnel

Level CFM	Diff	Fans				Tunnel				
		1	2	3	4	1	2	3	4	
T1 ₀	0 °F									
T2 ₀	2 °F									

25%
30%

6. On each level, define:


- Level: Read-only.
- Diff: Define the temperature differential. This factor defines the wind chill factor. Trio switches to the higher level when the temperature reaches the tunnel temperature plus the differential. Range: 0.0°C >10.0°C.


NOTE The Diff parameter manually defines the wind chill factor for each level. To automatically define the wind chill factor, refer to Defining the Wind Chill Factor, page 63.

- Each differential must be equal to or higher than the previous level's differential.
- At T1, the differential is predefined as 0.0.
- Fan Status. Refer to Defining Basic Ventilation, page 41 on how to configure fans.
- Tunnel Doors: Refer to Tunnel Doors, page 62. (Inlets close during tunnel mode.)

NOTE To prevent overcooling, when defining the fans in the first tunnel level, the total amount of air should be the same or slightly lower than the last Minimum Ventilation or Extra Ventilation level.

Tunnel Ventilation Fan Cycle (Optional):

7. Go to System > Control Strategy > Ventilation .



8. Under Enable Fan Cycle, check Tunnel.

9. Go to Climate > Ventilation > Tunnel.

Level CFM	Diff	On (sec.)	Fans				Tunnel				
			1	2	3	4	1	2	3	4	
T1 ₀	0 °F	60						25%			
T2 ₀	2 °F	100						30%			

10. Define the cycle times. Refer to Minimum Ventilation Cycle, page 44 for details.

7.4.2 DEFINING THE TUNNEL VENTILATION SETTINGS

Efficiency Maximum Speed (Green Fan) 70 %

Basic

Ventilation Tuning Normal (Recommended)

Tunnel

Ventilation Tuning Normal (Recommended)

Total Cycle Time (sec.) 300

Tunnel Exit Hysteresis 2 °F

Outside Temp Exit Limit 0 °F

Tunnel Exit Delay (min.) 5

- Define:
 - **Ventilation Tuning:** This parameter determines how aggressively the Trio responds to differences between the measured temperature and the target temperature.

CAUTION *Munters recommends leaving this parameter at Normal.*

- **Total Cycle Time:** When the tunnel is working in cycle mode, the total cycle is defined here. Range: 60 – 999 seconds
- **Tunnel Exit Hysteresis:** This is a differential. When the temperature reaches the tunnel temperature minus this differential, ventilation goes down to Extra Ventilation (if enabled) or Minimum Ventilation. Range: 0.0 – 17.9°

- Outside Temp Exit Limit: This is a differential. When the outside temperature reaches the tunnel temperature plus this differential, ventilation will remain in Tunnel Mode, regardless of the inside temperature. Range: 0.0 – 17.9°
- Tunnel Exit Delay (min.): When Trio calculates that ventilation should exit Tunnel Mode, there is a delay (of this amount of time) before actually exiting. This parameter prevents Trio from entering and exiting Tunnel Mode too rapidly.

7.4.3 TUNNEL DOORS

- Tunnel Ventilation
- Basic Ventilation

7.4.3.1 Tunnel Ventilation


In Tunnel Ventilation, Trio enables control over the tunnel doors using control by level or control by static pressure. Control of these doors is the same as control over inlets. Refer to Inlet and Curtain Ventilation for details.

Level CFM	Diff	On (sec.)	Fans				Tunnel				
			1	2	3	4	1	2	3	4	
T1 ₀	0 °F	60						25%			
T2 ₀	2 °F	100						30%			

7.4.3.2 Basic Ventilation

In Version 8.5, Trio enables operating the tunnel doors (curtains) in Basic Ventilation. This function provides extra sources of ventilation in hotter climates.

1. Go to System > Control Strategy > Ventilation.
2. Enable Tunnel Door in Basic Mode.



7.4.4 DEFINING THE WIND CHILL FACTOR


Trio can take into account the tunnel wind speed. The effect of this speed is the wind chill factor. When taken into account, the ventilation is adjusted to reflect the effective temperature according to a built-in algorithm. The algorithm takes into account the wind velocity, house dimensions, and growth day. If there is a humidity sensor installed, the algorithm also factors the relative humidity into the calculation (starting from 40% RH). Factoring in the RH lowers the calculated wind chill factor.

- Wind chill is activated in tunnel mode only.
- Wind chill calculations take place between days 10 – 50.

➡ Define the fan capacity (refer to the Installation Manual).

Define the house dimensions (refer to Defining the House Setting, page 15).

1. Go to System > Control Strategy > Ventilation. Scroll down to Wind Chill.




New picture

2. Define:

- Enable wind chill real time control: Enable this function. The level target is defined as the tunnel set point plus the wind chill factor.
- Max. Effect Temperature: Define the maximum temperature adjustment.

NOTE When Wind Chill factor is enabled, Trio automatically calculates the Tunnel ventilation differential.



7.4.5 TUNNEL VENTILATION STATIC PRESSURE

If you selected By Pressure to determine the tunnel opening, define the static pressure settings.

1. Go to Climate > Static Pressure.

The screenshot displays the 'Static Pressure' configuration screen for 'House 1'. The top navigation bar shows the day as '5' and the time as '10:48'. The interface is divided into two main sections: 'Basic / Extra Ventilation' and 'Tunnel Ventilation'. The 'Basic / Extra Ventilation' section contains a table with the following data:

Band	0.02 INWC		
Pressure Target	Cold	0.1 INWC	→ Warm 0.08 INWC
Outside Temperature	Cold	14 °F	→ Warm 59 °F
Pressure Alarm	Low	0.012 INWC	→ High 0.161 INWC

The 'Tunnel Ventilation' section contains a table with the following data:

Target	0.08 INWC		
Band	0.02 INWC		
Pressure Alarm	Low	0.02 INWC	→ High 0.161 INWC

2. Define:

- Target: Define the required pressure level when using tunnel ventilation.
- Band: The static pressure level below or above which the controller must close or open the inlets to minimize or maximize the ventilation. Range:
- Pressure Alarm: Set the low and high pressures, at which an alarm is transmitted. Range:

7.5 Testing the Ventilation System

After configuring the fans and ventilation definitions, it is important to test the system to verify that ventilation flows as required (for example by employing a smoke machine). In addition, if there is any problem in the ventilation system, this test can help identify the problem.

Testing can be performed in Basic Mode. From Version 8.3, testing is also available in Extra and Tunnel Modes.

Testing checks:


- Air speed
- Airflow patterns (exhaust through the inlets)
- Testing room differential pressure (setting the right position for the inlets/outlets/tunnel doors).
- Filter/cooling pad performance
- Fan performance (mechanical drop)

To test the system:


1. Configure your ventilation system as required.

Level M3/h	Fans						Inlet	Outlet	Stir Fan
	1	2	3	4	5	6			
0 10,000							 15 %	 15 %	
1 20,000							 20 %		
2 30,000							 20 %		
3									


2. Click the three dots and select Testing.



3. Confirm the test start. Note that automatic ventilation control ceases to operate during a test.






4. Testing begins at Level 0. Begin increasing the output. When the output increases to 10%, the ventilation level should rise to Level 1. When the output increases to 20%, the ventilation level should rise to Level 2.



5. Ensure that all systems are operating properly.

- Press **Stop Testing** to cease the test. If there is no user input for five minutes, testing stops automatically.
- If Extra Ventilation is enabled, testing automatically switches to Extra Ventilation when Minimum Ventilation passes 100%. The same process happens if Tunnel Ventilation is enabled.



7.6 Calibrating the Inlet/Tunnel Door

To ensure that air circulation is carried out in the most efficient manner and according to the specifications, inlets must be positioned (opened) accurately. If used a potentiometer can control the opening and closing with a high degree of precision.


However when there is no potentiometer, positioning accuracy tends to degrade after the inlets go through several opening and closing cycles. The following section describes how to recalibrate the inlets and tunnel doors without a potentiometer.

During installation, the user enables auto-calibration in digital output inlets. Calibration automatically takes place after the number of inlet movements equals the number of movements required to start calibration.

Only one inlet or tunnel curtain can be calibrated at a time.

- Relay open occurs when the target position is 100%.
- Relay close occurs when the target position is 0%.

1. Go to System > Control Strategy > Ventilation  ..



2. Click .

3. Define:

- (Option): Enable Inlets/Tunnel Door Auto Calibration. If this is enabled, the following parameters appear. Define:
 - 24 hours a day or a specific time frame.
 - Number of Movements: Define the number of movements (meaning when the opening changes from idle to open or to close) after which the inlets or tunnel door auto calibrates. The movement can be automatic or manual. Range: 5 – 99. Default: 99
- Power Up Calibration (By Opening): Upon power up, the inlets or tunnel door are opened completely.

7.7 Stir Fan

Stir fans mix the air within the rooms. Because warm air rises and cool air falls, there can be a difference of several degrees in the temperature between the floor and the ceiling. By circulating the air, heating costs can be reduced while the environmental conditions are improved.


Stir fans can work continuously or in cycles.

- How do Stir Fans and Exhaust Fans Work Together?
- Defining the Stir Fan Functionality

7.7.1 HOW DO STIR FANS AND EXHAUST FANS WORK TOGETHER?

There are several rules guiding stir fan operation.

- An exhaust fan must be defined at the same level as a stir fan. The stir fan will not operate without an exhaust fan.



Level M3/h	Fans			Inlet	Stir Fan
	1	2	3		
0 5,000				 15%	

Figure 2: Valid Stir Fan – Exhaust Fan Configuration



Level M3/h	Fans			Inlet	Stir Fan
	1	2	3		
0 10,000 →				 15%	

Figure 3: Invalid Stir Fan – Exhaust Fan Configuration

- As the level of ventilation rises, the stir fan operates until there is a change in the exhaust fan configuration. At that point, the stir fan must be redefined or it will stop operating. In Figure 4, The stir fan operates at Level 0 and Level 1. At Level 2, when the exhaust fan configuration changes, the stir fan stops operating. Figure 5 illustrates how to define the stir fan to ensure continuous operation.

House 1					
Ventilation					
Level M3/h	Fans			Inlet	Stir Fan
	1	2	3	1	1
0 5,000				 15 %	
1 5,000				 20 %	
2 10,000				 25 %	

Figure 4: Change in Exhaust Fan – Stir Fan Stops Working

House 1					
Ventilation					
Level M3/h	Fans			Inlet	Stir Fan
	1	2	3	1	1
0 5,000				 15 %	
1 5,000				 20 %	
2 10,000				 25 %	

Figure 5: Change in Exhaust Fan – Stir Fan Continues Working

- Variable speed stir fans continue working at the same level until a new level is defined; there is no ramping. In Figure 6 the stir fan works at 25% from Level 0 to Level 2. At Level 3, it rises to 50%.

Level M3/h	Fans			Inlet	Stir Fan
	1	2	3	1	1
0 5,000				 15 %	 25 %
1 5,000				 20 %	
2 10,000				 25 %	
3 0				 25 %	 50 %

Figure 6: Variable Stir Fan Speed

- If the stir fans operate in a cycle, they can synchronize their on-time with exhaust fans that operate in a cycle (refer to [Cycle Time Option](#)). If the exhaust fans work continuously, the stir fans operating in a cycle work independently of the exhaust fans.



7.7.2 DEFINING THE STIR FAN FUNCTIONALITY

To define the stir fan functionality:

1. Define up to two relays or analog ports as a stir fan (refer to the Installation Manual).
2. Define the stir fan parameters (refer to the Installation Manual).
3. Go to Climate > Ventilation, enable the fan(s) and define the fan(s) parameters.

Level CFM	Stir Fan	
	1	2
0 0	 25 %	
1 0		

4. **Cycle Time Option:** If ventilation runs in cycle, define the stir fan cycle time (refer to Minimum Ventilation Cycle, page 44 for details).
 - a. Define the On Time.

House 1			
Ventilation			
Level CFM	On (sec.)	Stir Fan	
		1	2
0 0	100	 25 %	
1 0	0		

b. Go to Climate > Ventilations > Settings and define the cycle times.

House 1	
Ventilation → Settings	
Efficiency Maximum Speed (Green Fan)	70 %
Basic	
Ventilation Tuning	Normal (Recommended)
Total Cycle Time (sec.)	300
Min Cycle OFF Time (sec.)	60
Stir Fan	
Cycle Stir Fan Operate During	OFF Time

c. Define when the stir fan operates, during the exhaust fans' cycle On or Off time.

DAY 106 TIME 16:18 House 1

Ventilation → Settings CANCEL SAVE

Efficiency Maximum Speed (Green Fan) 70 %

Basic

Ventilation Tuning Normal (Recommended) ▾

Total Cycle Time (sec.) 300

Min Cycle OFF Time (sec.) 60

Stir Fan

Cycle Stir Fan Operate During OFF Time ▾
ON Time
OFF Time

Range

1	2	3
4	5	6
7	8	9
-	0	.
Enter		<

8 Cooling

- Cooling Pads
- Foggers

8.1 Cooling Pads

- Cooling Principles
- Selecting the Cooling Mode

8.1.1 COOLING PRINCIPLES


Trio supports controlling up to four cooling devices (foggers or cooling pads). The devices can run separately or together.

The relative humidity directly affects the ability of birds to cool down, even when the temperature is the same (heat loss decreases in higher humidity rate causing heat stress). What is important to remember is that the cooling process adds moisture to the air; therefore it needs to stop when the relative humidity is too high.

- To enable limiting cooling according to the humidity, install a humidity sensor.
- Invalid humidity sensor readings are not taken into consideration.

To avoid causing the animals undo heat stress during periods of high relative humidity, Trio employs the following rules:

- When the temperature reaches the Cooling Temperature in the Temperature Curve, cooling begins and continues until the temperature falls below this point. The Cooling Temperature must be higher than the Target Temperature.



Day	Target	Heat	Cool	Low T° Alarm	High T° Alarm	Current Target
0	80.1 °F	78 °F	90 °F	70 °F	90 °F	82 °F
5	82 °F	78 °F	82 °F	70 °F	90 °F	
10	82.5 °F	79 °F	82.5 °F	69 °F	91 °F	

- If the humidity level rises above the To Humidity parameter (plus the Humidity Band), cooling ceases.
- Cooling only takes place between the start and finish times.
- When the minimum OFF time = 0sec, and the temperature reached ON temp + Ramping range the cooling device operates continuously.

- While cycling, the minimum OFF time will never be less than 5 seconds.
- Cooling runs in all ventilation modes.
- To record the amount of water used during cooling: install, map, and define a water meter (refer to the Installation Manual).


8.1.2 SELECTING THE COOLING MODE

Trio enables running the cooling device in three different modes:

- Ramping: Cycle modulation, frequency depends on the error in °C, with respect to the cooling setting (target). Ramping is the default mode.
- Continuous: When activated, the cooling devices operate continuously.
- Cycle: When activated, the cooling device operates according to user-defined an on/off cycle.

➡ Go to System > Devices and Sensors and set the relays as cooling (refer to the Installation Manual).

1. Go to Climate > Cooling.> Cooling Pad  > Settings.




2. Define:

- The operation mode.
- Humidity to Stop: Define the humidity level at which cooling stops.
- Humidity Band: Set the humidity band to re-enable cooling outputs after the process ceases because of the high humidity level.
- Filling Time: Define the amount of time required to distribute water over the pad.
- Cooling Enabled: Define when cooling is enabled, 24 hours a day or time frames.


3. Go to Climate > Cooling > Cooling Pad . The screen that appears depends on the mode of operation chosen.

- Continuous Cooling
- Cycle Cooling
- Ramping Cooling
- If you want cooling pads to operate only in Tunnel mode, 1) enable Tunnel Mode 2) set up the Temperature Curve so that Tunnel Target Temperature is below the Cooling Temperature.



Day	Target	Heat	Cool	Tunnel	Low T° Alarm	High T° Alarm	Current Target
0	75 °F	72.9 °F	80 °F	79 °F	65 °F	85 °F	72 °F
5	74 °F	70 °F	81 °F	80 °F	65 °F	85 °F	
10	73 °F	69.5 °F	83 °F	82 °F	65 °F	85 °F	
14	72 °F	63 °F	84 °F	83 °F	65 °F	85 °F	

- Each cooling pad can be mapped to its own temperature sensor(s) or can operate according to the average temperature (System > Temperature Definition).



Device	Avg.	Temperature Sensors					
Full House		1	2	3	4	5	6
Cooling Pad 1		1					
Cooling Pad 2			2				
Cooling Pad 3					4	5	
Cooling Pad 4	✓						

8.1.2.1 Continuous Cooling

	Day 1	Day 4	Day 10	Day 16	Day 21	Day 26
	Pad 1	Pad 2	Pad 3	Pad 4		
Pad Control	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
Enable From Ventilation Level	10 %	10 %	10 %	10 %		
Start Temperature (Diff. From Cool Temp.)	0 °F	0 °F	0 °F	0 °F		
Stop Temperature (Diff. From Cool Temp.)	-0.4 °F	-0.4 °F	-0.4 °F	-0.4 °F		
Stop above this Humidity	85	85	85	85		

Current Target: 90 °F

Related Pages >

- Define:
 - Growth days at which the settings change. Define up to 15 days. The cooling pads run at their current levels until the next defined day.
 - Pad Control: Enable or disable a cooling pad.
 - Enable from Ventilation Level: Select the level (ventilation output) to enable cooling operation. (Default 1).
 - Start Temperature (Diff from Cool Temp.): Sets the temperature differential from the cooling temperature (Temperature Curve) to activate cooling. The calculated temperature to start cooling is adjusted according to the growth-days. Range: -17.6 to +18.0° F. Default: 0.0
 - Stop Temperature ((Diff from Cool Temp.): Sets the temperature differential from the cooling temperature (Temperature Curve) to stop the cooling pad. Range: -18.0 to -0.4° F. Default: -0.4° F
 - Stop cooling pad temperature = Cooling Target ± Stop temperature
 - Stop above this Humidity: Stop cooling when the humidity level reaches the level defined in this parameter. Define the level for each individual cooling pad.
 - An indoor humidity sensor must be installed for this parameter to appear.

8.1.2.2 Cycle Cooling

	Pad 1	Pad 2	Pad 3	Pad 4
Pad Control	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Enable From Ventilation Level	10 %	10 %	10 %	10 %
Start Temperature (Diff. From Cool Temp.)	0 °F	0 °F	0 °F	0 °F
Stop Temperature (Diff. From Cool Temp.)	-0.4 °F	-0.4 °F	-0.4 °F	-0.4 °F
ON Time (Sec.)	30	30	30	30
OFF Time (Sec.)	30	30	30	30
Stop above this Humidity	85	85	85	85

- Define:
 - Growth days at which the settings change. Define up to 15 days. The cooling pads run at their current levels until the next defined day.
 - Pad Control: Enable or disable a cooling device.
 - Enable From Ventilation Level: Select the level (ventilation output) to enable cooling operation. (Default 1).
 - Start Temperature (Diff from Cool Temp.): Sets the temperature differential from the cooling temperature (Temperature Curve) to activate cooling. The calculated temperature to start cooling is adjusted according to the growth-days. Range: -17.6 to +18.0° F. Default: 0.0
 - Stop Temperature ((Diff from Cool Temp.): Sets the temperature differential from the cooling temperature (Temperature Curve) to stop cooling device. Range: -18.0 to -0.4° F. Default: -0.4° F
 - Stop cooling device temperature = Cooling Target - Stop temperature
 - ON/OFF Time: Define the amount of time the cycle is ON and OFF, respectively.
 - Stop above this Humidity: Stop cooling when the humidity level reaches the level defined in the Humidity settings. Define the level for each individual pad.
 - An indoor humidity sensor must be installed for this parameter to appear.

8.1.2.3 Ramping Cooling

	Day 1	Day 4	Day 10	Day 16	Day 21	Day 26
	Pad 1	Pad 2	Pad 3	Pad 4		
Pad Control	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
Enable From Ventilation Level	10 %	10 %	10 %	10 %		
Start Temperature (Diff. From Cool Temp.)	0 °F	0 °F	0 °F	0 °F		
Stop Temperature (Diff. From Cool Temp.)	-0.4 °F	-0.4 °F	-0.4 °F	-0.4 °F		
ON Time (Sec.)	30	30	30	30		
Minimum Off Time (Sec.)	20	20	20	20		
Maximum Off Time (Sec.)	280	280	280	280		
Ramping Temperature Range (Sec.)	9 °F	9 °F	9 °F	9 °F		
Stop above this Humidity	85	85	85	85		

Current Target: 90 °F

Related Pages >

- Define:
 - Growth days at which the settings change. Define up to 15 days. The cooling pads run at their current levels until the next defined day.
 - Pad Control: Enable or disable a cooling device.
 - Enable from Ventilation Level: Select the level (ventilation output) to enable cooling operation. (Default 1).
 - Start Temperature (Diff from Cool Temp.): Sets the temperature differential from the cooling temperature (Temperature Curve) to activate cooling. The calculated temperature to start cooling is adjusted according to the growth-days. Range: -17.6 to +18.0° F. Default: 0.0
 - Stop Temperature ((Diff from Cool Temp.): Sets the temperature differential from the cooling temperature (Temperature Curve) to stop cooling device. Range: -18.0 to -0.4° F. Default: -0.4° F
 - Stop cooling device temperature = Cooling Target ± Stop temperature
 - ON Time: Describe the amount of time the cycle is ON. This number is a constant and does not change. Range 5 – 999. Default: 30
 - Maximum/Minimum OFF Time (Sec): Define the maximum and minimum off time that cooling devices remain off after having operated during the ON time. Range 5 – 999. Default: 280

- Ramping Temperature Range: Sets a temperature range to modulate the cooling device off cycle. When cooling starts, the off time will be the maximum off time. As the temperature rises to the band maximum, the maximum off time decreases to the minimum. Range: 0.0 to +17.9° F. Default: 9.0° F
- Stop above this Humidity: Stop cooling when the humidity level reaches the level defined in the Humidity settings. Define the level for each individual pad.
 - An indoor humidity sensor must be installed for this parameter to appear.

8.2 Foggers

Foggers shoot a mist of water into the air to lower the temperature. Foggers are most effective when the humidity is below 60%.

- Foggers operate according to the house temperature, humidity, and bird age.
- A fogger can be mapped to a particular temperature sensor or be controlled by the average temperature.
- The amount of water sprayed should increase as the birds age.
- Foggers run in cycles, with the user defining the on and off times.

To configure the foggers:


➡ Map at least one fogger in Devices and Sensors (refer to the Installation Manual).

1. Go to System > Temperature Definition.

Device	Avg.	Temperature Sensors					
Full House		1	2	3	4	5	6
Cooling Pad 3					4	5	
Cooling Pad 4		1	2				
Fogger 1	✓						
Fogger 2				3			
Fogger 3						5	
Fogger 4				3	4		

2. Map the fogger(s) to specific temperature sensors or to the average temperature.

3. Go to Climate > Cooling > Foggers .




4. Define:

- Growth days at which the settings change. Define up to four days. The foggers run at their current levels until the next defined day.
- Fogger Control: Enable or disable the foggers (all foggers are enabled or disabled simultaneously).
- From/To Ventilation Level: Define the minimum and maximum ventilation levels. If Extra or Tunnel Ventilation are enabled, the maximum level can be within these modes. Minimum level is always in Basic ventilation. Default: 10%/100%.
- Time of Day: Set the time frame during which fogger operation is possible (24H or time frames). Default: 24 hours.
- Start Temperature (Diff. From Cool Temp.): Define the temperature differential above the cooling temperature (Temperature Curve) above which the fogger starts to operate. Default: 0° F. Range: 0° - 18° F.
- Stop Temperature (Diff. From Cool Temp.): Define the temperature differential above the cooling temperature (Temperature Curve) below which the fogger ceases to operate. Default: -0.4° F. Range: -18° to -0.4° F.
- Off Time (Sec.): Define the time between fogging cycles. Default: 300 seconds. Range: 1 - 3600 seconds.
- Minimum On Time: Once the temperature rises above the Start Temperature, the fogger operates for at least this amount of time. Default: 60 seconds. Range: 1 - 3600 seconds.

- Maximum On Time: Once the fogger begins to operate, at a maximum the fogger operates for this amount of time. Trio automatically adjusts the actual on time based on the Ramping Temperature Range.
- Ramping Temperature Range (Sec.): If the temperature rises, Trio adjusts the Maximum On Time based on this parameter. Default: 9° F. Range: 0° - 17.9° F
- Stop above this Humidity: Stop fogging when the humidity level reaches this level. Default: 85%. Range: 0 - 100. .
 - This parameter requires that a humidity sensor be installed. If the humidity sensor readings are invalid, this limit is disabled.
 - Based on this parameter, Trio prevents the foggers from starting an on cycle. Trio does not stop fogging midway through a cycle.

5. Go to Climate > Cooling > Foggers > Settings.



6. Define:


Humidity Resume Band: Before fogging can resume, the humidity must decrease from the [Stop Level] - [Resume Band]. For example, if the Stop Level is 80% and the resume band is 10%, fogging will not resume until the humidity drops to 70%. Default: 5%. Range: 2- 10%.

9 Heating Functions

- Heating Functions
- Toggle Switch Options
- Second Stage Heating
- Central Heaters
- Zone Heaters
- Heating Options

9.1 Heating Functions

When the temperature reaches the Heat Temperature in the Temperature Curve, heating begins and continues until the temperature rises to this point. The Heating Temperature must be lower than the Target Temperature.



Day	Target	Heat	Cool	Low T° Alarm	High T° Alarm	Current Target
0	80.1 °F	78 °F	90 °F	70 °F	90 °F	82 °F
5	82 °F	78 °F	82 °F	70 °F	90 °F	
10	82.5 °F	79 °F	82.5 °F	69 °F	91 °F	

TRIO supports up to:

- 16 on/off heating devices and variable heaters
- 16 high heaters (relay controlled only)

To control the heat, TRIO has two different programs, one to maintain the target temperature in the entire house ([Central Heating](#)) and one program that controls separate heating zones ([Zoned Heating](#)). In the case of the latter, each heater has a dedicated sensor and unique target temperature.

TRIO supports on/off and [0-10V analog heaters](#). In addition, heaters can [run in cycles](#).

9.2 Toggle Switch Options

- Automatic Operation
- Manual Operation

9.2.1 AUTOMATIC OPERATION

When a heater toggle switch is set to Automatic, heating works according to the parameter defined in the heating functions. The heaters operate according to the heating set points, the heating bands, cycle times, tuning and other parameters (functions detailed in the following sections).

9.2.2 MANUAL OPERATION

Relay-controlled heaters can run in manual operation. Manual operation means that the relay toggle switch is set to ON. When set to On, heating output is 100%. In this mode, there is no software control over heating.

9.3 Second Stage Heating

- What is Second Stage Heating
- How do Heaters and High Heaters Work Together?

9.3.1 WHAT IS SECOND STAGE HEATING

Second stage heating (high heating) provides additional heat beyond the main heating system. Alternatively, second stage heating employs 2-stage heater (low/high fire) (????). The second stage heating operates when the outside weather is so cold that the standard heaters cannot maintain the required temperature.

There must be a primary heater defined for the second stage heater to operate. For example if there is one primary heater and two secondary heaters, heater #1 and high heater #1 work together; the 2nd secondary heater will not operate. Refer to the Installation Manual for more information.




9.3.2 HOW DO HEATERS AND HIGH HEATERS WORK TOGETHER?

Heaters and high heaters can work together or independently, depending on how their toggle switches are set. Each unit has a separate temperature definition.












- The basic heat temperature is defined in the Temperature Curve (refer to Configuring the Temperature Curve, page 25)
- Heater and Higher Heater differentials are defined in the Heating program screen (click [here for details](#)).





The following table uses Heater 1 and High Heater 1 as models.

- Toggle Switch/Current Temperature:
 - Auto/Below Heat Temperature: The heater is currently on.
 - Auto/Above Heat Temperature: The heater is currently off.
 - Auto/Below High Heat Temperature: The high heater is currently on.
 - Auto/Above High Heat Temperature: The high heater is currently off.

- On: The heater/high heater operates continually, independent of the target temperature.
- Off: The heater/high heater does not operate, independent of the target temperature.
- Heater Icons:
 - : Both heaters are off
 - : The heater is operating alone
 - : Both the heater and the high heater are operating or the high heater is operating alone


*NOTE When the heating method is defined as central heating, Trio displays one icon.
When the heating method is defined as zoned heating, Trio displays an icon for each heater-high heater pair.*

Heater 1 Toggle Switch	Current Temperature	High Heater 1 Toggle Switch	Current Temperature	Icon Displayed
Auto	Below heat temperature	Auto	Below high heat temperature	
Auto	Below heat temperature	Auto	Above high heat temperature	
Auto	Below heat temperature	On	Irrelevant	
Auto	Below heat temperature	Off	Irrelevant	
Auto	Above heat temperature	Auto	Above high heat temperature	
Auto	Above heat temperature	On	Irrelevant	
Auto	Above heat temperature	Off	Irrelevant	
On	Irrelevant	Auto	Below high heat temperature	
On	Irrelevant	Auto	Below high heat temperature	
On	Irrelevant	On	Irrelevant	
On	Irrelevant	Off	Irrelevant	

Heater 1 Toggle Switch	Current Temperature	High Heater 1 Toggle Switch	Current Temperature	Icon Displayed
Off	Irrelevant	Auto	Below high heat temperature	
Off	Irrelevant	Auto	Above high heat temperature	
Off	Irrelevant	On	Irrelevant	
Off	Irrelevant	Off	Irrelevant	

9.4 Central Heaters

When using central heat, the heater output is defined by the average measured temperature of all temperature sensors.




As temperature drops, TRIO reduces the amount of ventilation until it provides the minimum defined amount. If the temperature goes below the target temperature, TRIO continues to run at minimum ventilation. At the same time, heating begins when the temperature drops to a user defined temperature.


- Define relays output ports as heaters in Devices and Sensors. Refer to the Installation Manual.
- In Configuring the Temperature Curve, page 25 define the Heat parameter.
- Configuring On-Off heaters requires mapping one fan, inlet, outlet, or tunnel door.

To define the central on/off heaters:

1. Go to System > Control Strategy > Climate  .




2. Define the Heating Method as Central.
3. Go to Climate > Heating.



4. Define:
 - Heater On Temp: Define the difference from the Heat target temperature at which the heaters turn on. Range: 0.4 – 8.9° F.
 - If Heater – High relays are mapped:
 - High On (Diff Below Heat): Define the temperature at which the 2nd stage heater begins to operate.
 - High Off (Diff Below Heat): Define the temperature at which the 2nd stage heater ceases to operate.

5. Go to Settings.




6. Heat Tuning: This parameter determines how aggressively the TRIO responds to differences between the measured temperature and the target temperature.

NOTE Munters recommends leaving this parameter at Normal.

9.5 Zone Heaters

A zone is an area in the poultry house. Each zone heater can be mapped to specific temperature sensor(s) and operates according to that sensor's data output. The heat set point in the temperature curve is the same for all zones. Once a zone's heater is activated, it will work to maintain the temperature. All zone heaters work independently.

Trio Rotem supports up to 16 heat zones.




Device	Avg.	Temperature Sensors	Outside
Full House		1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	
Cooling 1	<input checked="" type="checkbox"/>		
Heat 1		1 3	
Heat 2		2 4	
Heat 3		5 6 8	
Heat 4		7 9 10	
Heat 5		11 12 13	
Heat 6		14 15 16	



➡ Define relay or analog output ports as heaters. Refer to the Installation Manual.

➡ In [Configuring the Temperature Curve](#), page 25 define the Heat parameter.


To define the zoned on/off heaters:

1. Go to System > Control Strategy > Climate .



Control Strategy → Climate	
	Heating
	Heating Method: Zoned Heater Cycle: <input type="checkbox"/>


2. Define the Heating Method as Zoned.
3. Go to Climate > Heating.



4. Define:

- Heater On Temp: Define the difference from the Heat target temperature at which the heaters turn on. Range: 0.4 – 8.9° F.
- If Heater – High relays are mapped:
 - High On (Diff Below Heat): Define the temperature at which the 2nd stage heater begins to operate.
 - High Off (Diff Below Heat): Define the temperature at which the 2nd stage heater ceases to operate.

5. Go to System > Temperature Definition.



6. Map each heater to one or more temperature sensors.

NOTE Two or more temperature sensors must be defined to enable mapping devices to temperature sensors.

9.6 Heating Options


- Analogue Heaters
- Heat Cycles

9.6.1 ANALOGUE HEATERS

➡ Define analog ports as heaters in Devices and Sensors. Refer to the Installation Manual.

Define the analogue heaters using the same procedure as the on/off heaters. In addition:

1. Go to Climate > Heating > Settings.




2. Define the Minimum Heater Output. Range: 0 – 100%. Default: 5%

9.6.2 HEAT CYCLES


When running heaters in cycles, the user defines the minimum on and off times. As the temperature decreases, the on time automatically increases.

To enable running heaters in a cycle:

1. Go to System > Control Strategy > Climate .



2. Enable Heater Cycle.
3. Go to Climate > Heating > Settings.



4. Define:

- Total Cycle Time (sec.): Range 5 – 600 seconds. Default 300 seconds
- Minimum Cycle On Time (sec): Range 5 – 600 seconds. Default 60 seconds
- Minimum Cycle Off Time (sec): Range 5 – 600 seconds. Default 30 seconds


10 Brood Area

Chicks require extra heat during the first few weeks (8 – 14 days) of their lives. To reduce energy costs, Trio enables designating a certain area as a brooding area; that specific area can be kept extra warm. At a certain point in the chicks' growth cycle, the brooding area is expanded to the full house.


The brood area has its own temperature sensor(s) assigned to it. All devices and programs operate according to the brood area temperature sensors. However, as an option you can enable non-brood area heaters. In that scenario, those heaters operate according to the non-brood area temperature sensors and temperature set points.

Brooding affects the following screens:

- Mortality
- Bird scale settings and history
- Dashboard
- Scale Card



1. Go to System > Control Strategy > Flock .




a. Enable Brooding Area.

b. If required, enable non-brood heaters and define the set point. This is the on/off temperature for the heaters in the non-brooder area. These heaters are mapped to those sensors not mapped to the brooding area temperature sensors (next step). Range -40.0 to +193.9° F. Default: 32.0

2. Go to Flock > Flock Settings.

3. In Growing Stage, select Brooding.



4. Go to System > Temperature Definition (temperature sensors must be defined).

Device	Avg.	Temperature Sensors		
Full House		1	2	3
Brooding			2	
Heat 1	<input checked="" type="checkbox"/>			
Heat 2			2	

5. Map temperature sensor(s) to the brooding area.

11 Feed and Silo Management

- Feeding Summary
- Setting up Feeding
- Configuring the Silo

11.1 Feeding Summary

Feed is stored in silos located outside the chicken house. Augers transport the feed to hoppers. Sensors are installed on the augers and hoppers to ensure that the proper amount of feed is transported. Feed lines transport the feed from the hoppers to feeding pans, according to signals sent from the hoppers. Trio receives inputs from the augers and hoppers that enable controlling the feed distribution (start and stop signals). In addition, the user enable an alarm if the run time exceeds the defined parameters.

- ➡ Cross auger, feeder, and silo relays must be wired, defined, and mapped.
- ➡ Auger active and feeder active digital sensors must be wired, defined, and mapped.

11.2 Setting up Feeding


- Automatic Feed Control
- Manual Feed Control

11.2.1 AUTOMATIC FEED CONTROL

- ➡ Verify that the toggle switches of the feeder relays are set to Automatic.

Use the Feed Screen to configure automatic control over the augers and feeders, according to the user-designed schedule. All augers operate according to the auger schedule and all feeders work according to the feeder schedule.

1. Go to Control > Feed > Feeding .




2. Click

3. Define:

- Day tab: This defines the growth day at which the program runs until the next defined day. Define up to eight days.
- Time Frame: Define the period in which the feeders and augers are active:
 - Specific time frames define the start and stop time for each device via the input parameters.
 - Define up to eight time frames.
 - Times frames must be in consecutive order (beginning to end of the day).
 - Do not overlap time frames. If time frames are overlapped, the latter frame is ignored.
 - 24 hours a day.



4. If required, go to Control > Feed > Alarms to set the alarms. Enable the alarms.



5. Click  and define the cross auger and feeder alarms:

- Alarm Time Frame: Define the period in which the feeders and auger are active, 24 hours a day or specific time frames.
- Alarm Start Day: The growth day on which the controller begins to send alarms.
- Over/Under Runtime: If the feeders and auger run more or less (respectively) than these times, the controller sends an alarm.
 - Auger overtime alarm: The augers operate when the hoppers switch transmits a signal to distribute feed. The augers cease operating when hoppers are full. If the run time exceeds the user defined run time, the auger active sensor (refer to Devices and Sensors) should generate an alarm.
 - Auger under-time alarm: Under time alarms occur when the auger motor has been off for longer than the under time parameter.
 - Feeder overtime alarm: Feeders begin receiving feed when the last pan sends a signal. Feed distribution continues until the pans are full. If the feed distribution is longer than the user-defined time, the feeder active sensor should generate an alarm.
 - Feeder under time: Feeder under time defines the time required to generate an alarm when the feeder is not active.
- Stop feeding System: If enabled, the controller stops the feeding cycle once a cross over runtime is detected.

11.2.2 MANUAL FEED CONTROL

- ➡ Set the toggle switches of the feeder relays On or Off.
- When the Feed Relay is set to ON, feed is transported continually, regardless of the program configuration. Trio records the quantity of feed transported.
- When the Feed Relay is set to OFF, feed transportation ceases. Trio does not record any feed distribution.

Get screen shot


11.3 Configuring the Silo

Silo content is determined by weight using load cells attached to the silo legs.

- Silo weight increases when feed is delivered.
- Silo weight decreases when feed is distributed to birds.

1. Go to Flock > Silo Management.

The screen displays the amount of feed remaining in each silo, in quantity and percentage of the total capacity.



2. Enter the amount of feed in each silo. Range: 0 – 50000 kgs.

3. To specify the feed type, click Feed Supply. Click Feed Type and select the type.

Date	Time	Silo	Delivered	Storage	Feed Type
15/09/2024	00:00	1	0 Lb	0 Lb	Wheat

4. Go to Flock > Silo Management > Settings.

Minimum Filling Detection Amount 1,101 Lb

Silo Low Storage Alarm

5. Define:

- Minimum Filling Detection Amount: Define the minimum amount of feed to be delivered to be recorded. Range 111 – 11,013 Lb. Default 1101 Lb.
- Silo Low Storage Alarm: Enabling this alarm allows generating an alarm when the amount of feed in the silo drops to this percentage of the capacity.

12 Water Control

- Introduction to Water on Demand
- Setup
- Flushing the Drinking Lines

12.1 Introduction to Water on Demand

- How is Water Pressure Measured
- Water Program Control
- Water Pressure Units

12.1.1 HOW IS WATER PRESSURE MEASURED

Trio controls water pressure at two levels:

- A WOD Pro 0 – 10V device controls the water pressure.
- A water pressure (analog) sensor measures the actual pressure, providing feedback to the system.

12.1.2 WATER PROGRAM CONTROL

The WOD program can be managed according to:

- Trio's Light program.
- User-defined time schedule.

12.1.3 WATER PRESSURE UNITS

Trio measures water pressure in either metric or imperial units. Water pressure to the control room is measured in bars or PSI. Water pressure in the actual drinking lines is measured in centimeters-water or inch-water.

To select the units, go to System > General Settings > User (refer to Defining the Preferences, page 14).

12.2 Setup

The following section details how to set up the WOD, according to the options chosen. Control can be via relays (WOD) or a sensor (WOD Pro). In addition, Trio controls the program according to time or the light program.

NOTE Pressure must increase during the growth cycle.


- WOD Relay Control
- WOD Pro 0 – 10 Volt Control
- Manual Control Over Lighting and WOD

12.2.1 WOD RELAY CONTROL


- In Devices and Sensors, define 1 – 3 relays as WOD. Refer to the Installation Manual.
- WOD - Time Control
- WOD - Light Control


12.2.1.1 WOD - Time Control


1. Go to System > Control Strategy > Water.



2. Verify that the option is disabled.
3. Go to Control > Water > WOD.




4. Click .
5. Define the growth day, the start times, and the relays used to control the pressure.
6. Add a tab for each growth day and define the parameters.



12.2.1.2 WOD - Light Control

1. Go to System > Control Strategy > Water.



2. Enable Manage According To Light Program.

3. Go to Control > Water > WOD.



4. Click .


5. For each growth day, define the relay(s) used during the following times:

- Light times: Period when lighting is on.
- Dark Time: Period when lighting is off.

- Boost Time: These are the times when water consumption is increased. These periods are defined in the settings.



6. Go to  Settings



7. Define:

- Time Before Lights Come On: Define the number of minutes that pressure is increased before the lights come on. Default: 0. Range: 0 – 300.
- Time After Lights Come On: Define the number of minutes that pressure is increased after the lights come on. Default: 120. Range: 0 – 300.
- Time Before Lights Come Off: Define the number of minutes that pressure is increased after the lights turn off. Default: 120. Range: 0 – 300.


12.2.2 WOD PRO 0 – 10 VOLT CONTROL

➔ In Devices and Sensors, define one analog port as WOD Pro. Refer to the Installation Manual.

- WOD Pro - Time Control
- WOD Pro - Light Control
- WOD Pro Pressure Alarms


12.2.2.1 WOD Pro - Time Control

1. Go to System > Control Strategy > Water.



2. Verify that the option is disabled.

3. Go to Control > Water > WOD.



4. Click .


5. Define the growth day, the start times, and the drinker line pressure.

6. Add a tab for each growth day and define the parameters.



12.2.2.2 WOD Pro - Light Control

1. Go to System > Control Strategy > Water.



2. Enable Manage According To Light Program.


3. Go to Control > Water > WOD.





4. Click .

5. For each growth day, define the drink line pressure for the following times:

- Light times: Period when lighting is on.
- Dark Time: Period when lighting is off.
- Boost Time: These are the times when water consumption is increased. These periods are defined in the settings.



6. Go to



7. Define:

- Time Before Lights Come On: Define the number of minutes that pressure is increased before the lights come on. Default: 0. Range: 0 – 300.
- Time After Lights Come On: Define the number of minutes that pressure is increased after the lights come on. Default: 120. Range: 0 – 300.
- Time Before Lights Come Off: Define the number of minutes that pressure is increased after the lights turn off. Default: 120. Range: 0 – 300.

12.2.2.3 WOD Pro Pressure Alarms

When employing WOD Pro, Trio can generate water pressure alarms based on the difference between the requested pressure (defined by the WOD Pro) and the pressure measured by the water pressure sensor.

➡ In Devices and Sensors, define one analog port as Water Pressure. Refer to the Installation Manual.

1. Go to Control > Water > WOD > Settings.



2. Define:

- Low\High Pressure Diff: Define the difference between the requested and measured pressure to generate a low\high water pressure alarm. The condition must continue for 30 seconds for an alarm to be generated.

- Emergency High Water Pressure: Define the pressure required to generate an alarm.
 - If there is a leak, this leakage is translated into a high pressure signal. An alarm is generated when the pressure is above the defined level for more than five seconds. In the event of an emergency alarm, the pump is shut off.
 - Reset the alarm to exit the emergency state.

12.2.3 MANUAL CONTROL OVER LIGHTING AND WOD

➡ Position the toggle switches of the light relays to ON or OFF.

When the light relays' toggle switches (located on the Rotem Trio Expansion) are set to ON or OFF, the controller functions as if it is in light period or dark period, respectively.

- Dark period means that no lights are on.
- Water pressure is managed as if it is light period (refer to WOD - Light Control, page 103 and WOD Pro - Light Control, page 106 for details).
- The high water usage alarm, if managed by the light program (refer to Water Alarm, page 135), must be evaluated according to the boost time settings (refer to WOD Pro 0 - 10 Volt Control, page 104).

12.3 Flushing the Drinking Lines


Flushing means running clean water, at high pressure, through the drinking lines. Flushing:

- Keeps the nipple drinkers clear of any blockage
- Keeps the lines clean of contaminants
- Provides cooler water to birds which encourages them to drink more


To flush the drinker lines:

- ➡ Define WOD relays and WOD Pro analog port as required.
- ➡ Define Water Meter sensors.
- ➡ Define Water Pressure sensors.


1. Go to Control > Water.



2. Click:

- Start Drinking Line Flushing to begin the process.
-  to change the amount of time that flushing continues.


3. Go to Control > Water > WOD > Settings (option).



4. Click .

5. Define the Pressure During Drinker Line Flushing.

- The Drinker Line Flushing setting is available only when WOD Pro is enabled.
- When flushing is taking place, a pop up appears on the dashboard.



NOTE During flushing, the water measured by the water meter are not added to the drinking water history.


13 Lighting Program

Trio supports on/off (non-dimmable) lights and dimmable lights. In setting up the program, the following options must be defined:


- On/Off and/or 0 – 10 Volt Variable Lights (defined in Devices and Sensors). A system can include both.
 - Single line or multiline control: In single line control, all light lines have the same output. In multiline control, the user defines the value (on/off or intensity level) for each line.
 - Time: Starting time for each lighting event.
 - If a light sensor is installed, an alarm can be generated if the light goes below a certain intensity.
-
- Relay Control
 - 0 – 10 Volt Control
 - Service Lights
 - Light Intensity Alarm

13.1 Relay Control


NOTE The following section describes how to configure the controller programming for light relays. This programming operates when the light relays are set to Automatic. If the toggle switch is set to On or Off, refer to Manual Control Over Lighting and WOD, page 108.

-  Position the Rotem Trio Expansion toggle switches of the light relays on Automatic.

1. To enable multi line control, go to Control > Light > Settings and enable Multi Line Control (option).



2. Go to Control > Light.




3. Click .

4. Define the growth day.

5. In line one, define the time that the lights go on.

6. Enable the line(s) .

- In single line control, click the light icon. Another light icon appears. Click that icon. Both icons turn blue.
- In multi-line control, click the icon of each required line. Another light icon appears. Click that icon. All icons turn blue.



7. Add additional programming lines to define when the light lines go off and then on. Repeat for each growth day.

8. Click **Save**.

	Time	Light
1	06:00	
2	07:00	
3	08:00	


In this scenario, all lights go on at 6:00, turn off at 7:00, and turn on at 8:00.

	Time	Light 1	Light 2	Light 3	Light 4
1	06:00				
2	06:30				
3	07:30				


In this scenario, light line 2 goes on at 6:00. At 6:30, light line 2 goes off and light line 1 goes on. At 7:30, light line 3 also turns on.

13.2 0 – 10 Volt Control

1. To enable multi line control, go to Control > Light > Settings and enable Multi Line Control (option).




2. Go to Control > Light.




3. Click .

4. Define the growth day.

5. In line one, define the time that the lights go on.

6. Enable the line(s) .

- In single line control, click the light icon. Another light icon appears. Click that icon. Both icons turn blue.
- In multi-line control, click the icon of each required line. Another light icon appears. Click that icon. All icons turn blue




7. Under each light icon, define the light intensity.

8. Under Dim Time, define the amount of time before the next lighting event that the lights begin to change their intensity.

9. Add additional programming lines. Repeat for each growth day.

10. Click Save.



In this scenario, all light lines begin to turn on at 5:40. At 6:00, lights reach 45% intensity. At 6:40, light intensity begins to increase, reaching 55% at 7:00. At 8:10, light intensity begins to increase, reaching 60% at 8:30. At 18:40, lights begin to dim, reaching 0% at 19:00.

Light Program						
Day 1						
	Time	Light 1	Light 2	Light 3	Light 4	Dim Time(min.)
1	06:00	45 %				20
2	06:00		55 %			20
3	08:30	60 %			60 %	20
4	19:00	0 %	0 %		0 %	20

NOTE In multi-line mode devices may have different intensity settings; calculate the dimming rate for each line separately.

At 5:40 Line 1 and Line 2 turn on. Both reach their intensity (45% and 55% respectively) at 6:00. At 8:10, Line 1 begins to increase its intensity and Line 4 turns on. Both Line 1 and Line 4 reach 60% at 8:30. At 19:00 all lines begin to turn off, turning off completely at 19:20.

13.3 Service Lights


The screenshot displays the 'House 1' control interface. On the left, a sidebar shows 'VENTILATION' at 100% level and 0% heat, 'TEMPERATURE' at 24.5°C (set to 20.0°C, RH at 56%), and 'DEVICES' icons. The main area features a circular 'VENTILATION' dial with 'OUTPUT 100%' and '0 M3/h' displayed. The dial is marked with 'min' and 'max' and includes indicators for RH, NH₃, CO₂, and a snowflake icon. On the right, 'VENTS' 1 and 2 are both at 100%, and 'LIGHT' controls show three light icons (1, 2, 3) and a 'SERVICE LIGHT >' button.

Service lights is a function that turns on the lights for a defined amount of time, temporarily overriding the programming. When the service light icon (which appears on the dashboard) is pressed, all lights are turned on.

- Turning the lights on:
 - 0 – 10 volt lights: When turned on, the lights gradually rise to the defined brightness. The time required for the lights to fully turn on is user-defined. If the light level is higher according to the programming than the level defined in the Service Light function, the lights remain at their programmed level.
 - On/Off lights: All lines turn on immediately.
- Turning the lights off: When the time expires or the user presses Turn Off, lighting control returns to the levels defined in the program.


To define the Service Light functionality:

1. Go to Control > Light > Settings.
2. Define the parameters.
 - On/Off lights:



- Operative Time (Min.): Define the amount of time (in minutes) that the lights remain on. Range 1 – 120. Default: 30

- 0 – 10 volt lights:



- Operative Time (Min.): Define the amount of time (in minutes) that the lights remain on. Range 1 – 120. Default: 30
- Light Output: Define the lights' output (in percentages). Range: 10 – 100. Default: 50
- Dim Time (Min.): Define the amount of time that the lights require to power up to light output level and to power down to the programmed level.

13.4 Light Intensity Alarm

Trio can generate an alarm when lights go below a user-defined level.

🔔 This function requires a light sensor. Refer to the Installation Manual.

1. Go to Control > Light > Settings and enable Light intensity alarm.

2. Define the minimum light intensity that lights must achieve. Below this level, Trio generates an alarm.

14 Expected Bird Weight

Trio collects bird weight data. Factors to set up when configuring how Trio measures weight:

- Reference Bird Curve: The reference weight is a value that reflects the birds' expected target weight.
 - Enabled: Trio provides a weight curve (by growth day). The user can choose an industry standard template or manually define a curve.
 - Disabled: Trio provides a reference weight that can be edited.
- [Separate male/female weighing](#): When enabled:
 - Scales can be defined as male, female, or both.
 - Weight range can be specified for both genders.
 - If the bird curve is enabled, there are separate curves for each gender.
- ➔ To enable editing the weight range and bird scale definition, define at least one scale in Devices & Sensors. Two bird scales are required for weighing male and female bird separately.

14.1 Reference Bird Curve


As an option, Trio provides a default growth curve which increases according to the average weight. If required, there is an option to use a bird curve. These bird curves do not change according to the birds' actual weight. If required, you can edit the growth days and bird weights.

- Curve Enabled
- Curve Disabled

14.1.1 CURVE ENABLED

1. To enable a bird curve, go to System > Control Strategy > Scales






2. Click  and enable the reference curve.

3. Go to Flock > Bird Weight > Load Template. From the drop-down list, select one of the following:

- Industry standard curve
- Blank. This option enables manually defining a growth curve.





4. Click **Next** and confirm your choice.

5. If required, edit the curve and save.

6. Go to Flock > Bird Weight.

Day	Weight	Ref. Weight	Curve Offset
0	0.093 Lb	0.335 Lb	0 Lb
1	0.139 Lb		
2	0.163 Lb		
3	0.198 Lb		
4	0.24 Lb		

NOTE In the illustration above, the curve is not gender-separated. If male and female birds are weighed separately, two curves appear.

7. Click  and define:
 - Day: Define the growth day used to determine the desired weight. Range 0 - 999
 - Weight: Set the expected bird weight. Range 0 - 30.0 kg/0- 66 lbs.
8. Click  and edit the Curve Offset (option).


14.1.2 CURVE DISABLED




1. To disable a bird curve, go to System > Control Strategy > Scales

Control Strategy → Scales	
Reference Curve	<input type="checkbox"/>
Weight Range	
Above the Average	25 %
Below the Average	25 %

2. Verify that the curve is disabled.
3. Go to Flock > Bird Weight.




4. Click  to edit the reference weight.

14.2 Male/Female Weighing

- Gender Separated Weighing
- Non-Separated Weighing


14.2.1 GENDER SEPARATED WEIGHING

1. Go to System > Control Strategy > Flock .



2. Click  and enable Separate Male/Female.

3. Go to System > Control Strategy > Scales .



4. Define:


- Gender Selection: Define each scale as Male & Female, Male, or Female.
- Male/Female Weight Range: These parameters define the bands above and below the reference weights. If a bird weight is above or below this band, it is not included in the data.

NOTE When Separate Male/Female is enabled, there are reference curves, reference weights, and curve offsets for each gender in the Flock > Bird Weight Screen.

14.2.2 NON-SEPARATED WEIGHING




1. Go to System > Control Strategy > Flock



2. Click  and disable Separate Male/Female.

3. Go to System > Control Strategy > Scales



- **Weight Range:** These parameters define the bands above and below the reference weights. If a bird's weight is above or below this band, it is not included in the data.

15 Air Quality


Ensuring air quality means configuring the Trio relative humidity, CO2, and ammonia sensors. Each of these factors are independent and require a sensor. When any of these factors rise above the user defined levels, Trio compensates by increasing the ventilation rate or by increasing the heat.

- Ventilation must be running for compensation to begin. Air quality control runs during basic ventilation only.
 - If one of these factors is above the user defined set point, compensation begins. If two or more factors are above the user-defined set point, only one air quality program runs. When that factor falls to the required level, only then does the second air quality factor begin to operate.
 - The user defines which type of compensation is used.
 - As compensation takes place, Trio continually checks the sensors' measurements. As long as the measured RH, CO2, or ammonia remain above the defined levels (levels are checked every 30 seconds), ventilation or heating increases by 2%.
 - Once the levels are below the required levels, compensation begins to decrease by 2%. Trio continues to check the sensors' measurements (every 30 seconds). Treatment continues until the shut off values are reached.
- Defining the Air Quality Parameters
 - Defining the Air Quality Settings

15.1 Defining the Air Quality Parameters

1. Go to Climate > Air Quality.

- ➡ Each sensor must be defined and mapped for the sensor to appear on this screen. Refer to the Installation Manual.



Day	Humidity	CO2	Ammonia	Humidity Alarm	80 %
1	45 %	3,000	25	CO2 Alarm	2,000 ppm
				Ammonia Alarm	30 ppm

2. Set the values over which the “air treatment” start, these values are adjusted over growth days (no curve).


3. Define:

- Day: Set the growth day to determine the desired set points for RH, CO2 and NH3. Range 0-999
- Humidity: Set the humidity level above which air treatment starts. Range 0%-100%
- Co2: Set the Co2 level above which air treatment starts. Range 0 - 5000 ppm
- NH3: Set the ammonia level above which air treatment starts. Range: 0 - 100 ppm

15.2 Defining the Air Quality Settings

When the air quality (CO2/NH3/Humidity) exceeds the specifications defined in the Air Quality Screen, Trio can increase the ventilation, the heat or both. (Alternatively, additional treatment can be disabled).

When central heating is employed, the changes to heating are global. When zone heaters are employed, changes are specific to each heater.



• Define:

- Air Quality Treatment:
 - Off
 - By Ventilation (Treatment by Ventilation only is enabled)
 - By Heat (Treatment by is Heat only is enabled)
 - By Outside Temp (both Treat by Ventilation and Heat are enabled)
- Outside T° To Operate By Heaters (Diff Below Target): Below this difference from the target temperature the controller automatically adjusts the heat output to compensate the air quality. Range 32.1°to +121.9° F
- Treatment by Ventilation:

- Maximum Additional Ventilation: Define the maximum ventilation adjustment to cycle times or speed to variable speed fans. Range: 1 – 100%. Default: 20%
 - Inside T° to Stop Treatment (Diff Below Target): Define the difference below the target temperature at which additional ventilation treatment ceases. Range: 0 – 17.9° F. Default 3.6°.
- Treatment by Heat:
 - Maximum Additional Heat (%): The maximum increase in heat (max compensation). Either the cycle time or heat intensity in variable heaters increases. Range: 1% to 100%. Default: 60
 - Inside T° to Stop Treatment (Diff Above Target): Above this difference from the target temperature the controller stops this heat treatment. Range: 0 – 17.9° F. Default: 3.6°.
- Humidity:
 - RH Shutoff Differential: (%): Below this level, humidity treatment ceases. Range: 0% to 10%. Default: 5%
 - High Humidity Alarm Threshold (%): Trio sends an alarm when the humidity level rises above this level. Range: 0% to 100%. Default 80%
- CO2:
 - Co2 Shutoff Differential: (ppm): When CO2 levels are below the target level by this amount, all CO2 treatment stops. Range: 0 to 500 ppm. Default: 100 ppm
 - High Co2 Alarm Threshold (ppm): Trio sends an alarm when the CO2 level rises above this level. Range: 0 to 5000 ppm. Default: 2000 ppm
- Ammonia
 - NH3 Shutoff Differential: (ppm): When ammonia levels are below the target level by this amount, all ammonia treatment stop. Range: 0 ppm to 10 ppm. Default: 5 ppm
 - High NH3 Alarm Threshold (ppm): Trio sends an alarm when the ammonia level rises above this level. Range: 0 to 100 ppm. Default: 30 ppm.

16 Timers

Timers provide an additional method of controlling relay devices, namely setting a timetable in which the device can operate. In addition to the timetable, Trio enables setting up time cycles and temperature ranges in which a device can operate.

Trio supports up to five timers.

The screenshot displays the 'Timers' configuration page for 'House 1'. At the top, the interface shows the current day (5) and time (16:00). The main content area is divided into several sections:

- Active House Mode:** Includes radio buttons for 'Growing' (selected), 'Empty', 'Pre-Heat', 'Cleaning', and 'Catching'.
- Time:** Shows a 24-hour cycle starting at 24:00, with a duration of 24 h.
- Temperature:** Includes a table with the following data:

Function	Cooling
Temperature Set-Point	32 °F
Temperature Band	2
- Humidity:** Includes a table with the following data:

Function	Humidifying
Humidity Set-Point	60 %
Humidity Band	2
- Cycle:** Includes a table with the following data:

ON	0 sec
OFF	0 sec

➡ Define at least one relay as a timer in **Devices and Sensors**.

1. In **Control > Timers**, click edit, and define a timer as Active.
2. Define for each timer:

- **Active House Mode:** Define in which mode each timer can operate. Multiple modes can be selected.
- **Time:** Timers can run 24 hours a day or in user-defined time frames. Define up to four time frames for each timer.
- **Temperature:** This function enables controlling devices according to temperature. If enabled, define:
 - **Function:** Define the timer control mode:
 - **Cooling:** The timer operates when the temperature rises above the set point plus the band and continues to operate until the temperature drops below the set point.
 - **Heating:** The timer operates when the temperature drops below the set point minus the band and continues to operate until the temperature rises above the set point.
 - **Temperature Set-Point:** Define the target temperature. Range -40.0 to +193.0° F. Default 32.0° F
 - **Temperature Band:** The temperature band defines the range in which the timer operates. Range 0 to 10° F. Default 2° F.
- **Humidity:** This function enables controlling devices according to humidity. If enabled, define:
 - **Function:** Define the timer control mode:
 - **Dehumidify:** The timer operates when the humidity rises above the humidity set point plus the band and continues to operate until the humidity drops to the set point.
 - **Humidify:** The timer operates when the humidity drops below the set point minus the band and continues to operate until the humidity rises to the set point.
 - **Humidity Set-Point:** Define the target humidity. Range: 0 – 100%. Default: 60%.
 - **Humidity Band:** The humidity band defines the range in which the timer operates. Range 0 to 10%. Default 2%
- **Cycle:** If enabled, define the cycle times. The timer operates using the cycle defined here. Range: 0 – 999 seconds (optional). For the cycle to activate, other conditions (temperature/humidity/time) must be fulfilled.

3. As an option, timers can be mapped to an outside temperature sensor. Go to System > Temperature Definition.

Device	Avg.	Temperature Sensors			Outside
Full House		1	2	3	
Heat 1	✓				
Heat 2			2		
Heat 3	✓				
Heat 4			2	3	
Timer 1					✓
Timer 2			2		

- If an outside temperature sensor is enabled, map timers to it (if required).

17 Alarms


- Defining the Alarm Parameters
- Viewing the Alarms
- Defining the Auxiliary Alarms
- Sending a General Alarm

17.1 Defining the Alarm Parameters

- Alarm Definitions
- Alarm Test

17.1.1 ALARM DEFINITIONS

1. Go to System > Control Strategy > Alarms .



DAY 12 TIME 16:49 House 1

Control Strategy → Alarms

Alarm Delay (sec.) 60

Alarm Reminder (min.) 30

ALARM TEST

Scheduled Alarm Test

Days SU MO TU WE TH FR SA

Time 12:00

User Must Dismiss The Alarm

Potentiometer Alarm

Alarm Time Frame 24 Hours

NOTE Water Overflow, Water Shortage, and Potentiometer only appear if these devices are mapped. Refer to Devices and Sensors.

2. Click .

3. Define:

- Alarm Delay: After detecting that a parameter has gone above or below its specs, Trio waits this amount of time before sending an alarm. This prevents

sending alarms for short deviations. Range: 0 – 999 seconds. Default: 60 seconds.

- Alarm Reminder: Trio will resend an alarm after this amount of time if the alarm is not acknowledged. Range: 0 – 999 minutes. Default: 30 minutes.
- Potentiometer: Trio sends an alarm if potentiometer-controlled inlets are not opening to the required levels. Define the period in which the alarm is active, 24 hours a day or specific time frames. (A potentiometer must be mapped in Devices & Sensors for this alarm to appear. Refer to the Installation Manual.)

17.1.2 ALARM TEST

The alarm test confirms that the alarm system is functioning properly. A test can be performed manually at any time or scheduled weekly or daily.

- Manual Test
- Scheduled Tests


17.1.2.1 Manual Test

- Click . Stop the test as needed.

17.1.2.2 Scheduled Tests

Scheduled tests can be performed once a day only.

1. On the Alarm Screen, enable Scheduled Alarm Test.



The screenshot shows the 'Control Strategy → Alarms' configuration screen for 'House 1'. The top bar displays 'DAY 5' and 'TIME 17:32'. The screen is divided into two main sections. The left section contains the following settings:

- Alarm Delay (sec.): 60
- Alarm Reminder (min.): 30
- Scheduled Alarm Test**: Enabled (toggle switch)
- Days: Radio buttons for SU, MO (checked), TU, WE, TH (checked), FR, SA
- Time: 12:00
- User Must Dismiss The Alarm: Disabled (toggle switch)
- Self-Dismiss After(sec.): 60

The right section features a numeric keypad for entering a 'Range' value, with digits 1-9, 0, and a decimal point.

2. Define:

- The day(s) and time at which the test is performed.
- User Must Dismiss The Alarm:
 - When enabled, the user must acknowledge the alarm. The alarm remains active until the acknowledged.


- When disabled, the alarm stops after a specified amount of time (Self-Dismiss After (sec.)).

NOTE Testing takes place at the scheduled time. If there is a delay for any reason (for example, a power outage), the test will not take place more than five (5) minutes after the scheduled time.

17.2 Viewing the Alarms

- On the Main Menu bar, click




- Click  **ACK ALL** to acknowledge all alarms or acknowledge each one as required.

17.3 Defining the Auxiliary Alarms

The auxiliary alarm provides an additional method for adding alarm functions to specific relays. This function compares the relay's current state to its defined state (normally open, normally close). If the relay is not in its defined state, Trio sends an alarm. You can define the auxiliary alarms to operate during specific time periods. Use this alarm for those relays controlling important functions.

- ➡ Define at least one sensor as an auxiliary input in Devices and Sensors.

1. Go to Control > Auxiliary Alarm




2. In Control > Auxiliary Alarm, click edit, define an alarm as Active.

3. Define:


- Time Frames: Define the time frame, either 24 hours a day or specific time frames.
- Relay Function: Enable this function. Define the relay being monitored. When this relay is no longer in its defined state (normally open, normally closed) an alarm is sent.

17.4 Sending a General Alarm

1. Go to System > Device and Sensors.



2. Click




3. Click Test.


An alarm is sent to everyone on the contact list.

17.5 Water Alarm

The Water Alarm is a unique function which informs the user when water consumption is too low or too high, a parameter which is indicative of bird health issues.

- In Devices and Sensors, map and define at least one digital sensor as a water meter sensor and define it as drinking water. Refer to the Installation Manual.

1. Go to System > Control Strategy > Water .




2. Enable (according to your requirements):

- Low Water Flow: This alarm is triggered when there is a shortage in the estimated water consumption.
- High Water Flow: This alarm is triggered when the actual consumption exceeds the estimated water consumption or there is a water leak.
- Manage According to Light Program (the alarm only operates according to the light program).

3. Go to Control > Water.


NOTE The columns that appear here depend on which alarms were enabled in Control Strategy > Water.



4. Define the days and flow rates that trigger an alarm. These quantities remain in effect until another day is defined. Range: 0 – 999.9 liters/gallons per hour. Default: 0.

5. Go to Control > Water > Settings.

NOTE High and Low Water Alarms Settings are visible only if High and Low Water Flow Alarms are enabled, respectively.




6. Define:

- High Flow Delay (Min.): Define the amount of time that water flows at the high flow rate before Trio sends an alarm.
- Max Water/Hour During Dark Periods: Define the water flow that triggers an alarm when lighting is off. Range: 0.0 to 264.0 gallons. Default: 2.6 gallons
- Delay After The Lights Come ON (Min): After lights turn on, there is often a spike in water intake. Define the amount of time that the water intake is ignored (and no alarm is generated) after the lights come on. Range: 0 - 120 minutes. Default: 60
- Delay Prior To Light Turning OFF (Min): Before lights go off, there is often a spike in water intake. Define the amount of time that the water intake is ignored (and no alarm is generated) before the lights turn off. Range: 0 - 120 minutes. Default: 60.
- Low Flow Delay (Min.): Define the amount of time that water flows at the low flow rate before Trio sends an alarm.
- Enable During Dark Periods: Enable low water alarms when lighting is off (and drinking is normally reduced).


18 History

- A Trio controller saves:
 - 150 growth days of history data (minimum).
 - Up to 365 growth days of history data (estimated maximum)
 - TrioAir saves data on the server for an unlimited amount of time.
 - Starting a new batch/flock erases all history data.
 - The alarm and events history table can store up to 2000 items.
-
- Climate and Air Quality
 - Alarms and Events
 - Water and Feed History
 - Devices History
 - Bird Weight History

18.1 Climate and Air Quality


1. Go to Flock > History > .
2. Click the relevant tab to see its history.


NOTE The History screen only shows the history of installed sensors.



Day	Minimum	Average	Maximum
6 31/01/2024	98.7 °F	102 °F	102.9 °F
5 30/01/2024	95.8 °F	100.5 °F	106.8 °F
4 29/01/2024	91.9 °F	95.5 °F	103.1 °F
3 28/01/2024	92.4 °F	94.7 °F	98.9 °F
2 27/01/2024	93.8 °F	97.6 °F	100.5 °F

- Temperature History: Records the average, minimum and maximum temperature for each growth day every hour

- Humidity History: Records the average, minimum and maximum humidity for each growth day every hour.
- Co2 History: Records the average, minimum and maximum Co2 for each growth day every hour.
- Ammonia History: Records the average, minimum and maximum ammonia for each growth day every hour.
- Click the clock symbol () to view the hourly breakdown.




Hour	Minimum	Average	Target	Maximum	Outside Temp.
00:00	102.7 °F	102.8 °F	82.1 °F	102.9 °F	86.2 °F
01:00	102.2 °F	102.4 °F	82.1 °F	102.7 °F	86 °F
02:00	101.9 °F	102.1 °F	82.1 °F	102.2 °F	85.9 °F
03:00	101.9 °F	102.1 °F	82.1 °F	102.2 °F	86 °F
04:00	101.9 °F	102.2 °F	82.1 °F	102.4 °F	86 °F
05:00	102.4 °F	102.5 °F	82.1 °F	102.7 °F	86.1 °F

18.2 Alarms and Events

Go to this screen to view the last 999 alarms and events. Alarms history can display the following alarms.

NOTE Performing a Cold Start or Starting a new group clears the Alarm History.

1. Go to Flock > History > .
2. Click the relevant tab.

Day	Time	Alarm	Duration
1 17/05/2023	13:40:21	Ammonia Sensor Failure	00:00:00
1 17/05/2023	13:40:21	CO2 Sensor Failure	00:00:00
1 17/05/2023	13:25:13	Auxiliary 1 Activated	00:00:00
1 17/05/2023	12:53:56	Potentiometer 1 Failure	00:31:52
1 17/05/2023	12:53:51	Ammonia Sensor Failure	00:31:57

- Alarm Descriptions
 - Unknown Alarm
 - Low Temperature
 - High Temperature
 - Sensor # Low Temperature
 - Sensor # High Temperature
 - High humidity
 - High Co2
 - High Ammonia
 - Low Pressure
 - High Pressure
 - Water Overflow
 - Water Shortage
 - Outside Temperature Failure
 - Temperature Sensor # Failure
 - Humidity Sensor Failure
 - Co2 Sensor Failure
 - Ammonia sensor failure
 - Pressure Sensor Failure
 - Potentiometer # Failure
 - Auxiliary # Activated
 - Alarm Test
 - Insufficient Air Supply
 - CPU Low Battery
 - Emergency Temperature

18.3 Water and Feed History

NOTE Water, auger, feeder relays or sensors must be enabled to see these screens.

1. Go to Flock > History > Water .
2. Click the relevant tab to see its history.

	Day	Water Per Bird		Daily Water		Water Per Feed	Water Meters		
		Intake	Gain %	Intake	Gain %		1	2	
🔔	6 31/01/2024	0 G	0 %	0 G	0 %	N/A	0 G	0 G	🕒 >
💧	5 30/01/2024	0 G	0 %	0 G	0 %	N/A	0 G	0 G	🕒 >
🕒	4 29/01/2024	0 G	0 %	0 G	0 %	N/A	N/A	N/A	🕒 >
🔔	3 28/01/2024	0 G	0 %	0 G	0 %	N/A	N/A	N/A	🕒 >
🔔	2 27/01/2024	0 G	0 %	0 G	0 %	N/A	N/A	N/A	🕒 >

NOTE Click the clock symbol to view the hourly breakdown.

18.4 Devices History

Records the heaters, cooling pad, and power meter devices run time (in minutes) for each growth day in 24H resolution. This information enables investigating and verifying if the runtime of a device performs as expected.

- Go to Flock > History > .

NEW pictures

	Heaters	Cooling	Power Meter
🔔	Day		Power Meter
🔔			Main
💧	2 01/02/2024		0
🕒	1 31/01/2024		0


- Click the clock symbol to view the hourly breakdown.

NOTE History displays installed devices only.


18.5 Bird Weight History


Trio provides the history of the average weight, daily gain, and uniformity. In addition, data from one or both scales is provided.

- Go to Flock > History >  .



Day	Average	Daily Gain	Uniformity
20 19/02/2024	0.093 Lb	0 Lb	0 %
12 11/02/2024	0.093 Lb	0 Lb	0 %
11 10/02/2024	0.093 Lb	0 Lb	0 %
10 09/02/2024	0.093 Lb	0 Lb	0 %
9 08/02/2024	0.093 Lb	0 Lb	0 %
8 07/02/2024	0.093 Lb	0 Lb	0 %

- Click  to view the bird scale data.



Scale	Average	No. of Weights
1	0.09 Lb	0

19 Resetting, Saving and Loading Settings, Updating Software

Resetting means erasing the tables and current product definitions. Once the settings have been erased, the user can manually reconfigure the Trio or load settings from a USB device.


- Resetting the Settings
- Resetting the Trio CPU and Sensor Connections
- Updating the Software
- Viewing the Log
- Updating the Software

19.1 Resetting the Settings


CAUTION Do not disconnect the power while resetting the unit. Any disconnection can cause severe hardware damage.


To reset the Trio:

1. Go to System > General Settings.



2. Click .



3. Click .
4. Follow the on-line instructions. You have the option of backing up the settings.

19.2 Resetting the Trio CPU and Sensor Connections

There are two ways to reset the Trio unit, depending on what is required.

- To reset the CPU and the user interface, press the button shown in Figure 7: CPU Reset Button.
- To reset the unit's connection to the sensors, press the button shown in Figure 8.




Figure 7: CPU Reset Button





Figure 8: Connection to Sensors Reset

19.3 Saving or Loading the Settings

1. Go to System > General Settings > .




2. Click Choose Operation and select Load Settings, Save Settings, or Delete File.

3. Follow the instructions.

NOTE In Choose Operation, you can also delete a backed-up file.

19.4 Viewing the Log

The log displays which tables were successfully saved.





19.5 Updating the Software

CAUTION Do not disconnect the power while resetting the unit. Any disconnection can cause severe hardware damage.

To update the Trio Software:

1. Go to System > General Settings.



2. Click .
3. In Software Version, click **Update**.
4. Follow the on-line instructions.

20 Warranty

Warranty and technical assistance

Munters products are designed and built to provide reliable and satisfactory performance but cannot be guaranteed free of faults; although they are reliable products they can develop unforeseeable defects and the user must take this into account and arrange adequate emergency or alarm systems if failure to operate could cause damage to the articles for which the Munters plant was required: if this is not done, the user is fully responsible for the damage which they could suffer.

Munters extends this limited warranty to the first purchaser and guarantees its products to be free from defects originating in manufacture or materials for one year from the date of delivery, provided that suitable transport, storage, installation and maintenance terms are complied with. The warranty does not apply if the products have been repaired without express authorisation from Munters, or repaired in such a way that, in Munters' judgement, their performance and reliability have been impaired, or incorrectly installed, or subjected to improper use. The user accepts total responsibility for incorrect use of the products.

The warranty on products from outside suppliers fitted to Trio, (for example antennas, power supplies, cables, etc.) is limited to the conditions stated by the supplier: all claims must be made in writing within eight days of the discovery of the defect and within 12 months of the delivery of the defective product. Munters has thirty days from the date of receipt in which to take action, and has the right to examine the product at the customer's premises or at its own plant (carriage cost to be borne by the customer).

Munters at its sole discretion has the option of replacing or repairing, free of charge, products which it considers defective, and will arrange for their despatch back to the customer carriage paid. In the case of faulty parts of small commercial value which are widely available (such as bolts, etc.) for urgent despatch, where the cost of carriage would exceed the value of the parts, Munters may authorise the customer exclusively to purchase the replacement parts locally; Munters will reimburse the value of the product at its cost price.

Munters will not be liable for costs incurred in demounting the defective part, or the time required to travel to site and the associated travel costs. No agent, employee or dealer is authorised to give any further guarantees or to accept any other liability on Munters' behalf in connection with other Munters products, except in writing with the signature of one of the Company's Managers.

WARNING: In the interests of improving the quality of its products and services, Munters reserves the right at any time and without prior notice to alter the specifications in this manual.

The liability of the manufacturer Munters ceases in the event of:

- dismantling the safety devices;
- use of unauthorised materials;

- inadequate maintenance;
- use of non-original spare parts and accessories.

Barring specific contractual terms, the following are directly at the user's expense:

- preparing installation sites;
- providing an electricity supply (including the protective equipotential bonding (PE) conductor, in accordance with CEI EN 60204-1, paragraph 8.2), for correctly connecting the equipment to the mains electricity supply;
- providing ancillary services appropriate to the requirements of the plant on the basis of the information supplied with regard to installation;
- tools and consumables required for fitting and installation;
- lubricants necessary for commissioning and maintenance.

It is mandatory to purchase and use only original spare parts or those recommended by the manufacturer.

Dismantling and assembly must be performed by qualified technicians and according to the manufacturer's instructions.

The use of non-original spare parts or incorrect assembly exonerates the manufacturer from all liability.

Requests for technical assistance and spare parts can be made directly to the nearest [Munters office](#).

