

Installation Manual

Trio 20 Poultry Controller



Trio 20

Poultry Controller

Ag/MIS/ImGb-2850-11/22 Rev 4.4
P/N: 116894



Trio 20 Poultry Controller

Installation Manual

Rev 4.4, 05/2026

Product Software: Version 9.0.20

This manual for use and maintenance is an integral part of the apparatus together with the attached technical documentation.

This document is destined for the user of the apparatus: it may not be reproduced in whole or in part, committed to computer memory as a file or delivered to third parties without the prior authorization of the assembler of the system.

Munters reserves the right to effect modifications to the apparatus in accordance with technical and legal developments.

Index

<i>Chapter</i>	<i>page</i>
1 INTRODUCTION.....	10
1.1 Disclaimer	10
1.2 Introduction	10
1.3 Notes	10
2 PRECAUTIONS.....	11
2.1 English.....	11
2.1.1 Infrastructure Protection and Backup	11
2.1.1.1 RPLP Power Line Protection.....	12
2.1.1.2 RIT-100 Isolated Transformer	12
2.1.1.3 TS-02 Timer	12
2.1.1.4 Controller Backup.....	13
2.1.2 Protection Against Corrosion.....	13
2.1.3 Electrical Guidelines.....	13
2.1.4 Grounding Sensors.....	13
2.1.5 Reducing Interference	13
2.1.6 Filtering.....	14
2.1.7 Checking the CMOS RTC Batteries Level	15
2.1.7.1 Display Board Battery	15
2.1.7.2 Main Board Battery.....	15
2.1.8 Safety Precautions - Details.....	15
2.1.9 Grounding the Controller.....	16
2.1.9.1 Ground Rods	16
2.1.9.2 Ground Wire.....	16
2.1.9.3 Ground Clamps	17
2.1.9.4 What Should Be Grounded?.....	17
2.2 Français.....	17
2.2.1 Protection et Redondance de L'infrastructure	17
2.2.1.1 Protection de la Ligne D'alimentation RPLP	18
2.2.1.2 Transformateur D'isolement RIT-100.....	18
2.2.1.3 Temporisateur TS-02.....	18
2.2.1.4 Contrôleur de Secours	19
2.2.2 Protection Contre la Corrosion	19
2.2.3 Directives Électriques	19
2.2.4 Raccord à la Terre (Sensores).....	20

2.2.5	Réduire les Interférences	20
2.2.6	Filtrage.....	20
2.2.7	Vérification du Niveau des piles CMOS RTC	21
2.2.7.1	Pile de la Carte D'affichage.....	21
2.2.7.2	Batterie de la Carte Mère	21
2.2.8	Précautions de Sécurité - Détails	21
2.2.9	Mise à la Terre du Contrôleur.....	22
2.2.9.1	Piquets de Prise de Terre.....	22
2.2.9.2	Fil de Garde	22
2.2.9.3	Colliers de Mise à la Terre	23
2.2.9.4	Quels Elements Doivent Etre Mis a la Terre?	23
2.3	Locking the Trio	24
2.4	Product Symbols.....	24
3	UNIT INSTALLATION.....	25
3.1	What Comes in the Package.....	25
3.2	Mounting the Unit.....	25
3.2.1	Knockouts.....	25
3.2.2	Hanging the Unit.....	26
3.3	Board Layout.....	27
3.4	Wiring Diagrams	30
3.4.1	High Voltage Relays.....	30
3.4.2	Alarms and Power	32
3.4.3	Internet Connection	33
3.4.4	Analog Output Devices	34
3.4.5	Digital Devices.....	35
3.4.6	Analog Input Devices.....	36
3.4.6.1	CO2 Sensor Wiring	36
3.4.6.2	Temperature Sensor Wiring.....	39
3.4.6.3	Humidity Sensor Wiring	41
3.4.6.4	Potentiometer Wiring	43
3.4.6.5	Ammonia Sensor Wiring	44
3.4.6.6	Light Sensor Wiring.....	45
3.4.7	Trio RPS	46
3.4.8	Bird Scale Card.....	48
3.4.9	Silo Wiring.....	50
3.4.10	RSU Wiring.....	52
3.4.11	RLED 2.0 Wiring.....	52
3.4.12	Batch Weighing.....	53
3.4.12.1	External Batch Bin Installation.....	53
3.4.12.2	Electronic Batch Weighing Installation.....	54
3.4.12.2.1	Wiring and Mapping.....	55

3.4.12.2.2	Batch Bin Calibration.....	59
3.5	Trio – RSU/RLED 2.0 Wiring Termination.....	61
3.6	Pressure Sensor Hoses.....	63
3.7	Tech Support.....	63
3.8	SIM Card Configuration.....	64
4	TRIOAIR.....	65
4.1	Access the App.....	65
4.2	Sign Up.....	65
4.3	Adding a Controller to a Farm During Installation	66
4.4	Offline Registration	68
5	SPECIFICATIONS.....	70
5.1	Trio Specifications.....	70
5.2	Specification Details.....	71
5.3	External Device Specifications	71
6	USING THE TRIO TOUCH SCREEN	73
7	MAPPING AND DEFINING THE INPUT OUTPUT DEVICES.....	75
7.1	Using the Mapping Screen	75
7.2	Editing the Relays and Sensors.....	78
7.3	Defining Sensors	78
7.3.1	Defining Analog Sensors.....	78
7.3.1.1	Enabling/Disabling Analog Input Sensors.....	79
7.3.1.2	Temperature Sensors.....	80
7.3.1.2.1	Defining the Temperature Sensors.....	80
7.3.1.2.2	Mapping the Temperature Sensors.....	80
7.3.1.2.3	Enabling a Weather Station	81
7.3.1.3	Defining the Ammonia Sensor	82
7.3.1.4	Defining the CO2 Sensor.....	82
7.3.1.5	Defining the Humidity Sensors	83
7.3.1.6	Defining the Light Sensor	83
7.3.2	Defining Digital Sensors.....	84
7.3.2.1	Defining the Water Meter Sensors.....	84
7.3.2.2	Defining the Gas Meter Sensors	85
7.3.2.3	Defining the Power Meter Sensors.....	85
7.3.2.4	Defining the Auger Active Sensors	86
7.3.2.5	Defining the Feeder Active Sensors.....	86
7.3.2.6	Defining the Auxiliary Input.....	87
7.4	Defining Devices.....	87
7.4.1	0 – 10 Volt Analog Output Devices.....	88
7.4.2	Defining the Fans.....	88
7.4.2.1	On-Off Fans	88

7.4.2.2	0 – 10 Volt Fans.....	89
7.4.3	Defining the Stir Fan	89
7.4.3.1	On Off Stir Fan	89
7.4.3.2	0 – 10 Volt Stir Fan	90
7.4.4	Defining the Blowback Fan.....	90
7.4.5	Heating Devices	91
7.4.5.1	Defining the On/Off Heaters.....	91
7.4.5.2	Defining the Variable Heaters	91
7.4.5.3	Defining the High Heaters.....	92
7.4.6	Defining the Cooling Pads	92
7.4.7	Defining the Foggers	93
7.4.8	Mapping the Potentiometers, Inlets, Tunnel Doors, Outlets.....	93
7.4.8.1	Mapping the Potentiometers	93
7.4.8.2	Defining the Inlets/Tunnel Doors.....	94
7.4.8.2.1	Potentiometer Calibration.....	95
7.4.8.2.2	Calibrating the Inlets/Tunnel Door.....	95
7.4.8.3	Defining the Outlet.....	97
7.4.9	Defining the Same As Relays	98
7.4.10	Defining the Same As Analog Ports	98
7.4.11	Defining the Timers.....	99
7.4.12	Lighting Devices.....	100
7.4.12.1	Defining the On/Off LIGHTS	100
7.4.12.2	Defining the Variable LIGHTS.....	100
7.4.12.3	Defining the RLED 2.0	101
7.4.13	Feeding Devices	102
7.4.13.1	Defining the Auger Relays	102
7.4.13.2	Defining the Feeder Relays.....	103
7.4.14	Fail Safe Devices	103
7.4.15	Water Pressure Devices.....	104
7.4.15.1	Defining the WOD	104
7.4.15.2	Defining the WOD Pro	105
7.4.15.3	WOD Pro Calibration	105
7.5	Mapping the Weighing Devices	106
7.5.1	Defining the Silos.....	107
7.5.1.1	Mapping the Silo Scales	107
7.5.1.2	Configuring the Silo Scale.....	109
7.5.1.3	Testing the Silo.....	113
7.5.2	Defining BinTrac Silos.....	114
7.5.3	Defining the Bird Scales	115
7.5.3.1	Mapping the Bird Scales.....	115
7.5.3.2	Calibrating the Bird Scales.....	116

7.5.3.3	Testing the Bird Scale	118
7.5.4	Defining the RSU.....	119
7.6	Trio RPS.....	120
7.6.1	Defining the Sensor	120
7.6.2	Static Pressure Calibration	120
7.7	Testing Devices.....	122
8	APPENDIX A: ALARM BACKUP BATTERY	125
8.1	General Description.....	125
8.2	Detailed Description.....	127
8.3	Preparing the Battery for Operation After Transportation or Storage.....	129
9	APPENDIX B: EXTERNAL DEVICES (PREVIOUS VERSIONS).....	130
10	APPENDIX C: SERVICE MANUAL	133
10.1	Maintenance.....	133
10.2	Trouble Shooting	134
10.2.1	Internet	134
10.2.2	Electronic Components	135
10.3	Spare Parts	136
10.3.1	Preliminary Information	136
10.3.2	Trio Minimal Spare Parts	137
10.3.2.1	Global Customers	137
10.3.2.2	Chinese Customers.....	137
10.3.3	Trio 20 Container Spare Parts.....	138
10.3.4	Trio 20 Door Card Spare Parts	140
10.3.5	Trio 20 Main Container Spare Parts.....	142
10.3.6	Additional Options	144
10.3.7	Cards	145
10.3.7.1	Door Cards	146
10.3.7.2	Main Container Cards	148
10.3.7.3	Door Set.....	150
11	APPENDIX D: TRIO EXPANSION.....	151
11.1	Introduction	151
11.2	Expansion 10	151
11.2.1	Expansion Layout.....	152
11.2.2	TRIO to TRIO 10 Expansion Wiring.....	153
11.2.2.1	Wiring.....	153
11.2.2.2	Address.....	154
11.2.2.3	Restart.....	154
11.2.3	High Voltage Relays.....	155
11.2.4	Power	156
11.3	Expansion 20.....	157

11.3.1	Expansion Layout.....	157
11.3.2	Expansion Wiring Diagrams	158
11.3.2.1	Wiring.....	158
11.3.2.2	Address.....	159
11.3.2.3	Restart.....	159
11.3.3	High Voltage Relays.....	160
11.3.4	Power	161
11.4	Mapping Devices in Expansion.....	162
11.5	Expansion Specifications.....	164
11.5.1	Expansion 10 Specifications.....	164
11.5.2	Expansion 20 Specifications.....	165
11.5.3	Expansion Specification Details	165
11.6	Expansion Spare Parts	166
11.6.1	Preliminary Information	166
11.6.2	Trio Expansion 10 Spare Parts.....	166
11.6.2.1	Trio Expansion 10 Container Spare Parts.....	167
11.6.2.2	Trio Expansion 10 Main Container Spare Parts	168
11.6.3	Trio Expansion 20 Spare Parts.....	169
11.6.3.1	Trio Expansion 20 Container Spare Parts	169
11.6.3.2	Trio Expansion 20 Main Container Spare Parts	171
11.6.4	Additional Options	172
11.6.5	Cards	172
12	APPENDIX E: TRIO CELL MODEM INSTALLATION	173
12.1	Prerequisites	173
12.1.1	Supported Devices	173
12.1.2	Required Software.....	173
12.1.3	Internet Access.....	173
12.2	Installation	174
12.2.1	Physical Installation	174
12.2.1.1	Modem and SIM Card.....	174
12.2.1.2	Driilling.....	177
12.2.2	Configuration.....	179
13	APPENDIX F: PANEL MOUNT INSTALLATION.....	182
13.1	Trio Panel Mount Installation	182
13.1.1	Precautions	182
13.1.2	Panels.....	183
13.1.3	Panel Dimensions	184
13.1.4	Mounting the Panels.....	185
13.1.5	Panel Cables	186
13.1.6	Powering and Alarms	187

- 13.1.7 Grounding187
- 13.2 Trio Expansion Panel Mount Installation 188
 - 13.2.1 Precautions 188
 - 13.2.2 Panels..... 189
 - 13.2.3 Panel Dimensions 190
 - 13.2.4 Panel Expansion Wiring192
 - 13.2.4.1 Wiring.....192
 - 13.2.4.2 Address.....193
 - 13.2.4.3 Restart.....193
 - 13.2.5 Power 194
- 14 APPENDIX G: IT SETUP..... 195
 - 14.1 IT Setup..... 195
 - 14.2 Subnet Setup 196
 - 14.2.1 Required Equipment 196
 - 14.2.2 Procedure 196
 - 14.3 LAN Cable Information.....197
 - 14.3.1 Wire/Optical Ethernet Infrastructure Basics.....197
 - 14.3.2 Trio Connectivity: 100/1000 GBPS Ethernet Switch.....197
 - 14.4 Typical Setups 198
- 15 INDEX.....201
- 16 WARRANTY 203

1 Introduction

1.1 Disclaimer

Munters reserves the right to make alterations to specifications, quantities, dimensions etc. for production or other reasons, subsequent to publication. The information contained herein has been prepared by qualified experts within Munters. While we believe the information is accurate and complete, we make no warranty or representation for any particular purposes. The information is offered in good faith and with the understanding that any use of the units or accessories in breach of the directions and warnings in this document is at the sole discretion and risk of the user.

1.2 Introduction

Congratulations on your excellent choice of purchasing a Trio Poultry Controller!

In order to realize the full benefit from this product it is important that it is installed, commissioned and operated correctly. Before installation or using the controller, this manual should be studied carefully. It is also recommended that it is kept safely for future reference. The manual is intended as a reference for installation, commissioning and day-to-day operation of the Munters Controllers.

1.3 Notes

Date of release: Jan 2020

Munters cannot guarantee to inform users about the changes or to distribute new manuals to them.

All rights reserved. No part of this manual may be reproduced in any manner whatsoever without the expressed written permission of Munters. The contents of this manual are subject to change without notice.

2 Precautions

- English
- Français
- Locking the Trio
- Product Symbols

2.1 English

CAUTION *Protection provided by the equipment can be impaired if the equipment is used in a manner not specified by the manufacturer!*

CAUTION *There is a risk of explosion if the controller's lithium battery is replaced with an incorrect type. Replace the battery using the same type and manufacturer only.*

- Infrastructure Protection and Backup
- Protection Against Corrosion
- Electrical Guidelines
- Grounding Sensors
- Reducing Interference
- Filtering
- Checking the CMOS RTC Batteries Level
- Safety Precautions - Details
- Grounding the Controller

2.1.1 INFRASTRUCTURE PROTECTION AND BACKUP

Electrical grid disturbances—including voltage spikes, transient power drops, line fluctuations, and instability—may result in physical damage to controllers if not adequately mitigated.

To prevent controller damage, in areas having known, repeated issues with electrical supply stability Munters requires installing a protection infrastructure consisting of the Munters RPLP, Munters RIT-100, and a Trumeter TS-02 timer. Installing these products are best industrial practice.




Figure 1: Electrical Protection Setup

- RPLP Power Line Protection
- RIT-100 Isolated Transformer
- TS-02 Timer
- Controller Backup

2.1.1.1 RPLP Power Line Protection

Install an RPLP-1 to provide lightning protection to the controllers as well as reducing noise. While no lightning protection is perfect, the RPLP-1 significantly enhances the reliability of built-in lightning protection. Refer to the RPLP-1 documentation for detailed wiring instructions and specifications.

NOTE Common surge protectors provide little additional protection and may trip unnecessarily.

- RPLP-1-V1 (115 Volt): P/N: 922-01-00001
- RPLP-1-V2 (230 Volt): P/N: 922-01-00002

2.1.1.2 RIT-100 Isolated Transformer

Electronic controllers can be damaged by disturbances in the power supply. Examples of disturbances include:

- Lightning strikes
- Power line spikes

Munters RIT-100 stabilizes incoming power, preventing spikes (very short (microseconds to milliseconds), sharp changes (positive or negative) in voltage). In addition, RIT-100 defends the controller against power surges or lightning strikes that run through a power line. Refer to the RIT-100 documentation for detailed wiring instructions and specifications.

- P/N: 922-02-00006 (RIT100-POU-230V-TO-230V-100VA or 115V-TO-115V-50VA)

2.1.1.3 TS-02 Timer

The Trumeter TS-02 timer blocks electrical input when the voltage drops below 120 VAC. After a delay of 10 seconds, the TS-02 reconnects the electrical system once the voltage rises above 150 VAC.

- P/N: TS02 – 240V AC / 24V AC/DC, ON-Delay, 1 C/O

2.1.1.4 Controller Backup

Munters strongly recommends that all controllers have a backup controller that operates during a primary controller failure or during extreme temperatures. The backup ensures animal survival in cases of extreme temperatures or power disruptions. The backup controller comes into play when:

- A general controller failure occurs, in this case the controller functions at the current operating temperature.
- House temperatures readings are higher than what is set for the thermostat.

In both situations, the backup controller sends out alarms and/or takes over basic operations.

Munters provides two different backup systems:

- USA/Canada: [RBU-27](#) and [RDT-5](#) (Double Phase)
- EMEA/Asia: [RBU-5](#) (Triple Phase)

2.1.2 PROTECTION AGAINST CORROSION

To prevent against corrosion of electrical components:

- Installation location: If possible, install the Trio in a well-ventilated area.
- Keep the Trio closed at all times when a litter or passel is present in the building. In situations where maintenance or repairs are required, close the controller when you finish the work.
- After running the cables through the knockouts, seal the holes with a silicon sealant. If you use silicon sealant with acetic acid cure, keep the controller open and ventilated until cured. Otherwise, the acetic acid will attack metal components, including circuitry.
- When splicing sensors to longer wires, ensure that the splice is **waterproof**. Use adhesive lined heat shrink (marine grade) to make waterproof connections.
- Use shielded wiring for low level signals. For buried wiring (building to building runs) use high grade jell filled cables that are impervious to moisture.

2.1.3 ELECTRICAL GUIDELINES

- If this unit is installed in an electrical closet, ensure that no contactors are in that closet. Placing this unit in proximity (50 centimeters/1.5 feet or less) to contactors results in severe signal interference.
- Review the guidelines given in the Precautions and Safety Precautions sections. These are vital to ensuring both personal safety and proper controller functioning.

2.1.4 GROUNDING SENSORS

- Every low power device (digital, analog, or communication) must have a shield cable connected to the unit ground strip.

2.1.5 REDUCING INTERFERENCE

- Avoid mixing high voltage wiring with sensor and low voltage wiring. There should be at least 3 feet/1 meter between sensor and electrical cables.

- Keep the controller as far as possible from heavy contactor boxes and other sources of electrical interference.
- Do not connect communication wire shields, which go from one house to another at both ends. Connect them at one end only. Connection at both ends can cause ground loop currents to flow, which reduce reliability.
- The communication COM wiring is not the shield wire! The COM, RX and TX wires must connect to each other at all controllers.
- Refer to Safety Precautions - Details, page 15 for more information.

2.1.6 FILTERING

If this installation includes a power inverter to drive variable speed fans, RLD, RVS-2, or any device that switches high electrical current, install an EMI filter in front of the device. Refer to the inverter documentation.

Frequency inverters can cause severe electrical and electromagnetic interference. Therefore, when employing a frequency inverter, it is critical that you carefully follow the manufacturer's installation instructions.

In particular verify:

- That the cable shielding between the inverter and any motor meets industry standards
- Proper grounding of the inverter's chassis and motor power cable
- Proper grounding of low voltage cable shield wire
- That the controller and inverter cables are kept in separate conduits or wire bundles




Figure 2: Filter Block Diagram

1. Controller
2. Inverter
3. Place the controller at least 1.5 feet/50 centimeters from the inverter.


2.1.7 CHECKING THE CMOS RTC BATTERIES LEVEL

- Display Board Battery
- Main Board Battery

2.1.7.1 Display Board Battery

On the Trio Controller Display Board (refer to Figure 11) is a CMOS Battery. This CMOS battery keeps the CPU's real-time clock running when the power is off.

Check the battery once a year. The output must be 2.7 volts (minimum). Authorized personnel only must replace the battery if the output is below the minimum required level or every five years. Use a RENATA-CR2450N battery only.

If the CMOS battery output is below the required minimum, an icon  appears on the touch screen and on the TrioAir app.

CAUTION *If the CMOS battery output is below the required minimum, in the event of a power failure the user will have to reset the time and date when power is reapplied.*

2.1.7.2 Main Board Battery

On the Trio Controller Main Board is a CMOS Battery. This battery is located behind the Scale Card (refer to Figure 9). This CMOS battery keeps the board's real-time clock running when the power is off.

Do not test this battery. If the CMOS battery output is below the required minimum, Trio sends an alarm to everyone on the contact list. In this event, an authorized technician must replace the battery with a RENATA-CR2450N battery only.

CAUTION *If the CMOS battery output is below the required minimum, in the event of a power failure the user will have to reset the time and date when power is reapplied.*

Warning: *It is very important to reset the growth date to the required day.*

2.1.8 SAFETY PRECAUTIONS - DETAILS

CAUTION *An authorized electrician must install these units. Disconnect the power to avoid electrical shock and damage.*

NOTE *Installation Category (Over voltage Category) II*

- The power supply to the controller should be protected by a 10 amp circuit breaker.
- All electrical connections should comply with National Electrical code (NEC).

2.1.9 GROUNDING THE CONTROLLER

- Ground Rods
- Ground Wire
- Ground Clamps
- What Should Be Grounded?

2.1.9.1 Ground Rods

Ground rods are used to efficiently connect the system to earth where current may be dissipated in the soil.

1. Material: Ground rods should be copper clad or galvanized steel.
2. Diameter: Minimum 5/8", preferably 3/4". Generally the larger the rod diameter, the lower it's resistance to current flow.
3. Length: Minimum 2.5 meters (8 feet), preferably 3-meter (10-foot). A longer ground rod will reach a soil with higher moisture content. Moist soil carries current much better than drier soil.
4. Single grounding: It is important that there is only one grounding location where a rod or series of rods are connected to each other using a ground wire.
5. Independent ground rods will increase the risk of current, from a lightning strike for example, being dissipated through one rod and reentering the system through an adjacent rod.
6. Location: Close to the main circuit breaker panel and in moist soil. For example in an area that is usually wet from a drip or a low spot where water drains. Make sure the area is well protected from damage by lawnmowers, tractors, etc.'
7. Rod installation: Drive the rod into the earth until about 10 cm (4 inches) is left above grade. If it is impossible to drive the rod to the proper depth, it is acceptable to lay the rod horizontally, 80 cm (2.5 feet) below grade.
8. In case the rod is exposed to damage, for example by lawnmowers or tractors it can be installed in a hole, about 20 cm (8 inches) deep so that the rod is about 10 cm under grade and 10 cm above hole level.

NOTE The National Electric Code (NEC) mandates two ground rods unless you can show less than 10 ohms resistance with one rod.

2.1.9.2 Ground Wire

The ground wire is a large copper wire that connects the main circuit breaker panel to the ground rod.

1. Material: Ground rods should be copper clad or galvanized steel.
2. Diameter: Typically, 16 mm (6-gauge) copper wire is sufficient. If the wire run is greater than 20 feet, 20 mm (4-gauge) wire should be used.
3. Length: Minimum 2.5 meters (8 feet), preferably 3-meter (10-foot). A longer ground rod will reach a soil with higher moisture content. Moist soil carries current much better than drier soil.
4. The ground wire should be protected from damage by lawnmowers, tractors, etc. It should be buried at a minimum of 15 cm (6 inches) under grade for protection and

enter the house as soon as possible. It is important that the wire not be cut; it should remain continuous.

2.1.9.3 Ground Clamps

Ground wires should not be merely wrapped around a ground rod. Ground clamps are used to attach a ground wire to a ground rod. The most common clamp is known as an acorn clamp. Make sure the ground clamps you select are rated for outdoor use. Do not use pipe clamps rated for inside water lines or hose clamps to attach the ground wire.

2.1.9.4 What Should Be Grounded?

Any equipment that is or could become energized, even accidentally, should be grounded. Current from lightning, strikes objects in a random fashion. Accounts of lightning strikes reveal scenarios most of us could not predict.

Electric circuits should be wired with a 3-wire conductor consisting of hot, neutral, and grounding wires. The grounding wire should be attached cleanly and securely to devices or systems to be grounded. The other end of the grounding wire should be attached to the ground bus on the main panel.

2.2 Français

- Protection et Redondance de L'infrastructure
- Protection Contre la Corrosion
- Directives Électriques
- Raccord à la Terre (Sensores)
- Réduire les Interférences
- Filtrage
- Vérification du Niveau des piles CMOS RTC
- Précautions de Sécurité - Détails
- Mise à la Terre du Contrôleur

CAUTION *La protection fournie par l'équipement peut être compromise si l'équipement est utilisé d'une façon non spécifiée par le fabricant !*

CAUTION *Risque d'explosion si la batterie au lithium du contrôleur est remplacée par un modèle inapproprié. Remplacez la batterie uniquement par une batterie du même type et du même fabricant.*

2.2.1 PROTECTION ET REDONDANCE DE L'INFRASTRUCTURE

Les perturbations du réseau électrique – y compris les surtensions, les chutes transitoires de tension, les fluctuations de ligne et l'instabilité – peuvent provoquer des dommages physiques aux contrôleurs si elles ne sont pas correctement atténuées.

Pour prévenir les dommages aux contrôleurs, dans les zones où la stabilité de l'alimentation électrique est connue pour poser des problèmes récurrents, Munters exige l'installation d'une infrastructure de protection composée du Munters RPLP, du Munters RIT-100 et d'un temporisateur Trumeter TS-02. L'installation de ces produits constitue une bonne pratique industrielle.




Illustration 3: Configuration de la protection électrique

- Protection de la Ligne D'alimentation RPLP
- Transformateur D'isolement RIT-100
- Temporisateur TS-02
- Contrôleur de Secours

2.2.1.1 Protection de la Ligne D'alimentation RPLP

Installez un RPLP-1 pour assurer une protection contre la foudre des contrôleurs ainsi que pour réduire les parasites. Bien qu'aucune protection contre la foudre ne soit parfaite, le RPLP-1 améliore considérablement la fiabilité de la protection intégrée. Reportez-vous à la documentation du RPLP-1 pour les instructions de câblage détaillées et les spécifications.

REMARQUE Les parasurtenseurs courants offrent peu de protection supplémentaire et peuvent se déclencher inutilement.

- RPLP-1-V2 (230 V): P/N: 922-01-00006

2.2.1.2 Transformateur D'isolement RIT-100

Les contrôleurs électroniques peuvent être endommagés par des perturbations de l'alimentation électrique. Exemples de perturbations:

- Impacts de foudre
- Pics de tension sur la ligne d'alimentation

Le Munters RIT-100 stabilise l'alimentation entrante, en empêchant les pics (variations très brèves – microsecondes à millisecondes – et abruptes, positives ou négatives, de la tension). En outre, le RIT-100 protège le contrôleur contre les surtensions ou les impacts de foudre se propageant via la ligne d'alimentation. Reportez-vous à la documentation du RIT-100 pour les instructions de câblage détaillées et les spécifications.

- P/N: 922-02-00006 (RIT100-POU-230V-TO-230V-100VA ou 115V-TO-115V-50VA)

2.2.1.3 Temporisateur TS-02

Le temporisateur Trumeter TS-02 bloque l'entrée électrique lorsque la tension chute en dessous de 120 VAC. Après un délai de 10 secondes, le TS-02 rétablit l'alimentation une fois la tension remontée au-dessus de 150 VAC.

- P/N: TS02 – 240 V AC / 24 V AC/DC, retard à l'enclenchement (ON-Delay), 1 contact inverseur (1 C/O)

2.2.1.4 Contrôleur de Secours

Munters recommande fortement que tous les contrôleurs disposent d'un contrôleur de secours qui prenne le relais en cas de défaillance du contrôleur principal ou de températures extrêmes. Le système de secours garantit la survie des porcs en cas de températures extrêmes ou de perturbations de l'alimentation électrique. Le contrôleur de secours intervient lorsque:

- Une défaillance générale du contrôleur se produit ; dans ce cas, le contrôleur fonctionne à la température de fonctionnement actuelle.
- Les relevés de température du bâtiment sont supérieurs à la consigne du thermostat.

Dans les deux cas, le contrôleur de secours émet des alarmes et/ou prend en charge les opérations de base.

Munters propose deux systèmes de secours différents:

- USA/Canada: [RBU-27](#) et [RDT-5](#)
- EMEA/Asie: [RBU-5](#)

2.2.2 PROTECTION CONTRE LA CORROSION

Pour éviter la corrosion des composants électriques:

- Installez les commandes électroniques dans une salle de commande ventilée séparée, à l'abri des températures extrêmes et des environnements sales. Placer les commandes de façon à ce que les opérateurs puissent facilement les utiliser et lire les indicateurs et les affichages.
- Gardez le contrôleur fermé à tout moment lorsqu'il y a de la poubelle ou un passage dans le bâtiment. Dans les situations nécessitant une maintenance ou des réparations, fermez le contrôleur lorsque vous avez terminé le travail.
- Après avoir acheminé les câbles à travers les ouvertures, scellez les trous avec un produit d'étanchéité au silicone. Si vous utilisez un mastic de silicone avec durcissement à l'acide acétique, maintenez le contrôleur ouvert et ventilé jusqu'à ce qu'il durcisse. Sinon, l'acide acétique attaquera les composants métalliques, y compris les circuits.
- Lors du raccordement de capteurs à des câbles plus longs, assurez-vous que le raccordement est étanche. Utilisez une gaine thermorétractable adhésive (qualité marine) pour réaliser des connexions étanches.
- Utilisez un câblage blindé pour les signaux de faible niveau. Pour les câbles enterrés (d'un bâtiment à l'autre), utilisez des câbles remplis de gel de haute qualité, imperméables à l'humidité.

2.2.3 DIRECTIVES ÉLECTRIQUES

- Munters recommande vivement que seuls les contrôleurs montés sur panneau soient installés directement dans une armoire électrique.
- Placer cette unité à proximité (50 centimètres/1,5 pieds maximum) de tout appareil électrique transmettant 10 ampères ou plus de courant peut entraîner de graves interférences de signal.

- Consulter les consignes données dans Précautions de Sécurité - Détails, page 21 pour plus de détails. Elles sont essentielles pour garantir à la fois la sécurité personnelle et le bon fonctionnement du contrôleur.

2.2.4 RACCORD À LA TERRE (SENSORES)

- Chaque appareil à faible puissance (numérique, analogique ou de communication) doit être équipé d'un câble blindé raccordé à la barrette de mise à la terre de l'unité.

2.2.5 RÉDUIRE LES INTERFÉRENCES

- Maintenez les câbles basse tension séparés des câbles haute tension. Il doit y avoir au moins un mètre entre le capteur et les câbles électriques.
- Maintenez le contrôleur aussi loin que possible du boîtier lourd de contacteur et des autres sources d'interférences électriques.
- Ne connectez les protections des fils de communication, allant d'une maison à une autre aux deux extrémités. Connectez-les à une seule extrémité uniquement. La connexion aux deux extrémités peut entraîner la circulation de courants dans la boucle de terre, et risquer ainsi de réduire la fiabilité.
- La connexion COM pour les communications n'est pas le fil blindé. Les fils COM, RX et TX doivent être connectés les uns aux autres au niveau de tous les contrôleurs.

2.2.6 FILTRAGE

Si cette installation comprend un onduleur pour entraîner des ventilateurs à vitesse variable, RLD, RVS-2 ou tout autre dispositif qui commute un courant électrique élevé, installez un filtre EMI devant l'appareil. Reportez-vous à la documentation de l'appareil.

- Que le blindage du câble entre l'appareil et tout moteur est conforme aux normes industrielles
- Mise à la terre correcte du châssis de l'appareil et du câble d'alimentation du moteur
- Mise à la terre correcte du fil blindé du câble basse tension
- Que les câbles du contrôleur et de l'appareil sont conservés dans des conduits ou faisceaux de câbles séparés




Illustration 4: Emplacement de l'onduleur

1. Contrôleur
2. Dispositif de courant électrique élevé
3. Placez le contrôleur à au moins 50 centimètres de l'appareil


2.2.7 VÉRIFICATION DU NIVEAU DES PILES CMOS RTC

- Pile de la Carte D'affichage
- Batterie de la Carte Mère

2.2.7.1 Pile de la Carte D'affichage

La carte d'affichage Trio (voir Utilisation de l'écran tactile Trio) est équipée d'une pile CMOS. Cette pile CMOS permet à l'horloge temps réel du processeur de continuer à fonctionner lorsque l'appareil est hors tension.

Vérifiez la batterie une fois par an. La tension doit être de 2,7 volts (minimum). Seul le personnel autorisé doit remplacer la batterie si la tension est inférieure au niveau minimum requis ou tous les cinq ans. Utilisez uniquement une batterie RENATA-CR2450N.

Si la tension de la batterie CMOS est inférieure au minimum requis, une icône  apparaît sur l'écran tactile et dans l'application TrioAir.

CAUTION *ATTENTION Si la tension de la batterie CMOS est inférieure au minimum requis, en cas de panne de courant, l'utilisateur devra réinitialiser l'heure et la date lorsque le courant sera rétabli.*

2.2.7.2 Batterie de la Carte Mère

La carte mère Trio est équipée d'une batterie CMOS. Cette batterie est située derrière la carte de pesée (voir figure 7). Cette batterie CMOS permet à l'horloge en temps réel de la carte de continuer à fonctionner lorsque l'appareil est hors tension.

Ne testez pas cette batterie. Si la sortie de la batterie CMOS est inférieure au minimum requis, Trio envoie une alarme à toutes les personnes figurant sur la liste de contacts. Dans ce cas, un technicien agréé doit remplacer la batterie par une batterie RENATA-CR2450N uniquement.

CAUTION *ATTENTION Si la tension de la batterie CMOS est inférieure au minimum requis, en cas de panne de courant, l'utilisateur devra réinitialiser l'heure et la date lorsque le courant sera rétabli.*

WARNING! *Avertissement: il est très important de réinitialiser la date de croissance au jour requis.*

2.2.8 PRÉCAUTIONS DE SÉCURITÉ - DÉTAILS

NOTE *Catégorie d'installation (catégorie de surtension) II*

- L'alimentation électrique du contrôleur doit être protégée par un disjoncteur de 10 A.
- Tous les raccordements électriques doivent être conformes au National Electrical Code (NEC)

2.2.9 MISE À LA TERRE DU CONTRÔLEUR

- Piquets de Prise de Terre
- Fil de Garde
- Colliers de Mise à la Terre
- Quels Elements Doivent Etre Mis a la Terre?

2.2.9.1 Piquets de Prise de Terre

Les piquets de prise de terre sont utilisés pour connecter efficacement le système à la terre, lorsque le courant peut être dissipé dans le sol.

1. Matériel: Les piquets de prise de terre doivent être plaqués cuivre ou en acier galvanisé.
2. Diamètre: Minimum 12,5/20,3 cm, de préférence 7,6/10,16 cm. Généralement, plus le diamètre du piquet est gros, moindre sera sa résistance à la circulation du courant.
3. Longueur: Au minimum 2,5 mètres, de préférence 3 mètres. Un piquet de prise de terre plus long atteindra un sol avec une humidité plus élevée. Des sols humides portent beaucoup mieux le courant que des sols plus secs.
4. Mise à la terre unique: Il est essentiel qu'il n'y ait qu'un seul emplacement de mise à la terre auquel un piquet ou une série de piquets sont connectés les uns aux autres à l'aide d'un fil de garde.
5. Des piquets de prise de terre indépendants augmenteraient le risque de courant, provenant par exemple d'un éclair, dissipé par un piquet et réintégrant le système par un piquet adjacent.
6. Emplacement: Prêt du panneau de disjoncteur principal et dans un sol humide. Par exemple, dans une zone qui est habituellement humide provenant de précipitation, ou un point bas où l'eau est drainée. Assurez-vous que la zone est bien protégée des dommages pouvant être causés par des tondeuses à gazon, des tracteurs, etc.
7. Installation du piquet: Enfoncez le piquet dans le sol jusqu'à ce qu'il reste 10 cm au dessus du niveau du sol. S'il est impossible d'enfoncer le piquet à une profondeur correcte, vous pouvez poser le piquet horizontalement, 80 cm en dessous du niveau du sol.
8. Dans le cas où le piquet risque d'être endommagé, par exemple, par des tondeuses à gazon ou des tracteurs, il peut être installé dans un trou, à une profondeur d'environ 20 cm pour que le piquet soit environ 10 cm en dessous du niveau du sol et 10 cm au dessus du niveau du trou.

NOTE Le National Electric Code (NEC) a comme impératif l'utilisation de deux piquets de prise de terre, à moins que vous puissiez montrer que la résistance est inférieure à 10 ohms avec un piquet.

2.2.9.2 Fil de Garde

Le fil de garde est un fil cuivré long et épais qui connecte le panneau du disjoncteur principal au piquet de prise de terre.

1. Matériel: Les piquets de prise de terre doivent être plaqués cuivre ou en acier galvanisé.

2. Diamètre: Généralement un fil cuivré de 16 mm (de calibre no. 6) suffit. Si le fil doit parcourir plus de 7m, un fil de 20 mm (de calibre no.4) devrait être utilisé.
3. Longueur: Au minimum 2,5 mètre, de préférence 3 mètres. Un piquet de prise de terre plus long atteindra un sol avec une humidité plus élevée. Des sols humides portent beaucoup mieux le courant que des sols plus secs.
4. Le fil de garde devrait être protégé des dommages pouvant être provoqués par des tondeuses à gazon, des tracteurs, etc. Il devrait être enterré au moins à 15 cm sous le sol pour protection, et être inséré dans la maison aussi vite que possible. Il est important que le fil ne soit pas coupé, il devrait rester entier.

2.2.9.3 Colliers de Mise à la Terre

Des fils de gardes ne devraient pas simplement revêtir un piquet de prise de terre. Des colliers de mise à terre sont utilisés pour attacher un fil de garde au piquet de prise de terre. Le collier le plus ordinaire est un collier ocre. Assurez-vous que les colliers de mise à terre que vous sélectionnez sont adaptés à une utilisation à l'extérieur. N'utilisez pas de collier de serrage adapté pour des conduites d'eau intérieures ou colliers de serrage pour tuyaux flexibles pour rattacher le fil de garde.

2.2.9.4 Quels Elements Doivent Etre Mis a la Terre?

Tout équipement qui est ou pourrait être sous tension, même accidentellement, devrait être mis à la terre. Les objets qui pourraient être aléatoirement porteurs de la foudre y sont inclus. Des récits de foudre ont montré des cas imprévisibles.

Les circuits électriques devraient être câblés avec un conducteur à 3 fils, constitué d'un fil de garde, d'un fil conducteur neutre et d'un fil chaud. Le fil de garde devrait être rattaché nettement et sûrement aux dispositifs ou aux systèmes à mettre à la terre. L'autre extrémité du fil de garde devrait être rattachée au collecteur de terre sur le panneau principal.

2.3 Locking the Trio

Ensure that the units remains locked to prevent unauthorized access to internal components.




Figure 5: Trio Lock

2.4 Product Symbols

The following labels appear on your controller:



: Caution! Hazardous voltage



: Caution: Refer to the manual



: Main Protective Earthing Terminal

CAUTION IF THE UNIT IS USED IN A MANNER NOT SPECIFIED BY THE MANUFACTURER, THE PROTECTION PROVIDED BY THE EQUIPMENT MAY BE IMPAIRED.

3 Unit Installation

The following sections detail how to mount and wire the Trio.

NOTE Munters recommends that a trained technician perform the following operations.

- What Comes in the Package
- Mounting the Unit
- Board Layout
- Wiring Diagrams
- Trio – RSU/RLED 2.0 Wiring Termination
- Pressure Sensor Hoses
- Tech Support
- SIM Card Configuration

3.1 What Comes in the Package

- One Trio unit
- One hanging bracket and screws
- Two keys
- RTS-2 sensors (number depending on order)

3.2 Mounting the Unit

- Knockouts
- Hanging the Unit

3.2.1 KNOCKOUTS

1. At the bottom the Trio are knockouts used to route the low and high voltage cables.




Figure 6: Trio Knockouts and PG Size

- Using a screwdriver and a hammer, gently apply pressure to the knockouts.
- **Only open up the holes that you require.**
- Munters recommends removing the knockouts before mounting the unit.
- 16*: Use this knockout for the Ethernet cable.

2. Place the required cables through the cable holders at the bottom of the unit.

CAUTION Run low voltage cables through one knockout and high voltage relay cables through a separate knockout. Do not place them in the same knockout!

3.2.2 HANGING THE UNIT

1. Attach the bracket to the wall (customer supplies the screws).




Figure 7: Hanging the Bracket

2. Hang the Trio on the bracket.




Figure 8: Hanging the Unit

3. Close the TRIO enclosure lid carefully and tightly. Use RTV silicon or equivalent sealant to seal the cable holders.

CAUTION Munters strongly recommends that you seal all entry spots with RTV silicon. Failure to do so can lead to damage to the unit.

4. After installation is completed, operate the TRIO for a few hours and re-check for proper operation.

3.3 Board Layout




Figure 9: Main Board layout

1	Analog/digital ports	6	Dipswitches
2	Ground strip	7	Scale Card (option) (CMOS battery is under the card)
3	20 relays	8	Pressure Sensor
4	Alarm relay	9	Power Supply
5	Power ports		



Figure 10: Dipswitches, expanded

- One dipswitch only in each set is raised.
- Only raise a dipswitch if a device is wired to an S port.




Figure 11: Display Board layout, Display Card Version 1.1.0

1	Wireless antenna
2	SD Port
3	Ethernet Port
4	Heat Sink
5	3V Battery
6	Modem
7	USB Port
8	Reset Button
9	Backup Battery (refer to Appendix A: Alarm Backup Battery, page 125)




Figure 12: Display Board layout, Display Card Version 1.0.4

1	Wireless antenna
2	SIM Port
3	SD Port
4	Ethernet Port
5	Heat Sink
6	3V Battery
7	Modem

NOTE There is no functional difference between Versions 1.0.4 and 1.1.0. All future versions will support both cards.

3.4 Wiring Diagrams

- High Voltage Relays
- Alarms and Power
- Internet Connection
- Analog Output Devices
- Digital Devices
- Analog Input Devices
- Trio RPS
- Bird Scale Card
- Silo Wiring
- RSU Wiring
- RLED 2.0 Wiring
- Batch Weighing

NOTE After physically installing and connecting the external input/output devices, perform a Cold Start (System > General Settings > About > Reset Factory Default). Map the devices after the Cold Start.

3.4.1 HIGH VOLTAGE RELAYS




Figure 13: High voltage devices (examples)

1	Example of devices
---	--------------------

NOTE The relays control motors and heating devices via contactors, not directly.




Figure 14: Relay Wiring Detailed View




Figure 15: Relay and Port Numbering

3.4.2 ALARMS AND POWER




Figure 16: Alarm relay and power ports

1	Alarm relay
2	Power ports

- Connect the light or siren device to the alarm relay.
- Input power can be up to one (1) amp/240 VAC.

NOTE The alarm power source can be AC or DC. The above illustration is an example only.

3.4.3 INTERNET CONNECTION




Figure 17: Ethernet port, Display Card Versions 1.0.4 and 1.1.0

CAUTION Connect the internet cable to port 2. Do not connect the cable to port 1.

1	Internal port (do not use this port)
2	Ethernet port
3	RJ-45 cable

3.4.4 ANALOG OUTPUT DEVICES

Trio supports analog control over a variety of devices.




Figure 18: Analog Output devices (examples)




Figure 19: Light Dimmer devices

- Connect analog output devices to an AO and a COM port. Ground these devices!




Figure 20: Analog Device Wiring Schematic

3.4.5 DIGITAL DEVICES

Trio supports a variety of digital inputs.




Figure 21: Digital Input devices (example)

- Connect digital devices to a D port and a DCOM port. Ground these devices!




Figure 22: Digital Device Wiring Schematic

3.4.6 ANALOG INPUT DEVICES

- CO2 Sensor Wiring
- Temperature Sensor Wiring
- Humidity Sensor Wiring
- Potentiometer Wiring
- Ammonia Sensor Wiring
- Light Sensor Wiring

CAUTION These devices must be wired to a COM port, not a DCOM port.

3.4.6.1 CO2 Sensor Wiring

Refer to the [CO2 Sensor Manual](#) for details on installing this unit.




Figure 23: CO2 Sensor Wiring (P/N: 913-03-XXXXX)

Number	Function
1	Red wire: +12V
2	Black wire: -12V (Sig COM)
3	S port
4	COM port
5	Shield wire
Power Supply	
6	Brown wire: phase
7	Blue wire: neutral

CAUTION Connect the shield to the safety ground.




Figure 24: CO2 Sensor Wiring (P/N: 913-01-XXXXX)

Number	Function
1	S port
2	COM port
3	Shield wire
Power Supply	
4	COM port Brown wire: phase
5	Shield wire Blue wire: neutral
6	Red wire: +12V
7	Black wire: -12V (Sig COM)

CAUTION Connect the shield to the safety ground.




Figure 25: CO2 Sensor Wiring Schematic

- Connect the CO2 device to:
 - Controller:
 - S port. In the corresponding dipswitch, raise dipswitch 4 (4-20 mA).
 - COM port
 - Grounding strip!
 - Power supply
 - +12V
 - -12V

3.4.6.2 Temperature Sensor Wiring

Refer to the [RTS-2 Manual](#) for details on this sensor.




Figure 26: RTS-2 Wiring

Number	Function
1	COM port (black wire)
2	T port (red wire)




Figure 27: RTS Wiring Schematic

- Connect each RTS sensor to a:
 - T port
 - COM port
 - Grounding strip!
- Note:
 - Wire all designated T ports before wiring the RTS sensors to the S ports.
 - Connect the black wire to a COM port, not a DCOM port.




Figure 28: RTS S Port Wiring

Number	Function
2	COM port (black wire)
3	S port (red wire)




Figure 29: RTS S Port Wiring Schematic

- Connect each RTS sensor to a:
 - S port. In the corresponding dipswitch, raise dipswitch 1 (temp)
 - COM port
 - Grounding strip!
- Note:
 - Wire all designated T ports before wiring the RTS sensors to the S ports.
 - Connect the black wire to a COM port, not a DCOM port.

3.4.6.3 Humidity Sensor Wiring




Figure 30: RHS+ Wiring




Figure 31: RHS Pro Wiring

Number	Function
1	COM port (black wire)
2	12V (red wire)
3	S port (white wire)
4	Shield wire




Figure 32: RHS+/Pro Sensor Wiring Schematic

- Connect each RHS+/Pro sensor to a:
 - S port. In the corresponding dipswitch, raise dipswitch 3 (analog input).
 - COM port.
 - 12VDC port.
 - Grounding strip!

3.4.6.4 Potentiometer Wiring




Figure 33: Potentiometer Wiring




Figure 34: Potentiometer Wiring Schematic

- Connect each potentiometer to a:
 - S port. In the corresponding dipswitch, raise dipswitch 2 (potentiometer).
 - COM port.
 - 3.3V port.
 - Grounding strip!
- Test the potentiometer. Refer to Potentiometer, page 123.

3.4.6.5 Ammonia Sensor Wiring

Refer to the [Ammonia Sensor manual](#) for further information.




Figure 35: Ammonia Sensor Wiring

No.	Function
1	COM port (Green wire)
2	S port (Brown wire)
3	White wire
4	Phase (Brown wire)
5	Neutral (Blue wire)
6	18-30VDC (Red wire)
7	COM (Black wire)
8	20.3 kohm resistor (Note: The resistor comes supplied with the sensor but must be installed on-site)
9	Quick connector




Figure 36: Ammonia Wiring Schematic

- Connect an ammonia sensor to a:
 - S port. In the corresponding dipswitch, raise dipswitch 3 (analog input).
 - COM port.
 - Grounding strip!

3.4.6.6 Light Sensor Wiring

Refer to the [RLS Manual](#) for more information.




Figure 37: Light Sensor Wiring

Number	Function
1	S port (black wire)
2	12V (red wire)
3	Shield wire

- Connect each RLS sensor to a:
 - S port. In the corresponding dipswitch, raise dipswitch 4 (4 -20 mA).
 - 12VDC port.
 - Grounding strip!




Figure 38: RLS Wiring Schematic

3.4.7 TRIO RPS

Trio RPS serves as a second static pressure sensor for the Trio Controller. The following section details the installation. Trio supports up to two static pressure sensors; one built in and one external. Install the RPS in the second house.




Figure 39: RPS Wiring

Number	Function
1	S port. Raise the corresponding S3 dipswitch.
2	COM port
3	12V
4	Shield wire




Figure 40: RPS Wiring Schematic




Figure 41: Static pressure tubes

NOTE After installing the RPS, no Cold Start is required.

3.4.8 BIRD SCALE CARD

If you install a scale card, perform a cold start. Refer to the User Manual.




Figure 42: Scale Card wiring to Power Supply and Bird Scale

Number	Function
1	Black wire, -5V
2	Green wire, +5V
3	Red, Channel 1 - 6
4	White, Channel 1 - 6
5	COM

NOTE Connect each RBS-1 white and red wire to matching RSC ports; for example White Ch.1 and Red Ch. 1.




Figure 43: RSC Card to Silo Power Supply/RBS-1 Schematic

RJB Wire	RSC Ports	
Green	2, 5, 8 (Upper)	
Black	2, 5, 8 (Lower)	
White	3, 4, 6, 7, 9, 10 (Upper)	Note: Connect each RJB white and red wire to matching ports. For example White Ch.1 and Red Ch.1

3.4.9 SILO WIRING

Wire the Trio to an RJB Junction Box and power supply. For details on how to wire the Junction Box to the load cells, refer to the RJB manual.




Figure 44: Scale Card Wiring to Power Supply and RJB-6

NOTE Connect each RJB-6 white and red wire to matching RSC ports; for example White Ch.1 and Red Ch. 1.

Number	Function
1	Black wire, -5V
2	Green wire, +5V
3	Red, Channel 1 - 6
4	White, Channel 1 - 6
5	COM




Figure 45: RSC Card to Silo Power Supply/RJB-6 Schematic

RJB Wire	RSC Ports	
Green	2, 5, 8 (Upper)	
Black	2, 5, 8 (Lower)	
White	3, 4, 6, 7, 9, 10 (Upper)	Note: Connect each RJB white and red wire to matching ports. For example White Ch.1 and Red Ch.1
Red	3, 4, 6, 7, 9, 10 (Lower)	

3.4.10 RSU WIRING

Refer to the [RSU Manual](#) for further information.




Figure 46: Trio – RSU Wiring

3.4.11 RLED 2.0 WIRING




Figure 47: Trio – RLED 2.0 Wiring




Figure 48 : Trio – RLED 2.0 Schematic

3.4.12 BATCH WEIGHING

- External Batch Bin Installation
- Electronic Batch Weighing Installation

3.4.12.1 External Batch Bin Installation

➤ Map and define cross augers in Devices and Sensors.

Every time feed is placed into the batch weigher, Trio receives a pulse. Each pulse corresponds to a quantity of feed. The mix is generated by defining the quantities (meaning, the number of pulses) of different type of feed to be added.

➤ Connect the batch counter to a digital input port.




Figure 49: Digital Counter Wiring

1. In System > Devices and Sensor > Installation > Sensors define one digital port as Batch Counter.

Batch Counter 1

QTY/Pulse 1 Kg

TEST

2. Define:

- Qty/Pulse: Define the quantity of feed per pulse (designate the quantity as metric or imperial; refer to the User Manual). This quantity must match the quantities defined in the external controller.
- Click Test to ensure that the Trio connection to the batch counter is operating.

NOTE When delivering feed via an external batch bin, no silo data (inventory) is provided.

3.4.12.2 Electronic Batch Weighing Installation

- Wiring and Mapping
- Batch Bin Calibration

3.4.12.2.1 Wiring and Mapping

➡ Wire the scale card to the hopper.




Figure 50: Scale Card Wiring

1	White wire	5	Blue wire
2	Green wire	6	Brown wire
3	Red wire	7	Trio relay ports
4	Black wire		

1. In System > Devices and Sensors > Installation > Scale, designate one scale port as Batch Weigher.




2. Define:

- Bin Capacity: Define the batch bin's capacity. Refer to the User Manual to define the units as imperial or metric. This parameter is used to determine the gain (refer to Calibration). This quantity is not related to the actual batch quantity.
- Clicking Test shows the following values:
 - Measured weight
 - Real time A/D
 - Error status
- Calibrate the weigher. Refer to Batch Bin Calibration, page 59.

NOTE Once the bin capacity is defined, any change will require recalibrating the batch weigher.

3. In System > Devices & Sensors > Installation > Scales define up to three relays as Silos.



4. Define:

- Storage Capacity: Define the capacity of the silo mapped to this auger (Silo Auger 1 – Silo 1, etc.).

NOTE This parameter is hidden when Silo Weight is used to manage the feed inventory.

5. In System > Devices & Sensors > Installation, define up to three relays as Silo Augers.




6. Define:

- Default Output: Define the relay’s default state, normally open or normally closed.
- Feed Per Minute: Define the amount of feed per minute that the silo auger sends to the batch weigher.

- Silo Capacity: Enter the silo’s capacity in kilograms or pounds. The controller uses this value to manage the silo inventory.


7. In System > Devices & Sensors > Installation, define one digital port as Batch Hopper Limit. This sensor (placed in the bin) stops feed delivery when the feed level reaches the sensor.



8. Define the Active State.

- Open: The circuit is open when the sensor is activated.
- Closed: The circuit is closed when the sensor is activated.

9. In System > Devices and Sensors > Installation, define one relay as Batch Release Valve. This relay opens the batch bin, releasing mixed feed into a hopper.




10. Define:

- Default Output: Normally open or normally close.
- Seconds to close Valve: Define the amount of time required for the release valve to go from opened to closed. Range: 0 – 255. Default 10.
- Test checks the relay functionality.


NOTE Testing stops the weigher process.

3.4.12.2.2 Batch Bin Calibration

1. On the Batch Weigher sensor screen, click **Calibrate**.




2. In the following screen, enter the bin capacity (the weight of the bin when empty, shown in the previous screen). Click **Next**.




CAUTION When you press Next, the batch weigher bin opens and any feed in the weigher spills out!

3. In the following screen, place a weight (between 1 – 10 kilograms/2 – 22 pounds) and enter the gain. Click Next.



The following screen appears.



3.5 Trio – RSU/RLED 2.0 Wiring Termination

Termination, installing or enabling 120-ohm termination resistors at the beginning and end units of a chain, ensures reliable communication in RS-485 infrastructures.

Termination is recommended when the distance between Trio and the final device in the chain is more than 50 meters/165 feet. Trio and Trio Expansion come with a switch to enable termination; an external resistor must be installed on the RSU communication card. Termination may not be required in shorter installations.




Figure 51: Termination Sample Topologies




Figure 52: Termination Switch




Figure 53: RLED 2 Termination Wiring

3.6 Pressure Sensor Hoses







Figure 54: Static pressure hoses

3.7 Tech Support

To view your unit’s network information go to System > General Settings > Network . You will need this information when speaking with technical support.



- Click Manage.



- Ethernet fields are read-only information.
- Enable Wi-Fi if required.

3.8 SIM Card Configuration

Trio units come equipped with a modem (including a SIM card and antenna). As an option, a unit can come without a modem.

- The Trio modem's SIM card is a global SIM. No configuration is required because the SIM will find the relevant ISP.
- The connection to the Cloud is prioritized: 1) LAN 2) Wi-Fi 3) Cell-modem. The cell-modem connection is active only if the LAN or Wi-Fi are not available.

The SIM card supports three levels of connectivity to the TrioAir application:

- Free: Users subscribed to TrioAir's free plan can register the unit for free. No data plan is required.
- Alarms: Users subscribed to the TrioAir alarm function receive alarms in real-time.
- Data plan: Users can subscribe to the TrioAir Premium access plan, enabling modem access to the TrioAir cloud.

CAUTION By default, the cell modem is enabled.

4 TrioAir

TrioAir is the Munters (desktop and cellphone) app that gives users remote access to their controllers. Trio Controllers are connected directly to the internet via a standard modem. Trio Air is the application used to manage your controllers via the web. In addition to seamless access to your Trio Controllers, Trio Air also offers:

- Remote control and configuration
- Centralized dashboard used to easily compare farms and their controllers.
- Real-time alarms and notifications
- Various levels of access control

There are four basic steps in setting up TrioAir.

- Access the App
- Sign Up
- Creating and Managing a Farm
- Adding Controllers to Farms

The following sections give basic information on signing up for Trio Air and adding controllers to the system. For more information, refer to the [Munters Zendesk](#).

4.1 Access the App

The first step in using TrioAir is to access the application, either on your PC or your cellphone.

- [Desktop App](#)
- [Cellphone App](#)


Users wanting to use TrioAir on their computer, go to <https://www.trioair.net>. Alternatively, you can download the app to your smart phone here:

- [Google Play](#)
- [Apple Store](#)


4.2 Sign Up

In using TrioAir, the first step for any user is to create an account. Once this is done, you can be invited to join farms or create your own farms. The creation process is fairly standard and should be familiar for anyone who has ever created an account for any application.

Note: Munters recommends using Google Chrome.



1. Click Sign up now.
2. Enter an email address.
3. Follow the online instructions.
4. Once these steps are completed, an account is created.



4.3 Adding a Controller to a Farm During Installation

NOTE The following procedure requires that the Trio be connected to the internet. If the unit is offline, refer to Offline Registration.

The first time that a user power ups a Trio, the following Welcome Screen appears.

Welcome To Trio Controller!



Before using your Trio, please register the controller with TrioAir.

Registration enables access to the following features:



Remote Access

Monitor and control your farm remotely and in real-time.



Manage Data

Access your farm data.



Data Insights

Receive data-driven insights needed to make informed decisions.



Remote Control

TrioAir enables remote control over your controllers in multiple manners.

SKIP FOR NOW

GET STARTED

1. Click Get Started. (If you do not want to register the unit at this time, click Skip For Now). The following screen appears.



TrioAir Registration



P2M58L796

To begin the registration process, follow the instructions below.

Note: You must have a TrioAir account to start this process.

1. On your smartphone or desktop, log into TrioAir.

2. Using a smartphone: Scan the QR code. -Or- Using a desktop: Go to Farm Settings > Add New Device. Enter the code manually.


3. Follow the on-line instructions.

2. Follow the instructions on the page. You will need to:

- Select the farm (if there is more than one) to which this Trio is to be added
- Agree to the Terms of Use.

NOTE For more details on the on-line registration process, click [here](#).

NOTE If you do not want to register the unit at this time click **Skip For Now**. The Trio Dashboard shows that the unit is not registered. Click that message to register the Trio.



4.4 Offline Registration


If the Trio unit is off-line, that status appears on the registration screen.

The registration screen has a blue background and features:
 - **Header:** 'Welcome To Trio Controller!' with a Wi-Fi warning icon.
 - **Main Message:** 'Before using your Trio, please register the controller with TrioAir.'
 - **Features List:**

- Remote Access:** Monitor and control your farm remotely and in real-time.
- Manage Data:** Access your farm data.
- Data Insights:** Receive data-driven insights needed to make informed decisions.
- Remote Control:** TrioAir enables remote control over your controllers in multiple manners.

 - **Warning Banner:** 'Your device is not connected to the internet. Please connect your device or click Manage Network.' with a 'MANAGE NETWORK' button.
 - **Buttons:** 'SKIP FOR NOW' and 'OFFLINE REGISTRATION'.

1. Click Offline Registration. The following screen appears.



2. Click Continue. Follow the online instructions.

NOTE For more details on how to register the Trio while offline, click [here](#).

5 Specifications

- Trio Specifications
- Specification Details
- External Device Specifications

5.1 Trio Specifications

Description	Specification
Input Power Voltage	<ul style="list-style-type: none"> • 100 – 240 VAC • 50/60 Hz
Input AC Power	0.35A (at full load)
Relay Rating	15A
Maximum Relay Load	1 Amp. Up to 70% of the relays can operate at any given time, at 240 Volts.
<i>Note: Running relays at the above current levels provides between 50,000 – 100,000 switching operations.</i>	
Analog Inputs	0 – 3.3 Volts
Analog Output	0 – 10 Volts; maximum load: 20 mA
Digital Inputs	3.3 Volts, 1.5 mA, dry contact
Communication	<ul style="list-style-type: none"> • LAN – Standard 10/100 BaseT • Expansion – RS-485: 115 Kbps, 8 bit, even parity <p><i>NOTE Refer to Appendix G: IT Setup, page 195 for more information.</i></p>
Operating and Storage Temperature Range	-10° to +50° C (+14° to +125° F)
Environmental Specifications	<ul style="list-style-type: none"> • Altitude: -400 m to 2000 m • Relative Humidity: 20% - 70% • Main supply voltage fluctuation up to 10% • Overvoltage category II • PD: 2
Enclosure	<ul style="list-style-type: none"> • Water and dust tight • Indoor use only
Dimensions (H/W/D)	403 x 324 x 141 mm/16 x 13 x 5.6 inches
Fuses	Fuse F2 & F4 on PS card: 3.15A, 250V
Power Cable	<ul style="list-style-type: none"> • Copper, 3-wires Phase, Neutral, Ground, 18 AWG minimum • 600V insulation

Description	Specification
Certification	   

5.2 Specification Details

- **Disconnection device/overcurrent protection:** The disconnect device in the building installation must be provided according to national regulations and using a certified 2-pole circuit breaker rated 10A, certified in accordance with the IEC standard 60947-2 (in the US and Canada use a Listed Branch Circuit protective circuit breaker). This step is required to provide overcurrent protection and mains disconnection. The circuit breaker must be easily accessible and marked as the controller disconnect device.
- **Main Supply Voltage:** Permanently connect the controller to the mains in accordance with the relevant national code. Provide fixed wiring inside a flexible conduit. Relays must be suitably protected against overcurrent, using a circuit breaker rated at 10A.

Keep the controller closed and locked (refer to Locking the Trio, page 11). Only authorized personnel should open and close the unit.

5.3 External Device Specifications

Table 1: Summary

I/O type	Qty
Analogue Output	8
Analogue Input	6
Digital Input	8
Temperature Sensors	12 maximum (6 dedicated, 6 optional)
Total	34

Table 2: Output Devices

Device type	Maximum Number of Devices	Number of Relay Devices	Number of Analog Devices
Cooling	2	2	N/A
Heaters	6	6	6
High Heaters	6	6	6
Inlets	4	4	4
Outlets	1	N/A	1
Tunnel Doors/Curtains	4	4	4
Fans Exhaust/Tunnel	20	20	8
Stir Fan	2	2	2

Lights	4	4	4
Timer	5	5	N/A
Auger	2	2	N/A
Feeder	4	4	N/A
As Relay	20	20	N/A
As Analog Out	8	NA	8
Alarm	1	1	N/A

Table 3: Sensors

Device type	Analog Sensors	Digital Sensors
Temperature Sensors	12	N/A
Humidity Sensors	2	N/A
Outside Humidity Sensor	1	N/A
CO2 Sensors	1	N/A
Ammonia Sensors	1	N/A
Pressure Sensors	1	N/A
Potentiometers	4	N/A
Bird Weighing	4	N/A
Silo Weighing	3	N/A
Feed Weighing	1	N/A
Lux Meter (light intensity)	1	N/A
Water Meters	N/A	4
Gas Meters	N/A	3
Power Meter	N/A	2
Auxiliary Input	N/A	4
Auger Sensor	N/A	2
Feeder Line Sensors	N/A	4
Feed Weighing by Pulse	N/A	2



Table 4: Other Devices

Device type	Number
RSU-2 Remote Scale Unit	2
RLED Light Dimmer	2

NOTE Refer to Appendix B: External Devices (Previous Versions), page 125 to view details on the input/output capacity of previous versions.

6 Using the Trio Touch Screen

	Go back to the previous screen
	View the Main menus
	Choose language
	Network settings
	View alarms
	Go back to the main screen
	Settings icon
	Edit parameters
Settings	Function settings
Testing	Function test
	Replace the dashboard battery with a standard 3V RENATA-CR2450N battery only.
	Click this icon to delete data stored on that page.

Phone App	
	Click the circle containing the user name to edit personal preferences such as the language, units, name, and more.
	When a Trio controls two or more rooms or there are two or more houses on a farm, Send to All enables editing certain select functions in more than one room or house. Edit the setting, click Send to All, and select the required Trios. The select rooms' or houses' settings are updated. Note: Send to All does not appear on every screen.

7 Mapping and Defining the Input Output Devices

NOTE Munters recommends that a trained technician perform the following operations.

- Using the Mapping Screen
- Editing the Relays and Sensors
- Defining Sensors
- Defining Devices
- Mapping the Weighing Devices
- Trio RPS
- Testing Devices


7.1 Using the Mapping Screen

After wiring devices to the Trio, each device must be mapped and then defined. Mapping and defining devices enables the system software to control each device's functionality.

CAUTION Mapping *MUST* match the physical wiring! An error message appears if the physical device is not wired to the relay or port as defined on the mapping screen.


To map the devices:



1. Go to System > Device and Sensors.




This screen displays the relays and analog/digital ports. At this point all, icons are undefined.

2. Click .




- Click  to map cooling devices, heaters, inlets, fans, stir fans, timers, tunnel doors, outlets, or the alarm relay.
- Click  to map auxiliary inputs, sensors (humidity, pressure, temperature, CO2, ammonia), water meter, and potentiometers.

3. Under Devices or Sensors, click the type of device that you want to map. In the following example, Heater is selected. The screen displays the relays and ports that can be defined as heaters.




- 4. Click on the relays and/or ports that you wired to heaters.
 - Trio automatically numbers the devices.
 - Trio enables selecting up to the maximum number of each device.
 - Devices having opening and closing relays require mapping of both relays.
- 5. Repeat steps 3 and 4 for all the connected devices.



6. After mapping all installed devices, click **SAVE**.

NOTE To un-map a device, click on the required device and hold the icon down.

NOTE If you map a sensor that is not physically connected to the Trio, an error symbol appears on the designated analog port.



7.2 Editing the Relays and Sensors

1. On the Device and Sensors screen, click a relay or sensor.

2. Click .

3. Edit the parameter(s).

4. Click **Save**.

7.3 Defining Sensors


- Defining Analog Sensors
- Defining Digital Sensors


7.3.1 DEFINING ANALOG SENSORS

- Enabling/Disabling Analog Input Sensors
- Temperature Sensors
- Defining the Ammonia Sensor
- Defining the CO2 Sensor
- Defining the Humidity Sensors
- Defining the Light Sensor


7.3.1.1 Enabling/Disabling Analog Input Sensors

By default, when the user maps an analog input sensor, the sensor is enabled. To disable a sensor:

1. Go to the device and click edit .
2. Move the enable mode icon to off and click Save.



3. On the dashboard, a disabled sensor is marked.



7.3.1.2 Temperature Sensors

- Defining the Temperature Sensors
- Mapping the Temperature Sensors
- Enabling a Weather Station

7.3.1.2.1 Defining the Temperature Sensors

- Define up to 12 analog input ports as temperature sensors (and one port as an outside temperature sensor).

Temperature 1

Offset 0 °F

Location Front

TEST

**Outside
Temperature 1**

Offset 0 °F

TEST

- Define:
 - Offset: This is an optional correction for the temperature sensor. Range: -10° C to +10° C
 - Enabled: enable/disable the sensor.
 - Location: Designate the area in the room where the sensor is located (front/back/center).

7.3.1.2.2 Mapping the Temperature Sensors

Calculating the temperature data, Trio takes the following into consideration:

Tunnel temperature: Select a sensor or a group of sensors to determine the tunnel temperature readings or select if the tunnel runs according to the average temperature reading.

Average temperature: Data from multiple sensors can be averaged. If a sensor fails, the sensor's data is removed from any calculations.

Device temperature: A sensor (or sensors) can be mapped to a specific device.

Outside temperature: The temperature sensor defined as an outside temperature is not included in any average calculation.

Map specific temperature sensors to specific devices.

- Go to System > Temperature Definition.

Device	Avg.	Temperature Sensors	Outside
Full House		1 3	
Cooling 1	✓		
Timer 1		1	
Timer 2			✓
Timer 3		2	

- Map the sensors to devices.
 - Define which sensors are used to calculate the average temperature.
 - If an outside temperature sensor is enabled, map timers to it (if required).


NOTE Uninstalling a device in the Relay Layout, Analog Output or TRIAC tables removes the device from this screen.


7.3.1.2.3 Enabling a Weather Station

To save costs on temperature sensors, one outdoor temperature sensor can provide data to the entire Trio network.

NOTE Install and map one outdoor sensor only.

1. In System > Device and Sensors, define one sensor as Outside Temperature.


2. Go to System > Control Strategy > Weather Station .



3. Enable Receive Outside Temp. Broadcast.

7.3.1.3 Defining the Ammonia Sensor


- Define one analog input port as an ammonia sensor (refer to Using the Mapping Screen, page 75).



- Define:
 - Offset: This is an optional correction for the ammonia sensor. Range: -10 to +10 ppm

7.3.1.4 Defining the CO2 Sensor


- Define one analog input port as a CO2 port (refer to Using the Mapping Screen, page 75).



- Define:
 - Offset: This is an optional correction for the CO2 sensor. Range: -500 to +500 ppm

7.3.1.5 Defining the Humidity Sensors


- Define (refer to Using the Mapping Screen, page 75):
 - One or two analog input ports as a humidity sensor
 - One analog input port as an outside humidity sensor. The outside humidity is used to collect data, not to adjust climate control.



- Define:
 - Offset: This is an optional correction for the humidity sensor. Range: -10 to +10%\

7.3.1.6 Defining the Light Sensor

- Define one analog port as a light sensor.(refer to Using the Mapping Screen, page 75)



- Define:
 - Enable Mode: Enable/disable the sensor.

7.3.2 DEFINING DIGITAL SENSORS

- Defining the Water Meter Sensors
- Defining the Gas Meter Sensors
- Defining the Power Meter Sensors
- Defining the Auger Active Sensors
- Defining the Feeder Active Sensors
- Defining the Auxiliary Input

7.3.2.1 Defining the Water Meter Sensors

➡ Define up to four (4) digital input ports as a water meter (refer to Using the Mapping Screen, page 75).


Water Meter 1	
QTY/Pulse	0.3 G
Meter Input	Drinking Water

- Define:
 - Quan/Pulse: Set the water meter’s water flow per pulse. Range: 0.0 to 99.9 (unit depends on the General Settings > User.)
 - Meter input: Chose drinking water or cooling.

NOTE Cooling refers to water used in the cooling pad or the foggers. However, the data history shows the quantity of each function separately.

7.3.2.2 Defining the Gas Meter Sensors


➡ Define up to three digital input ports as a gas meter (refer to Using the Mapping Screen, page 75).



- Define:
 - Quan/Pulse: Set the gas meter’s flow per pulse. Range: 0.0 to 999 (unit depends on the General Settings > User).

7.3.2.3 Defining the Power Meter Sensors

➡ Define up to two digital input ports as a power meter (refer to Using the Mapping Screen, page 75).



- Define:
 - Power Source:
 - Main: Power meter measures the amount of electricity used by the system.
 - Heat: Power meter measures the amount of electricity used by the heaters.
 - Pulses kW: Set the number of pulses per kilowatt. Range: 1 to 1000.

7.3.2.4 Defining the Auger Active Sensors

➡ Define up to two digital ports as auger active.

Cross Auger Active 1	
Active State	Open
Quantity Per Minute	0 Kg

- Define:
 - Active state:
 - Open: The circuit is open when the sensor is activated.
 - Closed: The circuit is closed when the sensor is activated.
 - Quantity Per Minute: Define the amount (weight per minute) of feed to be distributed.

7.3.2.5 Defining the Feeder Active Sensors

➡ Define up to four digital input ports as feeder active.

Feeder Active 1	
Active State	Open

- Define
 - Active State: Select if the relay is normally open or normally close.
 - Open: The circuit is open when the sensor is activated.
 - Closed: The circuit is closed when the sensor is activated.

7.4.1 0 – 10 VOLT ANALOG OUTPUT DEVICES

Several devices can be controlled by relays or analog output ports. In analog output-controlled devices, the user defines the voltages that define the devices' minimum and maximum output. For example, if the minimum voltage is set to 2V and the maximum to 8V the controller applies the calculated 0-100% output over a 2V-8V signal.

7.4.2 DEFINING THE FANS

The following sections detail how to configure fans.

NOTE These settings should be configured by a technician familiar with the fan and inlet/curtain specifications.

Fan air capacity defines how much air is provided when the fans run at full speed. These numbers are used to calculate minimum air requirements.

- In General Settings > User define the measurement unit.
- Define up to 20 relays or analog output ports as On/Off or 0 – 10 V fans, respectively (refer to Using the Mapping Screen, page 75).
 - On-Off Fans
 - 0 – 10 Volt Fans


7.4.2.1 On-Off Fans

Fan 1	
Capacity	0 M3/h
KWh	0
Reverse Relay Output	<input type="checkbox"/>
TEST	

- Define:
 - Capacity: Enter the fan capacity.
 - KWh: This field displays the amount of kilowatts used. Read-only.
 - Reverse Relay Output: Select if the relay is normally open or normally close.

7.4.2.2 0 – 10 Volt Fans

Fan 3	
Min. Voltage (V)	0.0
Max. Voltage (V)	10.0
Min. Capacity	1,000 M3/h
Max. Capacity	5,000 M3/h
KWh	0.0
Boost Time (sec.)	5

 0.0 TEST

- Define:
 - Minimum/Maximum Voltage: Enter the minimal and maximal voltage used to calibrate the fan speed.
 - Minimum/Maximum Capacity: Enter the fan's minimum and maximum capacity. These numbers are used to calculate the curve between these points.
 - KWh: This field displays the amount of kilowatts used. Read-only.
 - Boost Time: During this amount of time, the controller applies full power to the fan motor (100%). Boosting the speed is done to open shutters or extend the motor life. In addition, some types of motors have a minimum starting speed.

7.4.3 DEFINING THE STIR FAN

- Define up to two relays or ports as a stir fan (refer to Using the Mapping Screen, page 75).
 - On Off Stir Fan
 - 0 – 10 Volt Stir Fan

7.4.3.1 On Off Stir Fan

Stir Fan 1	
KWh	0
Reverse Relay Output	<input type="checkbox"/>

TEST

- Define:
 - KWh: This field displays the amount of kilowatts used. Read-only
 - Reverse Relay Output: Select if the relay is normally open or normally close.

7.4.3.2 0 – 10 Volt Stir Fan

Stir Fan 1

Min. Voltage (V) 0

Max. Voltage (V) 10

KWh 0

TEST

- Define:
 - Minimum/Maximum Voltage: Enter the minimal and maximal voltage used to calibrate the fan speed.
 - KWh: This field displays the amount of kilowatts used. Read-only.

7.4.4 DEFINING THE BLOWBACK FAN

➡ Define one relay as a blowback fan (refer to Using the Mapping Screen, page 75).

Blowback Fan 1

KWh 0

Reverse Relay Output


TEST

- Define:
 - KWh: This field displays the amount of kilowatts used. Read-only
 - Reverse Relay Output: Select if the relay is normally open or normally close.

7.4.5 HEATING DEVICES


- Define up to six relays and/or analogue output ports as heaters (refer to Using the Mapping Screen, page 75).
 - Defining the On/Off Heaters
 - Defining the Variable Heaters
 - Defining the High Heaters

7.4.5.1 Defining the On/Off Heaters



- Define:
 - KWh: This field displays the amount of kilowatts used. Read-only
 - Reverse Relay Output: Enable this function for Normally Closed Relays.
 - Ignition Time (sec.): Define the delay time between when the heater is turned on and when the gas is ignited.
 - Test checks the relay functionality.

7.4.5.2 Defining the Variable Heaters



- Define:
 - Min./Max Voltage: Define the voltage in the analogue output port that corresponds to the 0% and 100% output, respectively.
 - KWh: This field displays the amount of kilowatts used. Read-only.

7.4.5.3 Defining the High Heaters

High heaters work in conjunction with relay heaters. High heater 1 works with heater 1, high heater 3 works with heater 3, and so on. If there is no corresponding heater to a high heater, the latter does not function. For example, if there are three heaters and four high heaters, high heater 4 does not function.


➔ Define up to six relays as high heaters (refer to Using the Mapping Screen, page 75).



- Define:
 - Reverse Relay Output: Enable this function for Normally Closed Relays.

7.4.6 DEFINING THE COOLING PADS


➔ Define up to two relays as cooling pads (refer to Using the Mapping Screen, page 75).



- Define:
 - KWh: This field displays the amount of kilowatts used. Read-only.
 - Reverse Relay Output: Enable this function for Normally Closed Relays.

7.4.7 DEFINING THE FOGGERS

- Define up to six relays as foggers.



- Define:
 - Reverse Relay Output: Enable this function for Normally Closed Relays.

7.4.8 MAPPING THE POTENTIOMETERS, INLETS, TUNNEL DOORS, OUTLETS

- Mapping the Potentiometers
- Defining the Inlets/Tunnel Doors
- Defining the Outlet

7.4.8.1 Mapping the Potentiometers

- Define up to four analogue ports as potentiometers (refer to Using the Mapping Screen, page 75).

As an option, potentiometers enable exact positioning of relay-controlled inlets\tunnel doors when calibrating. If:



- potentiometers are not employed or
- there is a potentiometer failure
- opening and closing times are used to calibrate the inlets/tunnel doors.



- Enable/disable the potentiometer.

7.4.8.2 Defining the Inlets/Tunnel Doors

- Define up to four relays or analog output ports as inlets or tunnel doors (each device requires two relays or one analogue port) (refer to Using the Mapping Screen, page 75).



- For relay-controllers devices, define:
 - Position: Define how the inlet opening is controlled:
 - By time
 - Potentiometer (relay-controlled inlets or tunnel doors only). Map each inlet/tunnel door to a potentiometer. This option appears only if potentiometers are mapped.

NOTE After defining the potentiometer, test it. Refer to Potentiometer, page 123.

- Open/Close Time: Measure and enter the amount of time required to fully open or fully close the inlet. These parameters are only enabled when Position/By Time is selected.
- Open/Close Reverse Relay Output: Enable this function for Normally Closed Relays.
- Calibrate: Manually calibrate inlets/tunnel doors positioned by a potentiometer. Potentiometer-controlled calibration only.
- For 0 – 10V controlled devices, define:
 - Min./Max Voltage: Define the voltage in the analogue output port that corresponds to the 0% and 100% output, respectively.
 - Open/Close Time: Measure and enter the amount of time required to fully open or fully close the inlet.

7.4.8.2.1 Potentiometer Calibration

If used, a potentiometer can control the opening and closing with a high degree of precision. When there is no potentiometer, positioning accuracy tends to degrade after the inlets go through several opening and closing cycles.

In order to calibrate an inlet/vent/tunnel door using a potentiometer:

- Install and map a potentiometer.
- Define the relay-controlled inlet/vent/tunnel door that the potentiometer controls. (Analog controlled devices don't require a potentiometer.)
- Calibrate the potentiometer. Calibration must be successful.

In for any reason potentiometer calibration does not function:


- calibration is by time (auto and/or at power up). Time calibration does not fail.
- A potentiometer alarm is generated (if alarms are enabled). The alarm must be reset to enable potentiometer calibration to function.


7.4.8.2.2 Calibrating the Inlets/Tunnel Door

During installation, the user enables auto-calibration or power up calibration in digital output (relay) inlets. Calibration automatically takes place after the number of inlet movements equals the number of movements required to start calibration or at Trio power up.

Only one inlet or tunnel curtain can be calibrated at a time.


- Relay open occurs when the target position is 100%.
- Relay close occurs when the target position is 0%.

1. Go to System > Control Strategy > Ventilation .



2. Define:

- Inlets/Tunnel Position: Refer to the User Manual.
- Auto Calibration: If enabled, the inlet or tunnel automatically recalibrates itself.
 - Select 24 hours a day or define a specific time frame.
 - Number of Movements: Define up the number of steps (number of movements) after which the inlet/tunnel door automatically calibrates.
- Power Up Calibration: Enable this function to have the inlet/tunnel recalibrate itself each time power is applied.
- **Potentiometer-controlled calibration failure:** If calibration fails (during auto or power up calibration) in a potentiometer-controlled calibration, an error symbol appears in the Devices and Sensor screen.



In this situation, click **Calibrate** to run the Calibration Wizard. If the calibration fails again, check:

- Potentiometer wiring
- Potentiometer
- Inlets' and curtains' opening and closing position. There must be a minimum distance between the two, equivalent to 300 A2D points.

7.4.8.3 Defining the Outlet

➡ Define one analog output port as an outlet (refer to Using the Mapping Screen, page 75).

Outlet 1	
Min. Voltage (V)	0
Max. Voltage (V)	10
Open Time (sec.)	60
Close Time (sec.)	60

TEST

- Define:
 - Min./Max Voltage: Define the voltage in the analogue output port that corresponds to the 0% and 100% output, respectively.
 - Open/Close Time: Enter the amount of time required to fully open or fully close the inlet.

7.4.9 DEFINING THE SAME AS RELAYS

- Define up to 20 relays as Same as Relay (refer to Using the Mapping Screen, page 75).

This function enables defining a relay to operate using the parameters defined for another relay. A relay can be tied to any other relay.

Same As Relay -	
Related Channel	0
KWh	0
Reverse Relay Output	<input type="checkbox"/>

TEST

- Define:
 - Related: Define which relay number to follow. Range: 1 – 20
 - KWh: This field displays the amount of kilowatts used. Read-only.
 - Reverse Relay Output: Select if the relay is normally open or normally close.

7.4.10 DEFINING THE SAME AS ANALOG PORTS

- Define up to eight relays as Same as Analog Ports (refer to Using the Mapping Screen, page 75).

This function enables defining a relay to operate using the parameters defined for a corresponding analog port. Relays can be mapped to eight specific ports only.

Same As Analog -	
Related Channel	None
KWh	0
Reverse Relay Output	<input type="checkbox"/>


TEST

- Define:
 - Related Channel: Define which port number to follow.
 - KWh: This field displays the amount of kilowatts used. Read-only.
 - Reverse Relay Output: Select if the relay is normally open or normally close.

Port Number	Related Channel
7	1
8	2
9	3
10	4
21	5
22	6
23	7
24	8

7.4.11 DEFINING THE TIMERS

➡ Define up to five relays as timers (refer to Using the Mapping Screen, page 75).




- Define:
 - KWh: This field displays the amount of kilowatts used. Read-only.
 - Reverse Relay Output: Select if the relay is normally open or normally close.

7.4.12 LIGHTING DEVICES

➤ Define up to four relays or analog ports as light relays and one sensor as a light sensor (refer to Using the Mapping Screen, page 75). In addition, Version 8.3.X supports the RLED 2.0 Light Dimmer.


- Defining the On/Off Lights
- Defining the Variable Lights
- Defining the RLED 2.0

7.4.12.1 Defining the On/Off LIGHTS



- Define:
 - Reverse Relay Output: Select if the relay is normally open or normally close.

7.4.12.2 Defining the Variable LIGHTS




- Define:
 - Minimum/Maximum Voltage: Enter the minimal and maximal voltage used to calibrate the fan speed.


7.4.12.3 Defining the RLED 2.0

➡ The RLED icon does not appear unless an RLED 2.0 is connected to a Trio.

1. Go to Devices & Sensors.



2. Click RLED.



3. Select one RLED 2.0 channel.

4. Select the relays or ports. The RLED 2.0 will control those lights.

7.4.13 FEEDING DEVICES

Setting up a feed system requires auger relays and sensors, and feeder relays and sensors. Define:

- Auger and feed relays to control the auger/feeder lines.
- Auger digital sensors to detect auger overtime issues: silo is empty, feed lines are stuck, or other mechanical issue.
 - Auger 1 is automatically associated with Augur Active Sensor 1. Auger 2 is automatically associated with Augur Active Sensor 2.
 - Feeder 1 active is associated to feeder 1 relay, feeder 2 active to feeder 2 relay, etc.
- Defining the Auger Relays
- Defining the Feeder Relays

7.4.13.1 Defining the Auger Relays

➡ Define up to two relays as augers.

Cross Auger 1

KWh 0


Reverse Relay Output

TEST

- Define:
 - KWh: This field displays the amount of kilowatts used. Read-only.
 - Reverse Relay Output: Select if the relay is normally open or normally close.

7.4.13.2 Defining the Feeder Relays

➡ Define up to four relays as feeders (refer to Using the Mapping Screen, page 75).




- Define:
 - KWh: This field displays the amount of kilowatts used. Read-only.
 - Reverse Relay Output: Select if the relay is normally open or normally close.

7.4.14 FAIL SAFE DEVICES

The Fail Safe function defines extreme conditions that activate dedicated failsafe relays. These relays activate external devices used to deal with the condition.

➡ Define up to four relays as fail safe relays.



- Define:
 - Reverse Relay Output: Define the relay mode as Closed.


7.4.15 WATER PRESSURE DEVICES

- Defining the WOD
- Defining the WOD Pro
- WOD Pro Calibration

7.4.15.1 Defining the WOD

WOD relays control three pre-set pressure regulators.

➡ Define up to three relays as WOD relays.




- Define:
 - Reverse Relay Output: Enable this function for Normally Closed Relays.

7.4.15.2 Defining the WOD Pro

The WOD Pro sensor controls the water pressure and flow in all drink lines.

➡ Define one analog output port as a WOD Pro sensor.




- Define:
 - UPR Pressure: The UPR is a pressure regulator which has an adjustable range between 0 – 58 PSI.

7.4.15.3 WOD Pro Calibration


The system is factory calibrated. Calibrate the WOD Pro only if the pressure readings do not match expected values.

To calibrate the sensor:

1. Click Calibrate.




2. Click Calibrate.
3. WOD Pro supplies 2.5 volts. Enter the value of the pressure shown on the water outlet.




4. Click Next.

5. WOD Pro supplies 7.5 volts. Enter the value of the pressure shown on the water outlet.



6. Click Next.



Calibration is complete.

7.5 Mapping the Weighing Devices

- Defining the Silos
- Defining BinTrac Silos
- Defining the Bird Scales
- Defining the RSU

7.5.1 DEFINING THE SILOS

- Mapping the Silo Scales
- Configuring the Silo Scale
- Testing the Silo


7.5.1.1 Mapping the Silo Scales

Trio can support up to:


- three silo scales (Version 8.3 and below).
- four silo scales (Version 9.0 and above)

➔ This function requires a scale card.


1. On the Devices & Sensors screen, click Silo. The Scale icon turns brown.



2. Click the Scale icon.
3. Select up to three channels and click Save.



4. Click on each channel.




5. Define:

- Enable Mode: Enable/disable the channel.
- Storage Capacity: Define the quantity of feed that each silo can contain.
- Calibrate: Refer to the next section.


7.5.1.2 Configuring the Silo Scale

The following procedure details how to “zero out” the Trio silo scales. Zeroing out is way to ensure that the unit’s A2D number is accurate (shown in the Silo Icon; 430 in the picture below). To summarize the procedure:


- The user enters the correct amount of feed in the silo while calibrating the silo scale. In the Silo management screen, the user enters “0” (zero). Trio then defines the current A2D signal to be the A2D signal for an empty bin.



1. Define each silo’s storage capacity.
2. Click on the silo icon and click **Calibrate**. The following screen appears:




3. Click Other. The following screen appears:




4. Fill up the silo with a known amount of feed. Munters recommends either a truck filling or a minimum of 500 kilograms.


5. Enter the amount of feed in the silo and press Continue.





The following screen should appear.



6. Go to Flock > Silo Management.




7. Click  and change the feed weight to 0.




8. Click **Save**.

The Trio now displays an accurate A2D number on the silo icon screen.




7.5.1.3 Testing the Silo


1. After calibrating the silo, go to the Silo relay.



2. Click Test.



3. Place a known weight in the silo.




The weight should appear on the screen and the A2D level should rise.

7.5.2 DEFINING BINTRAC SILOS

TRIO can support up to three BinTrac silo scales.

➡ This function requires a scale card.

1. On the Devices & Sensors screen, click Silo. The Scale icon turns brown. Click the icon.



2. Define the ports as BinTrac. No parameter definitions required.


7.5.3 DEFINING THE BIRD SCALES

- Mapping the Bird Scales
 - Calibrating the Bird Scales
 - Testing the Bird Scale
- Trio can support up to four bird scales.

7.5.3.1 Mapping the Bird Scales


➡ Install a scale card.

1. On the Devices & Sensors screen, click Bird Scale. The Scale icon turns brown.



2. Click the Scale icon.


3. Define up to four channels as scales and click Save.



4. Verify that each channel is enabled.

7.5.3.2 Calibrating the Bird Scales

1. Click on a bird scale icon and click **Calibrate**. The following screen appears:



2. Remove everything from the scale and press **Zero**. In the following screen enter the weight being used to calibrate the scale; minimum is 1.0 kilogram. Click **Next**.

CAUTION The scale must be free of any objects before pressing **Next**!

Bird Scale 1 Calibration

Enter the weight being used to calibrate the scale

Caution: Do not place the weight on the scale yet!

Range 1.000 - 50.000

1	2	3
4	5	6
7	8	9
-	0	.
Enter		←

- 1.5 Kg +

CANCEL NEXT

3. Place a known weight on the scale (1.5 kilograms in the below example) and press **Next**.


Bird Scale 1 Calibration

Load 1.5 Kg on platform

- The load should be placed close to the center of the platform.

CANCEL NEXT


The following screen should appear:




7.5.3.3 Testing the Bird Scale



1. Click Test.



2. Place a known weight on the bird scale.




The result should be fairly close to the true weight.

7.5.4 DEFINING THE RSU

The following section details how to define up to two RSU units connected to the Trio (optional). For detailed information on using the RSU, refer to the product manual.

➡ **Wire the RSU to the Trio as shown in Figure 43, page 52.**

1. Reset the Trio, as shown in General Settings > About.
2. Go to Device & Sensors > Installation > Scale.



3. Click the RSU icon.
4. Click Calibrate.

Follow the instructions given in *Configuring the Silo Scale*, page 109.

7.6 Trio RPS

The following section details how to configure the RPS device.

- Defining the Sensor
- Static Pressure Calibration

7.6.1 DEFINING THE SENSOR


1. Go to System > Devices & Sensors.

2. Click . The Devices & Sensor screen appears.

3. Click .

4. Click Pressure.

5. Define an analog input port as the pressure sensor. In the following screen, ports 5 and 19 are defined as the pressure sensor.



6. Go to Climate > Static Pressure and define the parameters.

7.6.2 STATIC PRESSURE CALIBRATION

CAUTION *The Static Pressure sensor is factory calibrated. Only calibrate the sensor if you have reason to believe that they are producing inaccurate results.*


The Static Pressure should be 0 when there is no ventilation and the house is closed. When the controller A/D counts is 100, this means that there is zero (0) static pressure.

NOTE: Run the controller for a few hours so that the temperature in the box becomes stable and only then calibrate.


CAUTION DO NOT blow the air into the hose to see if the pressure changes! The sensor is sensitive and blowing air can cause irreparable damage.

To calibrate the Static Pressure Sensor:


1. Disconnect the air hoses.
2. Go to *System > Device & Sensors > Pressure*.



3. Click Calibrate.



4. If the A/D count is 100 +/- 30 (70 to 130), click **Calibrate**.
5. If the A/D count is less than 70 or greater than 130:
 - a. Check for blocked air hoses or wind interference.
 - b. Open the Trio. On the Main Board, find the Static Pressure Sensor.




- c. Adjust the zero pressure reading to approximately 100 by turning the calibration screw.
- d. When the A/D count is within the permitted range, press Calibrate.


7.7 Testing Devices

After mapping and wiring devices, Trio provides a testing function that enables checking the device's performance.


- Fans: Click Test to test the fan's response.




- Relay devices: Click Test > On to ensure that the device turns on.




- Analog output devices: Click Test and move the voltage scale to ensure that the device operates at the proper minimum and maximum voltage levels.



- Analog input devices: Click Test to view the current input results and A2D value. The test function also displays an error message when the input signal is weak or non-existent.



- Acceptable ranges: RTS-2: 200 – 600.
- Digital input devices: Click Test to view the current circuit status (signal close or signal open).



- Potentiometer/Inlets: Before testing the potentiometer:
 - Wire the potentiometer (refer to Potentiometer Wiring, page 43)
 - Define an inlet controlled by a potentiometer (refer to Mapping the Potentiometers, page 93).
 - Test the potentiometer:
 1. Using a voltmeter, test the signal voltage between the COM port and selected S port (S2 in Figure 50).





Figure 55: Testing the Potentiometer

- 2. In Devices and Sensors, go to the inlet controlled by the potentiometer and click Test. The test icon appears.



- If the wiring is correct:
 - When the inlet is fully closed, the voltage should be low (for example 0.5V).
 - When the inlet is fully open, the voltage should be high (for example 3.2V).
- If the voltages are reversed, that means that the wiring is reversed.




Figure 57: Trio Alarm Battery Installation

1	Attach the card with four screws
2	Attach the wires between the Trio battery and the alarm battery.
3	Attach the wires between the alarm battery and the CPU card.
4	On/off toggle switch

- The toggle switch:
 - When the switch is in the upper position, the backup delivers emergency power to the display card and cell modem when main power is lost.
 - When the switch is in the middle or bottom position, the backup is disconnected from the display card and cell modem; no power is delivered.
 - The LED next to the toggle switch is lit when the switch is in the upper position.

8.2 Detailed Description




Figure 58: Battery Board Detailed Schematic

##	Component	Functionality	Note
1	Dip switch S4 "BUZZER" Disable/Enable	Restores the battery to working condition after being on a shelf or after transportation	
2	LED D9 "18V"	Indicates the presence of the charger voltage	
3	P1	Input terminal	An input terminal that receives 12V voltage from the motherboard.
4	TP2, TP3	Test points	5V, 3.3VREF (for technicians only)
5	LED D13 "Status"	Indicates the character of the application running	<ul style="list-style-type: none"> Blinks during normal application operation. Remains steadily ON or OFF if the application is stalled.
6	P2	Battery connector	
7	LED D11	Indicates that the battery is connected to the board	
8	Toggle switch S1 "BATTERY SWITCH"	Connects the battery to the board	During transportation or being on the shelf must be in the state "OFF"

##	Component	Functionality	Note
9	Measurements TP1 group	Test points	<ul style="list-style-type: none"> • BC - Battery Current, see below. • BF - Battery Fail, default Low (≤ 150 mV) • MF - Main Fail, default High (4.75-5.0V) • OC - <u>reserve</u> (the Display Card has on its input overcurrent protection device). • VBAT - Battery voltage • BC1-BC2 - Charging battery current (for technicians only)
10	LED D4 "Charge Termin"	Indicates the charging process termination	Lights up when the battery is being discharged by an artificial load and when the battery is fully charged.
11	LED D12 "Charging process"	Indicates the charge/discharge process	<ul style="list-style-type: none"> • High-speed blinking when discharging. • Low-speed blinking when charging. • Turns OFF when charging is completed
12	P8	Communication terminal	RS-485 communication with Display Card
13	DIP Switch S2	Connects termination resistor for RS-485 communication	This DIP switch must be always kept in the position marked "TERM.OFF".
14	N/A		
15	P3	Output terminal	<ul style="list-style-type: none"> • Battery voltage on it appears when a main power 12V outage occurs. • To be connected to Display Card (for technicians only)

8.3 Preparing the Battery for Operation After Transportation or Storage

NOTE Refer to Figure 58 when numbers (#) are mentioned regarding the battery board's components.

1. Apply 12V to the input terminal P1 (#3).
2. Set switch S1 (#8) to the ON position.
3. Move DIP switch S4 (#1) to the ON position.
4. Press the Reset button (refer to #8 in Figure 12, page 29) for 1–2 seconds.
 - LED D12 (#12) begins flashing rapidly (battery is discharging).
 - LED D4 (#10) turns on.
5. Return DIP switch S4 to the OFF position. See Note 1.
 - When the battery voltage reaches 11.9 ± 0.1 V, discharging ceases and the system automatically begins charging the battery. At this point, LED D4 turns off.
 - Charging may take several hours.
 - During charging, LED D12 flashes slowly while the green LED D4 remains off.
 - When the battery is fully charged, LED D12 (#11) turns off and LED D4 (#10) turns on.

Note 1: DIP switch S4 is used to restore batteries that have been unused for a long time (for example, during storage or transport). It works by performing a deep discharge followed by a full recharge, which helps remove buildup on the battery electrodes.

- This process may take 1–4 hours, depending on the battery's condition.
- Use the same procedure when installing a new battery.

9 Appendix B: External Devices (Previous Versions)

The following section details the relays and analog/digital ports found in previous software versions.

Table 5: Trio 20 Poultry STD - Version 5

Device type	Maximum Number of Devices	Number of Relay Devices	Number of Analog Devices
Cooling	2	2	N/A
Heaters	6	6	6
Inlets	2	2	2
Outlets	1	N/A	1
Tunnel Doors/Curtains	2	2	2
Fans Exhaust/Tunnel	20	20	8
Stir Fan	2	1	1
Lights	4	4	4
Timer	5	5	N/A
Auger	2	2	N/A
Feeder	4	4	N/A
Lighting	4	4	N/A
As Relay	30	30	N/A
As Analog Out	8	NA	8
Alarm	1	1	N/A

Device type	Analog Sensors	Digital Sensors
Temperature Sensors	12	N/A
Humidity Sensors	2	N/A
Outside Humidity Sensor	1	N/A
CO2 Sensors	1	N/A
Ammonia Sensors	1	N/A
Pressure Sensors	2	N/A
Potentiometers	4	N/A
Bird Weighing	4	N/A

Device type	Analog Sensors	Digital Sensors
Silo Weighing	2	N/A
Lux Meter (light intensity)	1	N/A
Water Meters	N/A	4
Gas Meters	N/A	3
Aux. Input	N/A	4
Auger Sensor	N/A	2
Feeder Line Sensor	N/A	4

Table 6: Trio 20 Poultry STD - Version 4

Name	Output			Measurements	
	Total	Relay	0-10V	Analog	Digital
Cooling	2	2			
Heaters	6	6	6		
Inlets	2	2	2		
Outlets	1	NA	1		
Tunnel Doors/Curtains	2	2	2		
Fans Exhaust/Tunnel	20	20	8		
Stir Fan	1	1	1		
Timer	5	5			
Auger	2	2			
Feeder	4	4			
Lighting	4	4	4		
As Relay	30	30	NA		
As Analog Output	8	NA	8		
Alarm	1	1			
Temperature Sensors				12	
Humidity Sensors IN				1	
CO2 Sensors				1	
Ammonia Sensors				1	
Pressure Sensors				1	
Potentiometers				4	
Power Meter				2	
Gas Meter				2	
Lux Meter				1	
Bird Weighing				2	
Silo Weighing				2	
Water Meters					1
Aux. Input					4
Auger Sensor					2
Feeder Line Sensor					4

Table 7: Trio 20 Poultry STD - Version 3


Name	Output			Measurements	
	Total	Relay	0-10V	Analog	Digital
Cooling	2	2			
Heaters	4	4	4		
Inlets	2	2	2		
Outlets	1	NA	1		
Tunnel Doors/Curtains	2	2	2		
Fans Exhaust/Tunnel	12	12	8		
Stir Fan	1	1	1		
Timer	5	5			
Auger	2	2			
Feeder	4	4			
Lighting	4	4	4		
As Relay	20	20	NA		
As Analog Output	8	NA	8		
Alarm	1	1			
Temperature Sensors				12	
Humidity Sensors IN				1	
CO2 Sensors				1	
Ammonia Sensors				1	
Pressure Sensors				1	
Potentiometers				4	
Power Meter				X	
Gas Meter				X	
Lux Meter				1	
Bird Weighing				2	
Silo Weighing				2	
Water Meters					1
Aux. Input					4
Auger Sensor					2
Feeder Line Sensor					4



10 Appendix C: Service Manual

- Maintenance
- Trouble Shooting
- Spare Parts

10.1 Maintenance

Perform the following steps to maintain your unit.

<ul style="list-style-type: none">• Checking the Battery Level: Check the battery once a year. The output must be 2.7 volts (minimum). Authorized personnel only must replace the battery if the output is below the minimum required level or every five years.	
<ul style="list-style-type: none">• Visually inspect your unit once a year. Make sure that there are no signs of corrosion or residue on the PCBs. If these issues appear, it means that:	
<ul style="list-style-type: none"><ul style="list-style-type: none">○ the Trio is installed in an environment with high humidity, ammonia content, or some other destructive agent.	
<ul style="list-style-type: none"><ul style="list-style-type: none">○ There is a lack of (silicon) sealing or that the sealing has degraded.	
<ul style="list-style-type: none">• Make sure that the silicon seal around the PGs installed in the knockouts is not cracked.	
<ul style="list-style-type: none">• Check that the gasket is not cracked.	

<ul style="list-style-type: none">• Check that the gasket around the touch screen is not cracked.	 <p>A top-down view of the back of a Munters R0TEM unit. The device is housed in a grey, ruggedized case. A yellow gasket is visible around the perimeter of the touch screen. A label 'Gasket' with a pointer indicates this component. Below the screen, the green PCB is visible, featuring a 'ROTEM' label, several battery packs, and various electronic components. A 'CAUTION!' warning is printed on the PCB. The Munters logo is visible at the top of the case.</p>
<ul style="list-style-type: none">• Look for any signs of burns or browning around the varistors.	 <p>A top-down view of the back of the R0TEM unit, similar to the first diagram. A callout box on the right side shows a magnified view of the varistors on the PCB. The callout is labeled 'Varistors'.</p>
<ul style="list-style-type: none">• Inspect the shield wiring and main grounding cable; ensure that they are properly connected to the proper ports.	

10.2 Trouble Shooting

- Internet
- Electronic Components

10.2.1 INTERNET

The following section describes how to trouble shoot internet problems. In the event that there is no internet connection:

1. Go to System > General Settings > Network Screen. Verify that there is an IP address.
2. Check the cable connections between the switch and the Trio.
3. Verify that the unit is powered.

NOTE If there is no internet connection, the Main Menu Internet icon is marked.



10.2.2 ELECTRONIC COMPONENTS

Problem: The touch screen doesn't turn on up after applying 115/230VAC.

Solution: Open the Trio door and:

1. Check main 115/230VAC 3A fuse F2.
 - If required, replace fuse.
2. Check the 12V terminal voltage (COM & 12V).
 - If there is no voltage, there is a problem with the Switched Power Supply. Replace the power supply.
3. Verify that the 5V and 3.3V indicative LEDs of the I/O power board are lit.
4. Verify that the flat cable connecting the I/O board and the display board is in place.
5. Verify that the Green Status LED is flashing.
6. On the Trio display board, verify that the:
 - RED Status LED is flashing
 - Display's flat cable is firmly hooked up to its connector.

Problem: The screen doesn't reflect changes made in the analog inputs.

Solution:

1. Verify that the position of Dip Switch (S1-S6) corresponds with the relevant analog input.
2. Verify that the analog input terminals' mapping corresponds to the actual wiring.
3. Check that the terminal wire connection of Analog Input of interest coincides with the analog input chosen on the touch screen.

Problem: The screen doesn't reflect the changes in digital inputs.

Solution: Verify that the digital input terminals' mapping corresponds to the actual wiring.

Problem: The Alarm Relay doesn't operate.

Solution: Check fuse F4.

- By default, alarm relay contacts "NO-COM" should be closed.

Problem: The analog output voltage doesn't correspond to the voltage defined on the corresponding analog output terminal.

Solution: Check the load value. The maximum analog output load is 15 mA.

Problem: An analog output terminal has no output voltage.

Solution: Verify that the analog output terminals' mapping corresponds to the actual wiring.

Problem: The display screen appears but does not respond to any touch.

Solution: Check the USB cable between the touch screen card and the Trio display card.

Problem: There is no 3.3V output for to power the potentiometer(s).

Solution: There is a PPTC fuse F1 on the 3.3V line. Disconnect the potentiometers and using a DVM, check the resistance on the terminal between the 12V output and common ground (COM). The reading should indicate an open circuit.

- If not, the line is damaged.

Problem: The end user doesn't see changes in the data tables.

Solution:

1. Check the Internet cable, going from RJ-45 connector (marked as Ethernet-2). Verify that the connector's LEDs are flashing.
2. Check the Internet cable, going from the power card to the Trio display's card RJ-45 connector (marked as Ethernet-1). Verify that the connector's LEDs are flashing.

10.3 Spare Parts

- Preliminary Information
- Trio Minimal Spare Parts
- Trio 20 Door Card Spare Parts
- Trio 20 Main Container Spare Parts
- Additional Options
- Cards

10.3.1 PRELIMINARY INFORMATION

	Trio 20
Container	A
Door Cards	B
Main Container Cards	C
Cables and Harnesses	D
MPN	Munters Part Number
DPN	Distributor Part Number

10.3.2 TRIO MINIMAL SPARE PARTS

Munters Israel recommends that managers of farms equipped with Trio Controllers keep (as a minimum stock) the following spare parts on hand. Doing so simplifies maintenance and repairs of the Trio units.


10.3.2.1 Global Customers

P/N	Description
940-99-00002	TRIO-20 LCD KIT (DISPLAY + LVDS CARD + USB CABLE) (SP-250061)
940-99-00003	TRIO-20 CPU (TRIO 20-MAIN)
940-99-00004	TRIO 20 DISPLAY CARD (TRIO-DISPLAY)

10.3.2.2 Chinese Customers


P/N	Description
940-99-00002	TRIO-20 LCD KIT (DISPLAY + LVDS CARD + USB CABLE) (SP-250061)
940-99-00003	TRIO-20 MAI, CPU
940-99-00164	TRIO-POU-CN DISPLAY CARD IMX8 NEXCOM

10.3.3 TRIO 20 CONTAINER SPARE PARTS



ID No.	Description	Catalog Number	Note
A1.1	Trio-20 FRONT DOOR TOUCH PLASTIC PART	MPN: 940-99-00005	
		DPN:	
A1.2	Trio-20 PLASTIC BOX BASE (SP - 207124)	MPN: 940-99-00112	
		DPN:	
A1.3	Trio HINGE PLASTIC PIN V1.0.0 (SP-207128)	MPN: 940-99-00019	
		DPN:	
A2.1	Trio-20 PANEL PLASTIC PART BLUE LOGO MUNTERS + PART BLUE	MPN: 940-99-00001	OR
		DPN:	
A2.2	Trio PANEL PLASTIC PART RED RAL 3020 NO LOGO (SP-207138)	MPN: 940-99-00045	
		DPN:	
A3.1	ONE / ONE PRO - LATCH GENERAL LOCK PLASTIC PART + LOCK FOR LATCH	MPN: 900-99-00217	
		DPN:	
A3.2	GENERAL PLASTIC LATCH	MPN: 900-99-00216	
		DPN:	
A4	Trio-20 LCD HOLDER V1.0.0 (SP-207125)	MPN: 940-99-00024	
		DPN:	
A5	P4 SCREEN GASKET SILICONE 35 SHORE 75CM (EXTRUSION PROCESS) (SP-204079)	MPN: 940-99-00020	
		DPN:	
A6	MID-RANGE MAIN GASKET V1.0.0 (SP-207122)	MPN: 940-99-00021	
		DPN:	


10.3.4 TRIO 20 DOOR CARD SPARE PARTS




ID No.	Description	Catalog Number	Notes
B1	TRIO-20 LCD KIT (DISPLAY + LVDS CARD), [+ USB CABLE *	MPN: 940-99-00002 DPN:	
B2.1	TRIO-POU-EN DISPLAY CARD IMX8 NEXCOM	MPN: 940-99-00004 DPN:	OR
B2.2	TRIO-POU-CN DISPLAY CARD IMX8 NEXCOM	MPN: 940-99-00164 DPN:	
B2a	BAT COIN 3V FOR SOCKET (SP-450009)	MPN: 999-99-00386 DPN:	
B2b	FAN 12V 0.62W 7000RPM 8CFM (SP-240201)	MPN: 940-99-00177 DPN:	
B2c	TRIO 20 ANTENNA WIFI MOLEX 15cm CABLE U.FL/I-PEX MHF 2.4GHz 2.8dBi 50ohm (SP-491009)	MPN: 940-99-00035 DPN:	
B3.1	GLOBAL LTE CELL MODEM W/O SIM SOCKET-EG21GGB-MINIPCIE (SP-490099)	MPN: 904-99-00106 DPN:	
B3.2	Trio Cell Modem Global SIM (SP-221011)	MPN: 904-99-00118 DPN:	
B4	TRIO HIGH RANGE POWER BACKUP CARD (T2-BACKUP)	MPN: 940-99-00167 DPN:	
B4a	BAT Pb 12V 1.2AH NP12-1.2AH NPP (SP-450042)	MPN: 940-99-00178 DPN:	

ID No.	Description	Catalog Number
D1	VIDEO FLAT CABLE 0.02" (0.50 mm) Type 1,152.4 mm	MPN: 940-99-00012 DPN:
D2	USB CABLE FOR Vitek\Ampire DISPLAY (SP-140672)	MPN: 940-99-00027 DPN:
D3	NETWORK CABLE RJ485 (8 WIRES, 0.5 METERS)	MPN: 940-99-00011 DPN:
D4	FLAT FF14P 25CM F"D>_V1.0.0 (SP-141161)	MPN: 999-99-00457 DPN:
D6	CABLE GSM 40cm M.SMA-UFL (SP-490008)	MPN: 940-99-00036 DPN:

10.3.5 TRIO 20 MAIN CONTAINER SPARE PARTS





ID No.	Description	Catalog Number	Note
C1	Trio-20 MAIN CARD (Trio-20 MAIN)	MPN: 940-99-00003	
		DPN:	
C1.1	SWPS LPV-60-12 Mean Well 100-240V 12V 60W (SP-370193)	MPN: 900-99-00264	
		DPN:	
C2	STATIC PRESSURE SET - AC3G / SE / PL / Trio - POU (WITH EXTERNAL TUBE)	MPN: 901-99-00025	
		DPN:	
C3.1	Trio 20 SCALE CARD 2SCL (Trio-RSC-2)	MPN: 940-99-00013	OR
		DPN:	
C3.2	Trio 20 SCALE CARD 2SCL (Trio-RSC-6)	MPN: 940-99-00014	
		DPN:	
C5	ANTENNA 699-2690MHz 3.2dBi 500HM MAGNETIC WITH MOUNTING BRACKET 2G/3G/4G (SP-491010)	MPN: 940-99-00039	
		DPN:	



ID No.	Description	Catalog Number
C4	BAT COIN 3V FOR SOCKET(SP-450009)	MPN: 999-99-00386
		DPN:

10.3.6 ADDITIONAL OPTIONS





ID No.	Description	Catalog Number	Notes
ADO 1	TEMPERATURE SENSOR BLACK-RTS-2-POU	MPN: 918-01-00001	
		DPN:	




ADO2.1a	RHS10 HUMIDITY SENSING TIP SE (SP-RHS10-TIP-SE)	MPN: 999-99-00214 DPN:	For +/SE Sensor
ADO2.2.1	HUMIDITY SENSOR-RHS-PRO-POU-MUR	MPN: 917-04-10001 DPN:	OR
ADO2.2.2	HUMIDITY SENSOR-RHS-PRO-POU-PLS	MPN: 917-04-00002 DPN:	
ADO2.2.1a/ 2.2.2a	HUMIDITY SENSOR PRO TIP - (RHS-PRO-TIP)	MPN: 917-99-00002 DPN :	For Pro Sensor
ADO 3	TRIO GLOBAL LTE CELL MODEM & EXTERNAL ANTENNA SET	MPN: 940-99-00049 DPN:	
ADO 4	STATIC PRESSURE SET - AC3G/SE/PL/TRIO - POU	MPN: 901-99-00025 DPN:	
ADO 4.a	TUBES AND FILTERS FOR RPS (NO RPS CARD)	MPN: 999-99-00503 DPN:	
ADO 5.1	TRIO 20 SCALE CARD 2SCL WITH 230V POWER SUPPLY	MPN: 940-99-00015 DPN:	OR
ADO 5.2	TRIO 20 SCALE CARD 6SCL WITH 230V POWER SUPPLY	MPN: 940-99-00016 DPN:	OR
ADO 5.3	TRIO 20 SCALE CARD 2SCL WITH 115V POWER SUPPLY	MPN: 940-99-00017 DPN:	OR
ADO 5.4	TRIO 20 SCALE CARD 6SCL WITH 115V POWER SUPPLY	MPN: 940-99-00018 DPN:	
ADO 6.1	CO2 PRO-POU-EN-MUR	MPN: 919-03-10001 DPN:	OR
ADO 6.2	CO2 PRO-POU-EN-NRO	MPN: 919-03-20001 DPN:	
ADO 7	AMMONIA-POU-MUN	MPN: 929-01-00002 DPN:	
ADO 8	LIGHT SENSOR-RLS-1-40LUX-POU	MPN: 928-01-00002 DPN:	

10.3.7 CARDS




- Door Cards
- Main Container Cards
- Door Set





10.3.7.1 Door Cards

Card	Description	Catalog Number
	<p>250061: LCD TFT 10.1' VT101C-KC17- B07A Vitek</p> <p>Or</p> <p>AM- 1024600O2TMQW- TA0H Ampire</p> <p>Or</p> <p>TWS2101RBTV20C APEX</p>	<p>940-99-00002</p>
	<p>140672: USB CABLE FOR Vitek\Ampire DISPLAY</p>	<p>940-99-00027</p>
	<p>208027:TRIO- DISPLAY PC BOARD IMX8 NEXCOM</p>	<p>940-99-00004 (EN)</p> <p>940-99-00164 (CN)</p>
	<p>FAN 12V 0.62W 7000RPM 8CFM (SP-240201)</p>	<p>940-99-00177</p>

Card	Description	Catalog Number
	<p>491009: ANTENNA WIFI MOLEX 15cm CABLE U.FL/I-PEX MHF 2.4GHz 2.8dBi 50ohm/YF0026AA Quectel</p>	<p>940-99-00035</p>
	<p>490099: QUECTEL GLOBAL LTE CELL MOD EM W/O SIM SOCKET-EG21GGB- MINIPCIE</p>	<p>904-99-00106</p>
	<p>221011: TRIO CELL MODEM GLOBAL SIM</p>	<p>904-99-00118</p>

10.3.7.2 Main Container Cards

Card	Description	Catalog Number
	<p>R-TRIO-20-MAIN: MUNTERS ROTEM MIDDLE RANGE 2 CPU</p>	<p>940-99-00003</p>
	<p>370193: SWPS LPV- 60-12 Mean Well 100-240V 12V 60W</p>	<p>900-99-00264</p>
	<p>STATIC PRESSURE SET - AC3G/SE/PL/TRIO - POU</p>	<p>901-99-00025</p>

Card	Description	Catalog Number
	<p>TUBES AND FILTERS FOR RPS (NO RPS CARD)</p>	<p>999-99-00503</p>
	<p>R-TRIO-RSC-2: TRIO 20 SCALE CARD 2CH</p>	<p>940-99-00013</p>
	<p>R-TRIO-RSC-6: TRIO 20 SCALE CARD 6CH</p>	<p>940-99-00014</p>
	<p>ANTENNA 699-2690MHz 3.2dBi 50OHM MAGNETIC 2G/3G/4G (SP-491010)</p>	<p>940-99-00039</p>

10.3.7.3 Door Set

Card	Description	Catalog Number
	TRIO-20 COMPLETE DOOR SET	940-99-00133

11 Appendix D: TRIO Expansion

- Introduction
- Expansion 10
- Expansion 20
- Mapping Devices in Expansion
- Expansion Specifications
- Expansion Spare Parts

11.1 Introduction

- Observe all the safety rules given in Precautions, page 11.
- Install the unit according to the instructions given in Unit Installation, page 25.

11.2 Expansion 10

- Expansion Layout
- TRIO to TRIO 10 Expansion Wiring
- High Voltage Relays
- Power

11.2.1 EXPANSION LAYOUT




Figure 59: Board layout

1	10 relays
2	RS-485 ports
3	Power ports
4	Ground strip
5	Address dipswitch (refer to Address, page 159)

11.2.2 TRIO TO TRIO 10 EXPANSION WIRING

Connecting the Trio to its Expansion Unit consists of three steps:

- Wiring
- Address
- Restart

11.2.2.1 Wiring




Figure 60: Wiring diagram

- The cable between the controller and the expansion unit should be a 4 wire twisted shielded cable (22 or 24 AWG).
- 1 – red wire
- 2 – black wire
- 3 – COM

11.2.2.2 Address

The Trio can support one expansion unit. Verify that both dipswitches in the Modbus Address are set to ON.




Figure 61: Expansion Address

11.2.2.3 Restart

After connecting the units and verifying the Modbus address, reset the factory settings.

1. Go to System > General Settings > .

2. Click .

3. Follow the on-line instructions. You have the option of backing up the settings. Refer to the User Manual for more information.

11.2.3 HIGH VOLTAGE RELAYS




Figure 62: High voltage devices (examples)

1	Example of devices
---	--------------------

NOTE The relays control motors and heating devices via contactors, not directly.




Figure 63: Relay and port numbering

11.2.4 POWER




Figure 64: Power ports

11.3 Expansion 20

- Expansion Layout
- Expansion Wiring Diagrams
- High Voltage Relays
- Power

11.3.1 EXPANSION LAYOUT




Figure 65: Board layout

1	20 relays
2	RS-485 ports
3	Power ports
4	Ground strip
5	Address dipswitch (refer to Address, page 159)

11.3.2 EXPANSION WIRING DIAGRAMS

Connecting the Trio to its Expansion Unit consists of three steps:

- Wiring
- Address
- Restart

11.3.2.1 Wiring




Figure 66: Wiring diagram

- The cable between the controller and the expansion unit should be a 4 wire twisted shielded cable (22 or 24 AWG).
- 1 – red wire
- 2 – black wire
- 3 – Comm wire

11.3.2.2 Address

The Trio can support one expansion unit. Verify that both dipswitches in the Modbus Address are set to ON.






Figure 67: Expansion Address

11.3.2.3 Restart

After connecting the units and verifying the Modbus address, reset the factory settings.

1. Go to System > General Settings > .
2. Click .
3. Follow the on-line instructions. You have the option of backing up the settings. Refer to the User Manual for more information.

11.3.3 HIGH VOLTAGE RELAYS




Figure 68: High voltage devices (examples)

1	Example of devices
---	--------------------

NOTE The relays control motors and heating devices via contactors, not directly.




Figure 69: Relay and port numbering

11.3.4 POWER




Figure 70: Power ports

11.4 Mapping Devices in Expansion

- Install and wire the Expansion unit to the TRIO and to the external devices before beginning.

- After wiring the Expansion unit to TRIO, go to System > General Settings > Info 




and click **Reset Factory Settings**. Follow the online instructions. TRIO will not recognize the Expansion until this step is performed.

After wiring devices to the TRIO Expansion Unit, each device must be mapped and then defined. Mapping and defining devices enables the system software to control each device's functionality.

CAUTION Mapping *MUST* match the physical wiring! An error message appears if the physical device is not wired to the relay or port as defined on the mapping screen.

To map the devices:

1. Go to System > Device and Sensors.



2. Click Expansion.




Figure 71: Expansion 20 Expansion Screen

3. Map the devices as detailed in the TRIO manual. Refer to the manual for more information.
4. Click I to get information on the Expansion Card.








Figure 72: Expansion 20 Information

5. Map the devices as detailed in the TRIO manual. (refer to Using the Mapping Screen, page 75) for more information.





11.5 Expansion Specifications

- Expansion 10 Specifications
- Expansion 20 Specifications
- Expansion Specification Details

11.5.1 EXPANSION 10 SPECIFICATIONS

Parameter	Specifications
Input Power Voltage	115/230 VAC, 50/60 Hz
Input AC Power	0.2A
Maximum number of relays operating simultaneously	10
<i>Note: Running relays at the above current levels provides between 50,000 – 100,000 switching operations.</i>	
Communication	RS-485: 115 Kbps, 8 bit, even parity
Operating Temperature Range	-10° to +50° C (+14° to +125° F)
Storage Temperature Range	-20° to +80° C (-4° to +176° F)
Environmental Specifications	<ul style="list-style-type: none"> • Altitude: -400 m to 2000 m • Relative Humidity: 20% - 90% • Main supply voltage fluctuation up to +10 - 20% • Overvoltage category II
Enclosure	Water and dust tight Indoor use only
Dimensions (H/W/D)	403 x 324 x 141 mm/16 x 13 x 5.6 inches
Fuses	Fuse F2 on PS card: 3.15A, 250V
Certification	   

11.5.2 EXPANSION 20 SPECIFICATIONS

Parameter	Specifications
Input Power Voltage	115/230 VAC, 50/60 Hz
Input AC Power	500 mA
Maximum number of relays operating simultaneously	15
<i>Note: Running relays at the above current levels provides between 50,000 – 100,000 switching operations.</i>	
Communication	RS-485: 115 Kbps, 8 bit, even parity
Operating Temperature Range	-10° to +50° C (+14° to +125° F)
Storage Temperature Range	-20° to +80° C (-4° to +176° F)
Environmental Specifications	<ul style="list-style-type: none"> • Altitude: -400 m to 2000 m • Relative Humidity: 20% - 90% • Main supply voltage fluctuation up to +10 - 20% • Overvoltage category II • PD: 2
Enclosure	<ul style="list-style-type: none"> • IP: 52 • Indoor use only
Dimensions (H/W/D)	403 x 324 x 141 mm/16 x 13 x 5.6 inches
Fuses	Fuse F2 on PS card: 3.15A, 250V
Certification	   

11.5.3 EXPANSION SPECIFICATION DETAILS

- **Disconnection device/overcurrent protection:** In the building installation, use a certified 2-pole circuit breaker rated 10A, certified in accordance with the IEC standard 60947-2 (in the US and Canada use a Listed Branch Circuit protective circuit breaker). This step is required to provide overcurrent protection and mains disconnection. The circuit breaker must be easily accessible and marked as the controller disconnect device.
- **Main Supply Voltage:** Permanently connect the controller to the mains in accordance with the relevant national code. Provide fixed wiring inside a flexible conduit. Relays must be suitably protected against overcurrent, using a circuit breaker rated at 10A.
- **Keep the units closed and locked.** Only authorized personnel should open and close the units.

11.6 Expansion Spare Parts

- Preliminary Information
- Trio Expansion 10 Spare Parts
- Trio Expansion 20 Spare Parts
- Additional Options
- Cards


11.6.1 PRELIMINARY INFORMATION

	TRIO EXP 10	TRIO EXP 20
Container	A	C
Main Container Cards	B	D
Cables and Harnesses	N/A	E
MPN	Munters Part Number	
DPN	Distributor Part Number	

11.6.2 TRIO EXPANSION 10 SPARE PARTS


- Trio Expansion 10 Container Spare Parts
- Trio 20 Main Container Spare Parts

11.6.2.1 Trio Expansion 10 Container Spare Parts



ID No.	Description	Catalog Number	Note
A1.1	TRIO FRONT DOOR EXP PLASTIC PART V1.0.0 (SP: 207129)	MPN: 940-99-00028 DPN:	
A1.2	TRIO-20 PLASTIC BOX BASE (SP: 207124)	MPN: 940-99-00112 DPN:	
A1.3	TRIO HINGE PLASTIC PIN V1.0.0 (SP-207128)	MPN: 940-99-00019 DPN:	
A2.1	TRIO-20 PANEL PLASTIC PART BLUE LOGO MUNTERS + PART BLUE	MPN: 940-99-00001 DPN:	OR
A2.2	TRIO PANEL PLASTIC PART RED RAL 3020 NO LOGO (SP-207138)	MPN: 940-99-00045 DPN:	
A3.1	GENERAL PLASTIC LATCH	MPN: 900-99-00216 DPN:	
A3.2	ONE/ONE PRO LATCH GENERAL LOCK PLASTIC PART + LOCK FOR LATCH	MPN: 900-99-00217 DPN:	
A4	MID-RANGE MAIN GASKET V1.0.0 (SP-207122)	MPN: 940-99-00021 DPN:	

11.6.2.2 Trio Expansion 10 Main Container Spare Parts




ID No.	Description	Catalog Number
B1	TRIO-EXP 10 CARD (SP: R-TRIO-EXP10)	MPN: 940-99-00029
		DPN:
B1.1	SWPS APV-16-12 Mean Well 115V/230V 12V 16W (SP: 370153)	MPN: 999-99-00338
		DPN:

11.6.3 TRIO EXPANSION 20 SPARE PARTS

- Trio Expansion 20 Container Spare Parts
- Trio Expansion 20 Main Container Spare Parts


11.6.3.1 Trio Expansion 20 Container Spare Parts





ID No.	Description	Catalog Number	Note
C1.1	TRIO FRONT DOOR EXP PLASTIC PART V1.0.0 (SP: 207129)	MPN: 940-99-00028	
		DPN:	
C1.2	TRIO-20 PLASTIC BOX BASE (SP: 207124)	MPN: 940-99-00112	
		DPN:	
C1.3	TRIO HINGE PLASTIC PIN V1.0.0 (SP-207128)	MPN: 940-99-00019	
		DPN:	
C2.1	TRIO-20 PANEL PLASTIC PART BLUE LOGO MUNTERS + PART BLUE	MPN: 940-99-00001	OR
		DPN:	
C2.2	TRIO PANEL PLASTIC PART RED RAL 3020 NO LOGO (SP-207138)	MPN: 940-99-00045	
		DPN:	
C3.1	GENERAL PLASTIC LATCH	MPN: 900-99-00216	
		DPN:	
C3.2	ONE/ONE PRO LATCH GENERAL LOCK PLASTIC PART + LOCK FOR LATCH	MPN: 900-99-00217	
		DPN:	
C4	MID-RANGE MAIN GASKET V1.0.0 (SP-207122)	MPN: 940-99-00021	
		DPN:	

11.6.3.2 Trio Expansion 20 Main Container Spare Parts






ID No.	Description	Catalog Number
D1	TRIO-EXP 10 CARD (SP: R-TRIO-EXP10)	MPN: 940-99-00029 DPN:
D1.1	SWPS APV-16-12 Mean Well 115V/230V 12V 16W (SP: 370153)	MPN: 999-99-00338 DPN:
D2	TRIO EXP 10 RELAY ADDIT CARD (TRIO-EXP-10R)	MPN: 940-99-00159 DPN:

ID No.	Description	Catalog Number
E1	FLAT FF14P 34cm (TRIO EXP)<F"D_F"D> (SP-141201)	MPN: 940-99-00168 DPN:

11.6.4 ADDITIONAL OPTIONS

ID No.	Description	Catalog Number
ADO 1	Trio Expansion: 10 Relays To 20 Relays Upgrade Kit	MPN: 940-99-00169
		DPN:

11.6.5 CARDS

Card	Description	Catalog Number
 <p>A green printed circuit board (PCB) for a Trio expansion. It features a central microcontroller, various integrated circuits, and a large white power supply unit (APV-16-12) mounted on the right side. There are several terminal blocks and connectors along the bottom edge. The board is labeled 'C-TRIO-EXT Ver. 1.0.0 270794'.</p>	R-TRIO-EXP10: TRIO EXP 10 CARD	940-99-00029
 <p>A white Mean Well APV-16-12 power supply unit. It has a rectangular shape with a label on top providing technical specifications: 'APV-16-12', 'INPUT: 100-240V~ 0.55A 50/60Hz', 'OUTPUT: +12VDC 1.33A', '12V 16W'. It has four wires extending from it: red, black, blue, and brown.</p>	370153: SWPS APV-16-12 Mean Well 115V/230V 12V 16W	999-99-00338
 <p>A green PCB for a Trio expansion with 10 relays. It features ten relay modules mounted in a row. Each relay has a label 'RELAY RELAY'. The board is labeled 'TRIO-EXP-10R Ver. 1.0.0' and has the Munters logo. A barcode and '270818' are also visible.</p>	R-TRIO-EXP- 10R: CARD EXP RLY ADDIT 10 TRIO	940-99-00159

12 Appendix E: Trio Cell Modem Installation

This document details how to install and configure a cell modem in a Trio unit lacking this device.

- Prerequisites
- Installation

12.1 Prerequisites

- Supported Devices
- Required Software
- Internet Access

12.1.1 SUPPORTED DEVICES

Trio Display Card Version 1.1.0 or above supports the modem.

- Order: 940-99-00049 Trio GLOBAL LTE CELL MODEM & EXTERNAL ANTENNA.
- For Trio Display Board versions 1.0 or lower, contact Customer Success.



Figure 73: SIM 940-99-00049 Front and Back

12.1.2 REQUIRED SOFTWARE

Trio cell modem requires the following software installations:

- Image Version 1.5. Consult with a Munters technician on how to install the image.
- Software Version 5.0 or higher. Upgrade this software via the Trio Software Upgrade screen.

12.1.3 INTERNET ACCESS

Trio has a priority system for internet access:

1. LAN connection
2. WIFI
3. Cell modem

If a LAN connection is available, Trio automatically connects to the web via the LAN only, even if the unit supports WIFI or a cell modem connection. If there is no LAN, Trio uses WIFI. Trio will only use the cell modem when the first two options are not available.

12.2 Installation

- Physical Installation
- Configuration


12.2.1 PHYSICAL INSTALLATION


- Modem and SIM Card
- Drilling

12.2.1.1 Modem and SIM Card


1. Locate the designated spot for the modem.

2. Insert the modem into the connector and secure it using the two screws supplied.








3. Insert the SIM card into the SIM port.




4. Gently press the cable connector onto the modem.




5. Thread the modem cable to the connector as shown below.




6. Remove the plug in the spot designated for the SMA connector.



7. Remove the sealing cap and attach the antenna. (For older units, refer to the next section.)




8. Secure the antenna using the brace provided.





12.2.1.2 Drilling

In the event that the Trio unit was shipped before 08/2022, a hole must be drilled for the SMA connector.



1. Drill a 6.5-millimeter hole in the spot shown below.



2. Insert and secure the SMA connector.



3. Thread the modem cable to the connector as shown below.




12.2.2 CONFIGURATION


NOTE The cellular Modem function appears only if a modem is installed with a working SIM card.

To configure the cell modem:

1. Go to System > General Settings > Network.




2. Under Cellular Modem, click **Manage**.



3. Under Cellular Modem, click **Manage**.

4. Final steps:

- a. Enable the modem.
- b. Using data provided by your service provider, enter the data in the fields.
- c. Click **Save**.



(example only!)

13 Appendix F: Panel Mount Installation

The following section details the Trio Panel Mount and Trio Expansion Panel Mount installation.

- Trio Panel Mount Installation
- Trio Expansion Panel Mount Installation

13.1 Trio Panel Mount Installation

The Trio Panel Mount consists of two elements, connected by flat ribbons and internet cable:

- Front panel (CPU panel)
- Rear panel (relay / card panel)

- Precautions
- Panels
- Panel Dimensions
- Mounting the Panels
- Panel Cables
- Powering and Alarms
- Grounding

13.1.1 PRECAUTIONS

Ensure the following:

- The setup meets electrical, mechanical and fire enclosure requirements.
- Clearance and creepage distances are maintained.
- Grounding meets industry standards.
- Ambient temperatures do not go above product requirements (50° C).
- If this unit is installed in an electrical closet, ensure that no contactors are in that closet. Placing this unit in proximity to contactors results in severe signal interference.

13.1.2 PANELS



Figure 74: Trio CPU Panel, Front View




Figure 75: Trio CPU Panel, Rear View




Figure 76: Trio Relay Panel, Front View

13.1.3 PANEL DIMENSIONS

Distances are in millimetres.




Figure 77: Front Panel Depth Dimensions




Figure 78: Rear Panel Dimensions




Figure 79: Rear Panel Depth Dimensions

13.1.4 MOUNTING THE PANELS




Figure 80: Panel Cutting and Drilling Dimensions (millimeters)

- Drill eight holes as indicated above.
- Using the dimensions shown, cut out a space into which the CPU Front Door is placed.

13.1.5 PANEL CABLES




Figure 81: Panel Mount, Open Closet (sizes are not to scale)

- Connect the flat cable and internet cable as shown above.
- Mount the Trio Panel Front Door on the left door (hinge on left side).
- The distance between the Front Door and the Rear Panel must be less than one (1) meter!
- Make sure that there is at least 20 cm/8 inches between the Trio relay plate and the electrical cabinet having power contactors.
- Any inverter must be at least five meters away from the controller.
- To prevent signal disruption, do not run sensor wiring via the DIN rails.
- Do not run power wires through the area of the Trio relay plate.

13.1.6 POWERING AND ALARMS

- Connect the light or siren device to the alarm relay.




Figure 82: Alarm relay and power ports

1	Alarm relay
2	Power ports

13.1.7 GROUNDING




Figure 83: Grounding

CAUTION The unit must be grounded at all times!

13.2 Trio Expansion Panel Mount Installation

The Trio Expansion Panel Mount) consists of two elements, connected by flat ribbons and internet cable:

Trio Expansion Panel supports 10 or 20 relays.

- 10 relays: P/N 940-10-10001
- 20 relays: P/N 940-10-10002

- Precautions
- Panels
- Panel Dimensions
- Panel Expansion Wiring

13.2.1 PRECAUTIONS

Ensure the following:

- The setup meets electrical, mechanical and fire enclosure requirements.
- Clearance and creepage distances are maintained.
- Grounding meets industry standards.
- Ambient temperatures do not go above product requirements (50° C).
- Ensure that no contactors are in that closet. Placing this unit in proximity to contactors results in severe signal interference.

13.2.2 PANELS




Figure 84: Trio Expansion 10 Relay Panel, Front View




Figure 85: Trio Expansion 20 Relay Panel, Front View

13.2.3 PANEL DIMENSIONS

Distances are in millimetres.




Figure 86: Expansion Rear Panel Dimensions




Figure 87: Rear Panel Depth Dimensions

13.2.4 PANEL EXPANSION WIRING

Connecting the Trio to its Expansion Unit consists of three steps:

- Wiring
- Address
- Restart

13.2.4.1 Wiring




Figure 88: Panel Mount/Expansion Panel Mount Wiring

- The cable between the controller and the expansion unit should be a 4-wire twisted shielded cable (22 or 24 AWG).
- 1 – red wire
- 2 – black wire
- 3 – COM

13.2.4.2 Address

The Trio Panel can support one expansion unit. Verify that both dipswitches in the Modbus Address are set to ON.




Figure 89: Panel Expansion Address

13.2.4.3 Restart

After connecting the units and verifying the Modbus address, reset the factory settings.

1. Go to System > General Settings > .



2. Click
3. Follow the on-line instructions. You have the option of backing up the settings. Refer to the User Manual for more information.

13.2.5 POWER




Figure 90: Power ports

14 Appendix G: IT Setup

The following information is intended for the IT specialist/ISP personnel setting up the internet LAN network between the Communicator 2.0 and Trio Controllers.

- IT Setup
- Subnet Setup
- LAN Cable Information
- Typical Setups

14.1 IT Setup

- Communicator 2.0 for Trio and Trio controllers must be on same subnet LAN.

WARNING! *In order to ensure continual communication, the Communicator 2.0 and Trio LAN must be an independent dedicated subnet.*

- Employ a standard home router, using the default settings, and all devices on the same router.
- On the local network, Communicator 2.0 and Trio must have same the subnet mask (subnet mask must be **255.255.255.0**).
- Three first sections of the Communicator 2.0 and Trio IP address must have the same numbers (for example **192.168.1.x**).
- Network must be IPv4.
- The local network can employ a firewall on condition that the following ports are open:
 - Zero-configuration networking (zeroconf)
 - RabbitMQ
 - MQTT
 - AMQPT
 - 15672
 - 1883
 - 4200
 - UDP port 5353
 - UDP port 1900
 - TCP port 3689
 - 5355
 - 1883 MQTT
- Communicator 2.0 has a built-in firewall; all outgoing ports are closed. Incoming ports 8- and 443 are open.

14.2 Subnet Setup

To create a subnet within an industrial network that uses its own DHCP server with the range 192.168.1.1 - 192.168.1.255 or 192.168.2.1 - 192.168.2.255, you need networking equipment capable of isolating and managing traffic.

- Required Equipment
- Procedure

CAUTION Only Communicator 2.0 for Trio and Trio Controllers can be part of this subnet.

14.2.1 REQUIRED EQUIPMENT

- Router or Layer 3 Switch:
 - Capable of creating and managing subnets
 - Allows routing between subnets if required
 - Example: Cisco ISR, Ubiquiti EdgeRouter, or MikroTik
- Managed Switch (Optional):
 - If you need to segment traffic further with VLANs
 - Example: Cisco Catalyst, TP-Link JetStream, or similar
- DHCP Server or Router with DHCP Capabilities:
 - Configure a separate DHCP scope for the new subnet
 - Many modern routers support multiple DHCP scopes
- Firewall (Optional, for added security):
 - To enforce rules between the industrial network and the new subnet

14.2.2 PROCEDURE

1. Define the Subnet:
 - Choose a new IP range (e.g., 192.168.2.0/24)
2. Set Up the Router:
 - Configure a new interface or sub-interface for the new subnet
 - Assign an IP address (e.g., 192.168.2.1) to this interface
3. Configure DHCP for the New Subnet:
 - On the router or a dedicated DHCP server, set a DHCP scope (e.g., 192.168.2.2 - 192.168.2.254)
4. Isolate Traffic:
 - Ensure the industrial network (192.168.1.0/24) and the new subnet (e.g., 192.168.2.0/24) are isolated
 - Use VLANs or routing rules to control traffic flow
5. Connect Devices:
 - Connect devices in the new subnet to the appropriate port on the router/switch

14.3 LAN Cable Information

- Wire/Optical Ethernet Infrastructure Basics
- Trio Connectivity: 100/1000 GBPS Ethernet Switch

14.3.1 WIRE/OPTICAL ETHERNET INFRASTRUCTURE BASICS

- Wire Ethernet 1100/1000 BaseT Copper
 - Media – CAT5E or CAT6 Cable with maximum segment length of 100 meters
- Optical Ethernet 1000Base-X Optical
 - 1000Base-SX Media: Short Haul multi-mode optic fiber (MMF) with maximum segment length of 220 meters (62.5/125µm type) or 550 meters (50/125µm type)
 - 1000Base-LX Media: Long Haul single-mode optic fiber (SMF) with maximum segment length of 10000 meters
- Connectivity
 - Connectivity is Point-to-Point using 100/1000 Switches
 - Low latency network. If the DHCP takes too long (over 3 minutes) to assign IP addresses to controls, it may cause lost communication alarms when controls reset.
- Equipment
 - Wire Switch serves for Ethernet switching over wire connectivity
 - Could be with preinstalled specific Optic Transceiver (short or long haul)
 - Could be with the SFP port, serving for pluggable SFP Optic Transceiver
 - SFP Transceiver pluggable device serving to transmit data over optic fiber
 - 1000Base-SX SFP serves for multi-mode optic fiber (MMF) of
 - 62.5/125µm type or 50/125µm type
 - 1000Base-LX SFP serves for single-mode optic fiber (SMF)
 - Media Converters server for converting from optics to wire and vice versa. This is used for segments over 100 meters / 330 feet.

14.3.2 TRIO CONNECTIVITY: 100/1000 GBPS ETHERNET SWITCH

- The switch is wired to the router and modem to access the Internet.
- Switches can be wired to each other by Ethernet cables, each one splitting off to other devices.
- Gigabit switches support 100 and 1,000 Mbps.

14.4 Typical Setups




Figure 91: Typical Poultry Installation 1




Figure 92: Typical Poultry Installation 2




Figure 93: Typical Swine Installation

15 Index

3V Battery		Digital Device	
Location	28, 29	Schematic	35
Alarm Battery		Digital Devices	
Restart.....	125	Wiring.....	35
Ventilation.....	125	Dipswitches.....	27
Ammonia Sensor		electrical shock.....	15
Schematic	45	electrician	15
Wiring.....	44	Environmental Specifications.....	70
Analog Out Devices		Ethernet Port	29
Wiring.....	34	Location	33
authorized electrician	15	Firewall	195, 196
Batch Counter		Heat Sink	28
Mapping.....	54	Icon	
Pulse.....	54	3V Battery.....	73
Wiring.....	53	Delete Data	73
Batch Weighing		Edit Parameters.....	73
Auger		Settings.....	73
Feed Per Minute	57	Installation	
Batch Hopper Limit	58	Inverter.....	14
Bin Capacity	56	Keys	24, 25, 71
Silo		LAN Cable	197
Capacity	57	Equipment.....	197
Board layout		SFP Transceiver	197
Version 1.1.0.....	28	Wire Switch	197
Board Layout		Latency.....	197
Version 1.0.4.....	29	Media	197
Bracket.....	25, 26	Optic Fiber	197
Cable		Switches.....	197
Ethernet.....	26	Light Dimmer	
Cables		Wiring.....	34
Routing	25	Light Sensor	
Certification	71	Schematic	46
CO2		Wiring.....	45
Schematic	38	Main Supply Voltage.....	71
Communicator 2.0.....	195	Mapping.....	75
Contactors.....	31	Devices	76
DCOM Port.....	35	Error Message.....	75

Sensors.....	76	Wiring.....	39
Modem.....	28, 29	RTV	26
Outdoor Temperature Sensor	81	SD Port.....	28, 29
Overcurrent Protection	71	sealant.....	26
Potentiometer		shock.....	15
Schematic	43	silicon	26
Wiring.....	43	SIM Port	29
Power Loss.....	125	Siren Device	32
SMS.....	125	Subnet	
Power Ports	32	DHCP Server	196
Relay		Router/Switch	196
Alarm.....	32	Subnet Mask	195
Relays		Switching Operations	70
Numbering	31	Symbols	
RHS		Caution.....	24
Schematic	42	Earthing	24
Wiring.....	41	Hazardous voltage.....	24
RLED 2.0		Temperature	
Wiring.....	53, 54, 55	Average.....	80
RPLP-1	12	Device.....	80
RPS		Outside.....	80
Schematic	47	Tunnel	80
Static Pressure Tubes.....	47	Termination.....	61
Wiring.....	46	RLED-2.....	62
RSC Card		Trio	
Bird Scale Schematic.....	49	Static Pressure Tubes.....	63
Bird Scale Wiring	48	TrioAir	
Silo /RJB-6 Schematic.....	51	Access	65
Silo/RJB--6 Wiring.....	50	Chrome.....	65
RSU		Wireless Antenna	28
Wiring.....	52	Wiring	
RTC Batteries.....	27	Analog Input Devices	36
RTS-2	25	Analog Output Devices	34
S Port Schematic.....	40	CO2 Sensor	36
S Port Wiring	40	Digital Devices.....	35
Schematic	39	Light Dimmer Devices.....	34

16 Warranty

Warranty and technical assistance

Munters products are designed and built to provide reliable and satisfactory performance but cannot be guaranteed free of faults; although they are reliable products they can develop unforeseeable defects and the user must take this into account and arrange adequate emergency or alarm systems if failure to operate could cause damage to the articles for which the Munters plant was required: if this is not done, the user is fully responsible for the damage which they could suffer.

Munters extends this limited warranty to the first purchaser and guarantees its products to be free from defects originating in manufacture or materials for one year from the date of delivery, provided that suitable transport, storage, installation and maintenance terms are complied with. The warranty does not apply if the products have been repaired without express authorisation from Munters, or repaired in such a way that, in Munters' judgement, their performance and reliability have been impaired, or incorrectly installed, or subjected to improper use. The user accepts total responsibility for incorrect use of the products.

The warranty on products from outside suppliers fitted to Trio, (for example antennas, power supplies, cables, etc.) is limited to the conditions stated by the supplier: all claims must be made in writing within eight days of the discovery of the defect and within 12 months of the delivery of the defective product. Munters has thirty days from the date of receipt in which to take action, and has the right to examine the product at the customer's premises or at its own plant (carriage cost to be borne by the customer).

Munters at its sole discretion has the option of replacing or repairing, free of charge, products which it considers defective, and will arrange for their despatch back to the customer carriage paid. In the case of faulty parts of small commercial value which are widely available (such as bolts, etc.) for urgent despatch, where the cost of carriage would exceed the value of the parts, Munters may authorise the customer exclusively to purchase the replacement parts locally; Munters will reimburse the value of the product at its cost price.

Munters will not be liable for costs incurred in demounting the defective part, or the time required to travel to site and the associated travel costs. No agent, employee or dealer is authorised to give any further guarantees or to accept any other liability on Munters' behalf in connection with other Munters products, except in writing with the signature of one of the Company's Managers.

WARNING: In the interests of improving the quality of its products and services, Munters reserves the right at any time and without prior notice to alter the specifications in this manual.

The liability of the manufacturer Munters ceases in the event of:

- dismantling the safety devices;
- use of unauthorised materials;

- inadequate maintenance;
- use of non-original spare parts and accessories.

Barring specific contractual terms, the following are directly at the user's expense:

- preparing installation sites;
- providing an electricity supply (including the protective equipotential bonding (PE) conductor, in accordance with CEI EN 60204-1, paragraph 8.2), for correctly connecting the equipment to the mains electricity supply;
- providing ancillary services appropriate to the requirements of the plant on the basis of the information supplied with regard to installation;
- tools and consumables required for fitting and installation;
- lubricants necessary for commissioning and maintenance.

It is mandatory to purchase and use only original spare parts or those recommended by the manufacturer.

Dismantling and assembly must be performed by qualified technicians and according to the manufacturer's instructions.

The use of non-original spare parts or incorrect assembly exonerates the manufacturer from all liability.

Requests for technical assistance and spare parts can be made directly to the nearest [Munters office](#).

