


RBS-1 Bird Scale Wiring



An RBS-1 Power Supply (P/N: A-RBS1-PS-V1/2) is required for connecting a bird scale to an AC-2000SE unit. Each AC-2000SE unit has the option of connecting up to two bird scales.



- Connect Black and Red wires of Scale-1 > Scale 1 terminal, and Black and Red wires of Scale-2 > Scale 2 terminal