


EMERGENCY SIREN INSTALLATION QUICK GUIDE

1. Open the Emergency Siren Box by loosening the 4 screws located at each corner.
2. Make sure that the red and black wires are connected to the battery charger in the appropriate locations:
RED + **BLACK –**
3. Connect a wire from the (+) of the right terminal (To Backup Card) to the **COMMON (COM)** of the alarm card.
4. Connect the wiring as follows:
 - a. Connect the **BLACK** wires to the (–) of the right terminal (To Backup Card).
 - b. Connect the **RED** wires to **N.C. (Normally Closed)** of the alarm card.
5. Connect the Main Power to the BATTERY CHARGER card.



EMERGENCY SIREN INSTALLATION QUICK GUIDE

1. Open the Emergency Siren Box by loosening the 4 screws located at each corner.
2. Make sure that the red and black wires are connected to the battery charger in the appropriate locations:
RED + **BLACK –**
3. Connect a wire from the (+) of the right terminal (To Backup Card) to the **COMMON (COM)** of the alarm card.
4. Connect the wiring as follows:
 - a. Connect the **BLACK** wires to the (–) of the right terminal (To Backup Card).
 - b. Connect the **RED** wires to **N.C. (Normally Closed)** of the alarm card.
5. Connect the Main Power to the BATTERY CHARGER card.

