
Munters

Emergency Light & Siren

Installation Quick Guide

- 1. Open the Emergency Light & Siren Box by loosening the 4 screws located at each corner.
- 2. Make sure that the red and black wires are connected to the battery charger in the appropriate locations: **RED +/BLACK** –
- 3. Connect a wire from the (+) of the right terminal (*To Backup Card*) to the COMMON (*COM*) of the alarm card.
- 4. Notice that the Light and the Siren each have red and black wires of their own.
 - a. Connect the **BLACK** wires to the (–) of the right terminal (*To Backup Card*).
 - b. Connect the **RED** wires to **N.C. (Normally Closed)** of the alarm card.
- 5. Connect the Main Power to the BATTERY CHARGER card.



Power Supply Specification:

- Input: 115VAC, 1A fuse
- Output: 12VDC, 0.7A Max