

Emergency Light

Installation Guide

1. Open the Emergency Light Box by loosening the four screws located at each corner.
2. Make sure that the red and black wires are connected to the battery charger in the appropriate locations:
RED + **BLACK –**
3. Connect a wire from the **(+)** of the right terminal (*To Backup Card*) to the **COMMON (COM)** of the alarm card.
4. Notice that the Light has red and black wires.
 - a. Connect the **BLACK** wires to the **(–)** of the right terminal (*To Backup Card*).
 - b. Connect the **RED** wires to **N.C. (Normally Closed)** of the alarm card.
5. Connect the Main Power to the BATTERY CHARGER card.

